MidWestTech | Komatsu EG150-5, EG150B-5, EG150BS-5 Generator Operation & Maintena...

SEAM001901

Operation & Maintenance Manual

EG150-5
EG150B-5
EG150BS-5

GENERATOR

SERIAL NUMBERS EG150-6001
EG150B-6001 and up
EG150BS-6001

KOMATSU

Order the manual at mid-west-tech.com >

CONTENTS

OPERATION

SAFETY HINTS . . . ⚠ 4
GENERAL LOCATIONS AND SPECIFICATIONS 6
SWITCHES AND GAUGES 7
ENGINE CONTROL PANEL 7
GENERATOR CONTROL PANEL 11
OUTPUT TERMINALS AND GROUND TERMINAL 16
LOAD CONNECTION 18
VOLTAGE CHANGE-OVER 21
CHECK BEFORE STARTING 22
OPERATION 27
PARALLEL ARRANGED OPERATION 34
HANDLING OF BATTERY 37
COLD WEATHER OPERATION 40
TRANSPORTATION 45

MAINTENANCE

PERIODIC MAINTENANCE 47
PRECAUTIONS FOR MAINTENANCE 48
PERIODICAL REPLACEMENT OF SAFETY PARTS 52
MAINTENANCE TABLE 54
OIL FILLER AND LEVEL GAUGE POSITIONS 56
EVERY 50 HOURS SERVICE 57
EVERY 250 HOURS SERVICE 58
EVERY 500 HOURS SERVICE 62
EVERY 1000 HOURS SERVICE 65
EVERY 2000 HOURS SERVICE 67
EVERY 4000 HOURS SERVICE 69
WHEN REQUIRED 70
TROUBLE SHOOTING GUIDE 78
STORAGE 80
SERVICE METER 82
MACHINE AND ENGINE SERIAL NUMBERS 83
FUEL, COOLANT AND LUBRICANTS 84

MidWestTech | Komatsu EG150-5, EG150B-5, EG150BS-5 Generator Operation & Mai... Order the manual at mid-west-tech.com >