Operation & Maintenance Manual

SEAM007603T

D475A-2

BULLDOZER

SERIAL NUMBERS D475A-10365 and up

WARNING

Unsafe use of this machine may cause serious injury or death. Operators and maintenance personnel must read this manual before operating or maintaining this machine. This manual should be kept near the machine for reference and periodically reviewed by all personnel who will come into contact with it.

NOTICE

Komatsu has Operation & Maintenance Manuals written in some other languages. If a foreign language manual is necessary, contact your local distributor for availability.

KOMATSU®

MidWestTech | Komatsu D475A-2 Bulldozer Operation & Maintenance Manual | Publication... Order the manual at mid-west-tech.com >

5. CONTENTS

1. **Foreword** 0- 1

2. **Safety information** 0- 4

3. **Introduction** 0- 5

4. **Location of plates, table to enter serial No. and distributor** 0- 6

SAFETY

6. **General precautions** 1- 2

7. **Precautions during operation** 1- 8
   - 7.1 Before starting engine 1- 8
   - 7.2 Operating machine 1-10
   - 7.3 Transportation 1-13
   - 7.4 Battery 1-14
   - 7.5 Towing 1-15

8. **Precautions for maintenance** 1-16
   - 8.1 Before carrying out maintenance 1-16
   - 8.2 During maintenance 1-18

9. **Position for attaching safety labels** 1-23
   - 9.1 Position for attaching safety labels 1-23
   - 9.2 Content and use of warning plates 1-26

OPERATION

10. **General view** 2- 2
    - 10.1 General view of machine 2- 2
    - 10.2 General view of controls and gauges 2- 3

11. **Explanation of components** 2- 4
    - 11.1 Monitor panel 2- 4
    - 11.2 Lamps 2-14
    - 11.3 Switches 2-15
    - 11.4 Control levers and pedals 2-17
    - 11.5 Dust indicator 2-22
    - 11.6 Fuse box 2-22
    - 11.7 Door lock 2-23
    - 11.8 Car stereo 2-24
    - 11.9 Operating the air conditioner 2-30

MidWestTech | Komatsu D475A-2 Bulldozer Operation & Maintenance Manual | Publi... Order the manual at mid-west-tech.com >

12. Operation 2-36
12.1 Check before starting engine 2-36
12.2 Starting engine 2-49
12.3 Operations and checks after starting engine 2-52
12.4 Moving machine 2-53
12.5 Shifting gear 2-54
12.6 Shifting between forward and reverse 2-55
12.7 Steering machine 2-56
12.8 Stopping machine 2-58
12.9 Precautions for operation 2-59
12.10 Work possible using bulldozer 2-61
12.11 Ripper operation 2-62
12.12 Adjustment of work equipment 2-64
12.13 Parking machine 2-67
12.14 Check after finishing work 2-68
12.15 Stopping engine 2-69
12.16 Check after stopping engine 2-70
12.17 Locking 2-70
12.18 Tips longer undercarriage life 2-71

13. Transportation 2-73
13.1 Loading, unloading work 2-73
13.2 Precautions for loading 2-74
13.3 Lifting position 2-74
13.4 Precautions for transportation 2-75
13.5 Removal of cab 2-75

14. Cold weather operation 2-78
14.1 Precautions for low temperature 2-78
14.2 After completion of work 2-80
14.3 After cold weather 2-80

15. Long-term storage 2-81
15.1 Before storage 2-81
15.2 During storage 2-81
15.3 After storage 2-82

16. Troubleshooting 2-83
16.1 After running out of fuel 2-83
16.2 Method of towing machine 2-83
16.3 If battery is discharged 2-83
16.4 Other trouble 2-86

MidWestTech | Komatsu D475A-2 Bulldozer Operation & Maintenance Manual | Publi... Order the manual at mid-west-tech.com >

MAINTENANCE

17. Guides to maintenance 3- 2

18. Outlines of service 3- 5
18.1 Outline of oil, fuel, coolant 3- 5
18.2 Relating to electric system 3- 7

19. Wear parts list 3- 8

20. Use of fuel, coolant and lubricants according to ambient temperature 3- 9

21. Standard tightening torques for bolts and nuts 3-13
21.1 Introduction of necessary tools 3-13
21.2 Torque list 3-14

22. Periodic replacement of safety critical parts 3-15

23. Maintenance schedule chart 3-19

24. Service Procedure 3-22
24.1 Initial 250 hours service 3-22
24.2 When required 3-23
24.3 Check before starting 3-40
24.4 Every 250 hours service 3-47
24.5 Every 500 hours service 3-55
24.6 Every 1000 hours service 3-57
24.7 Every 2000 hours service 3-61
24.8 Every 4000 hours service 3-65

SPECIFICATIONS

25. Specifications 4- 2

OPTIONS, ATTACHMENTS

26. General precautions 5- 2
26.1 Precautions related to safety 5- 2

27. Using seat belt 5- 3
27.1 Fasten the belt and remove it in the following manner 5- 3

28. Procedure for selecting ripper point 5- 4
28.1 Procedure for selecting ripper point 5- 4

29. Handling cap with lock 5- 5
29.1 Opening and closing lockable cap 5- 5

MidWestTech | Komatsu D475A-2 Bulldozer Operation & Maintenance Manual | Publi... Order the manual at mid-west-tech.com >