MidWestTech | Komatsu D20A-6, D20P-6, D20PL-6, D20PLL-6, D21A-6, D21E-6, D21P-6...

SEAM01010601

Operation & Maintenance Manual

D20A,P,PL,PLL-6
D21A,E,P,PL-6
D20P-6A,D21P-6A,6B

BULLDOZER

SERIAL NUMBERS 60001 and up

KOMATSU®

Order the manual at mid-west-tech.com >

CONTENTS

OPERATION

GENERAL LOCATIONS AND SPECIFICATIONS .. 4
INSTRUMENTS AND CONTROLS 5
CHECK BEFORE STARTING 19
OPERATING YOUR MACHINE 24
COLD WEATHER OPERATION 47
TIPS FOR LONGER UNDERCARRIAGE LIFE 52

MAINTENANCE

PERIODIC MAINTENANCE 53
MAINTENANCE TABLE 54
OIL FILLER AND LEVEL GAUGE POSITIONS ... 57
EVERY 50 HOURS SERVICE 58
INITIAL 250 HOURS SERVICE 59
EVERY 250 HOURS SERVICE 59
EVERY 500 HOURS SERVICE 67
EVERY 1000 HOURS SERVICE 71
EVERY 2000 HOURS SERVICE 76
EVERY 4000 HOURS SERVICE 77
WHEN REQUIRED 78
ADJUSTMENT 84
TROUBLE SHOOTING GUIDE 91
SERVICE METER 94
MACHINE AND ENGINE SERIAL NUMBERS 95
FUEL, COOLANT AND LUBRICANTS 96

MidWestTech | Komatsu D20A-6, D20P-6, D20PL-6, D20PLL-6, D21A-6, D21E-6, D21... Order the manual at mid-west-tech.com >