Operation & Maintenance Manual

SEAM011303T

BR500JG-1

MOBILE CRUSHER

SERIAL NUMBERS BR500JG-1201 and up

WARNING

Unsafe use of this machine may cause serious injury or death. Operators and maintenance personnel must read this manual before operating or maintaining this machine. This manual should be kept near the machine for reference and periodically reviewed by all personnel who will come into contact with it.

NOTICE

Komatsu has Operation & Maintenance Manuals written in some other languages. If a foreign language manual is necessary, contact your local distributor for availability.

KOMATSU®

MidWestTech | Komatsu BR500JG-1 Mobile Crusher Operation & Maintenance Manual | P... Order the manual at mid-west-tech.com >

5. CONTENTS

1. FOREWORD 0- 1

2. SAFETY INFORMATION 0- 4

3. TO THE USER 0- 5

4. LOCATION OF PLATES, TABLE TO ENTER SERIAL NO. AND DISTRIBUTOR 0- 6

SAFETY

1. GENERAL PRECAUTIONS 1- 2

2. PRECAUTIONS DURING OPERATION 1- 8
   - 2.1 Before starting engine 1- 8
   - 2.2 After starting engine 1- 9
   - 2.3 Crusher (crushing) operations 1-16
   - 2.4 Battery 1-19
   - 2.5 Towing 1-21

3. PRECAUTIONS FOR MAINTENANCE 1-22

4. POSITION FOR ATTACHING SAFETY LABELS 1-26

OPERATION

1. GENERAL VIEW 2- 2

2. EXPLANATION OF INSTRUMENTS 2- 3
   - 2.1 Vehicle monitoring system 2- 3
   - 2.2 Switch unit 2- 7
   - 2.3 Control lever, dial, patrol light 2- 9
   - 2.4 Cap and cover with lock 2-10
   - 2.5 Dust indicator 2-11
   - 2.6 Fusible link 2-11
   - 2.7 Fuse 2-12
   - 2.8 Additional lamp connector 2-12
   - 2.9 Radio control 2-13

3. OPERATING PROCEDURE 2-21
   - 3.1 Checks before starting 2-21
   - 3.2 Starting the engine 2-29
   - 3.3 Operations and checks after starting engine 2-32
   - 3.4 Moving machine off 2-33
   - 3.5 Steering (Changing the course) 2-34
   - 3.6 Stopping the vehicle 2-34
   - 3.7 Starting crusher operations 2-35
   - 3.8 Operations starting procedures of (new) crusher 2-36
   - 3.9 Basic handling of grizzly feeder (Effective much removing method) 2-37
   - 3.10 Water sprinkler 2-40
   - 3.11 Finishing operations 2-40

MidWestTech | Komatsu BR500JG-1 Mobile Crusher Operation & Maintenance Manual... Order the manual at mid-west-tech.com >

3.12 After completing operations 2-41
3.13 Stopping the engine 2-41
3.14 Checks after stopping engine 2-42
3.15 Reverse rotation function of crusher 2-42
3.16 Automatic stopping of belt conveyor 2-42
3.17 Prohibited operations 2-43
3.18 Precautions when traveling up or down hills 2-44

4. TRANSPORTATION 2-45
4.1 Packing style for transportation 2-45
4.2 Loading, unloading work 2-51
4.3 Precautions for loading 2-52
4.4 Precautions for transportation 2-53

5. LONG-TERM STORAGE 2-54
5.1 Before storage 2-54
5.2 During storage 2-54
5.3 After storage 2-54

6. TROUBLESHOOTING 2-55
6.1 Phenomena that are not failures 2-55
6.2 Method of towing machine 2-55

7. WHEN THE BATTERY HAS DISCHARGED 2-56
7.1 Battery removal and installation 2-57
7.2 Battery charges 2-57
7.3 Starting engine with booster cable 2-58

MAINTENANCE

1. GENERAL INSTRUCTIONS ON MAINTENANCE OPERATIONS 3- 2

2. AIR BLEEDING FROM CIRCUIT 3-10
2.1 Air bleeding in the main pump 3-11
2.2 Starting the engine 3-11
2.3 Air bleeding in the crusher motor 3-11
2.4 Bleeding air from grizzly feeder motor 3-12
2.5 Air bleeding in the belt conveyor motor 3-12
2.6 Air bleeding in the travel motor
(Perform this only when the oil in the travel motor case is drained.) 3-12
2.7 Air bleeding in the cylinder 3-13
2.8 Starting operations 3-13

3. OIL FILLER AND OIL LEVEL GAUGE 3-14

4. STANDARD TIGHTENING TORQUES FOR BOLTS AND NUTS 3-15
4.1 Introduction of necessary tools 3-15
4.2 Torque list 3-18

5. MAINTENANCE TABLE 3-19

MidWestTech | Komatsu BR500JG-1 Mobile Crusher Operation & Maintenance Manual... Order the manual at mid-west-tech.com >

6. PERIODIC MAINTENANCE 3-21
6.1 Checks before starting 3-21
6.2 Every 100 hours service 3-28
6.3 Every 250 hours service 3-30
6.4 Every 500 hours service 3-33
6.5 Every 1000 hours service 3-38
6.6 Every 2000 hours service 3-41
6.7 Every 4000 hours service 3-44
6.8 Every 5000 hours service 3-45

7. WHEN REQUIRED 3-50
7.1 Check, cleaning and replacement of air cleaner 3-50
7.2 Cleaning of the inside of the cooling system 3-52
7.3 Check and adjustment for looseness of track shoe bolt 3-55
7.4 Tension check and adjustment for the track shoe 3-55
7.5 Check, adjust, replace crusher 3-57
7.6 Check, adjust belt conveyor 3-73

8. WEAR PARTS 3-75
8.1 Wear parts replated to the body 3-75
8.2 Wear parts related to the crusher 3-76
8.3 Wear parts related to the belt conveyor 3-78

9. USAGE OF FUEL, COOLANT AND LUBRICANTS ACCORDING TO AMBIENT TEMPERATURE 3-79

10. PERIODIC REPLACEMENT OF IMPORTANT PARTS 3-82

11. TROUBLESHOOTING 3-84
11.1 Crusher 3-84
11.2 Electrical equipment 3-85
11.3 Body 3-86
11.4 Engine 3-87
11.5 Belt conveyor 3-89

SPECIFICATIONS AND CIRCUIT DIAGRAMS

1. EXTERNAL VIEW 4- 2

2. SPECIFICATIONS 4- 3

MidWestTech | Komatsu BR500JG-1 Mobile Crusher Operation & Maintenance Manual... Order the manual at mid-west-tech.com >