Operation & Maintenance Manual

SEAM015203T

[redacted]

PC20R-8
PC25R-8
PC27R-8

HYDRAULIC EXCAVATOR

SERIAL NUMBERS PC20R-10001
PC25R-10001 and up
PC27R-10001

WARNING

Unsafe use of this machine may cause serious injury or death. Operators and maintenance personnel must read this manual before operating or maintaining this machine. This manual should be kept near the machine for reference and periodically reviewed by all personnel who will come into contact with it.

NOTICE

Komatsu has Operation & Maintenance Manuals written in some other languages. If a foreign language manual is necessary, contact your local distributor for availability.

KOMATSU®

MidWestTech | Komatsu PC20R-8, PC25R-8, PC27R-8 Hydraulic Excavator Operation & Ma... Order the manual at mid-west-tech.com >

5. CONTENTS

1. **Foreword** 0- 1

2. **Safety information** 0- 4

3. **Introduction** 0- 5

4. **Location of plates, table to enter serial No. and distributor** 0- 6

SAFETY

6. **General precautions** 1- 2

7. **Precautions during operation** 1- 7
   - 7.1 Before starting engine 1- 7
   - 7.2 Operating machine 1- 9
   - 7.3 Transportation 1-16
   - 7.4 Battery 1-17
   - 7.5 Towing 1-19
   - 7.6 Lifting operation 1-19
   - 7.7 Window washer fluid 1-19

8. **Precautions for maintenance** 1-20
   - 8.1 Before carrying out maintenance 1-20
   - 8.2 During maintenance 1-24

9. **Position for attaching safety labels** 1-29

OPERATION

10. **General view** 2- 2
    - 10.1 General view of machine 2- 2
    - 10.2 General view of controls and gauges 2- 3

11. **Explanation of components** 2- 4
    - 11.1 Machine monitor 2- 4
    - 11.2 Switches 2- 9
    - 11.3 Control levers and pedals 2-12
    - 11.4 Engine hood 2-16
    - 11.5 Front window (Machine equipped with cab) 2-17
    - 11.6 Sliding door (Machine equipped with cab) 2-19
    - 11.7 Hammer for emergency escape (Machine equipped with cab) 2-20
    - 11.8 Fuses 2-20
    - 11.9 Fusible link 2-21
    - 11.10 Cap, cover with lock 2-21
    - 11.11 Manual storing space 2-22
    - 11.12 Tool box 2-22
    - 11.13 Dust indicator 2-22

MidWestTech | Komatsu PC20R-8, PC25R-8, PC27R-8 Hydraulic Excavator Operation... Order the manual at mid-west-tech.com >

12. Operation 2-23
12.1 Check before starting engine 2-23
12.2 Starting engine 2-31
12.3 Operations and checks after starting engine 2-33
12.4 Moving machine off 2-35
12.5 Steering machine 2-38
12.6 Stopping machine 2-40
12.7 Swinging 2-41
12.8 Operation of work equipment 2-42
12.9 Prohibitions for operation 2-43
12.10 Precautions for operation 2-45
12.11 Precautions when traveling up or down hills 2-46
12.12 How to escape from mud 2-48
12.13 Work possible using hydraulic excavator 2-49
12.14 Replacement of bucket 2-51
12.15 Parking machine 2-52
12.16 Check after finishing work 2-53
12.17 Stopping engine 2-53
12.18 Check after stopping engine 2-54
12.19 Locking 2-54
12.20 Handling rubber shoes (Rubber shoes only) 2-55

13. Transportation 2-60
13.1 Loading, unloading work 2-60
13.2 Method of lifting machine 2-62
13.3 Precautions for loading 2-64
13.4 Precautions for transportation 2-65

14. Cold weather operation 2-66
14.1 Precautions for low temperature 2-66
14.2 Precautions after completion of work 2-68
14.3 Preparing the cab heater (Machine equipped with cab) 2-68
14.4 After cold weather 2-68

15. Long-term storage 2-69
15.1 Before storage 2-69
15.2 During storage 2-70
15.3 After storage 2-70

16. Troubleshooting 2-71
16.1 Phenomena that are not failures 2-71
16.2 Method of towing machine 2-71
16.3 Precautions on particular jobsites 2-71
16.4 If battery is discharged 2-72
16.5 Other trouble 2-77

MidWestTech | Komatsu PC20R-8, PC25R-8, PC27R-8 Hydraulic Excavator Operation... Order the manual at mid-west-tech.com >

MAINTENANCE

17. Guides to maintenance 3- 2

18. Outlines of service 3- 4
18.1 Outline of oil, fuel, coolant 3- 4
18.2 Outline of electric system 3- 7
18.3 Outline of hydraulic system 3- 8

19. Wear parts list 3- 9

20. Use of fuel, coolant and lubricants according to ambient temperature 3-10

21. Standard tightening torques for bolts and nuts 3-14
21.1 Introduction of necessary tools 3-14
21.2 Torque list 3-15

22. Periodic replacement of safety critical parts 3-16

23. Maintenance schedule chart 3-18
23.1 Maintenance schedule chart 3-18
23.2 Maintenance interval when using hydraulic breaker 3-20

24. Service Procedure 3-21
24.1 Initial 250 hours service 3-21
24.2 When required 3-22
24.3 Check before starting 3-41
24.4 Every 100 hours service 3-45
24.5 Every 250 hours service 3-46
24.6 Every 500 hours service 3-51
24.7 Every 1000 hours service 3-57
24.8 Every 2000 hours service 3-58

SPECIFICATIONS

25. Specifications 4- 2

OPTIONS, ATTACHMENTS

26. General precautions 5- 2
26.1 Precautions related to safety 5- 2
26.2 Precautions when installing attachments 5- 3

27. Handling bucket with hook 5- 4
27.1 Checking for damage to bucket with hook 5- 4
27.2 Prohibited operations 5- 4
27.3 Precautions during operations 5- 4

28. Using seat belt 5- 5
28.1 Seat belt 5- 5

MidWestTech | Komatsu PC20R-8, PC25R-8, PC27R-8 Hydraulic Excavator Operation... Order the manual at mid-west-tech.com >