Operation & Maintenance Manual

SEAM018601

avance LOADER

WA800-3

WHEEL LOADER

SERIAL NUMBERS WA800-50001 and up

WARNING

Unsafe use of this machine may cause serious injury or death. Operators and maintenance personnel must read this manual before operating or maintaining this machine. This manual should be kept near the machine for reference and periodically reviewed by all personnel who will come into contact with it.

NOTICE

Komatsu has Operation & Maintenance Manuals written in some other languages. If a foreign language manual is necessary, contact your local distributor for availability.

KOMATSU®

MidWestTech | Komatsu WA800-3 Wheel Loader Operation & Maintenance Manual | Publi... Order the manual at mid-west-tech.com >

5. CONTENTS

1. **Foreword** 0- 1

2. **Safety information** 0- 2

3. **Introduction** 0- 3

4. **Location of plates, table to enter serial No. and distributor** 0- 4

SAFETY

6. **General precautions** 1- 2

7. **Precautions during operation** 1- 7
   - 7.1 Before starting engine 1- 7
   - 7.2 After starting engine 1-10
   - 7.3 Transportation 1-18
   - 7.4 Battery 1-19
   - 7.5 Towing 1-21

8. **Precautions for maintenance** 1-22
   - 8.1 Before carrying out maintenance 1-22
   - 8.2 During maintenance 1-27
   - 8.3 Tires 1-33

9. **Position for attaching safety labels** 1-35

OPERATION

10. **General view** 2- 2
    - 10.1 General view of machine 2- 2
    - 10.2 General view of controls and gauges 2- 3

11. **Explanation of components** 2- 4
    - 11.1 Machine monitor 2- 4
    - 11.2 Switches 2-14
    - 11.3 Control levers, pedals 2-22
    - 11.4 Steering column tilt lever 2-26
    - 11.5 Cap with lock 2-26
    - 11.6 Safety bar 2-27
    - 11.7 Grease pump 2-28
    - 11.8 Backup alarm 2-28
    - 11.9 Door-open lock 2-28
    - 11.10 Tool box 2-28
    - 11.11 Fuel stop lever 2-28
    - 11.12 Fuse 2-29
    - 11.13 Slow-blow fuse 2-30
    - 11.14 Lunch box tray 2-31
    - 11.15 Storaging place of this manual 2-31
    - 11.16 Taking off power 2-31
    - 11.17 Precautions when handling accumulator 2-32

MidWestTech | Komatsu WA800-3 Wheel Loader Operation & Maintenance Manual |... Order the manual at mid-west-tech.com >

12. Operation 2-33
12.1 Check before starting engine 2-33
12.2 Starting engine 2-48
12.3 Operations and checks after starting engine 2-50
12.4 Moving machine off 2-51
12.5 Changing gear speed 2-53
12.6 Changing direction 2-54
12.7 Turning 2-56
12.8 Stopping machine 2-57
12.9 Operation of work equipment 2-58
12.10 Work possible using wheel loader 2-59
12.11 Precautions for operation 2-64
12.12 Adjusting work equipment posture 2-66
12.13 Parking machine 2-68
12.14 Checks after completion of operation 2-69
12.15 Stopping engine 2-69
12.16 Check after stopping engine 2-70
12.17 Locking 2-70
12.18 Handling the tires 2-71
12.19 Removal and installation of the bucket 2-73

13. Transportation 2-77
13.1 Lifting machine 2-77

14. Cold weather operation 2-78
14.1 Precautions for low temperature 2-78
14.2 Precautions after completion of work 2-80
14.3 After cold weather 2-80
14.4 Warming-up operation for steering hydraulic circuit in cold weather 2-81

15. Long-term storage 2-82
15.1 Before storage 2-82
15.2 During storage 2-82
15.3 After storage 2-82

16. Troubleshooting 2-83
16.1 When machine runs out of fuel 2-83
16.2 Towing the machine 2-84
16.3 If battery is discharged 2-87
16.4 Other trouble 2-91

MidWestTech | Komatsu WA800-3 Wheel Loader Operation & Maintenance Manual |... Order the manual at mid-west-tech.com >

MAINTENANCE

17. Guides to maintenance 3- 2

18. Outlines of service 3- 5
18.1 Outline of oil, fuel, coolant 3- 5
18.2 Outline of electric system 3- 8

19. Wear parts list 3- 9

20. Use of fuel, coolant and lubricants according to ambient temperature 3-10

21. Standard tightening torques for bolts and nuts 3-14
21.1 Introduction of necessary tools 3-14
21.2 Torque list 3-15

22. Periodic replacement of safety critical parts 3-16

23. Maintenance schedule chart 3-18
23.1 Maintenance schedule chart 3-18

24. Service Procedure 3-22
24.1 Initial 250 hours service 3-22
24.2 When required 3-23
24.3 Check before starting 3-46
24.4 Every 50 hours service 3-53
24.5 Every 100 hours service 3-54
24.6 Every 250 hours service 3-58
24.7 Every 500 hours service 3-62
24.8 Every 1000 hours service 3-68
24.9 Every 2000 hours service 3-74
24.10 Every 4000 hours service 3-84

SPECIFICATIONS

25. Specifications 4- 2

OPTIONS, ATTACHMENTS

26. Optional part and attachments 5- 2

27. Selecting buckets and tires 5- 3

28. Handling auto shift system 5- 4
28.1 Automatic shift system 5- 4
28.2 Precautions when changing direction 5- 5

29. Handling joystick steering system 5- 8
29.1 Explanation of components 5- 8
29.2 Structure and function of joystick steering 5- 9
29.3 Operation method of joystick steering system 5-12
29.4 Precautions for steering with joystick 5-14
29.5 Adjustment of joystick console 5-15
29.6 Adjustment operator's seat 5-16

MidWestTech | Komatsu WA800-3 Wheel Loader Operation & Maintenance Manual |... Order the manual at mid-west-tech.com >