MidWestTech | Komatsu PC60-5, PC60L-5, PC60U-5 Hydraulic Excavator Operation & Main...

Operation & Maintenance Manual

SEAM02010502

PC60,60L,60U-5

HYDRAULIC EXCAVATOR

SERIAL NUMBERS PC60 -20501
PC60L- 7501 and up
PC60U- 4501

KOMATSU

Order the manual at mid-west-tech.com >

CONTENTS

OPERATION

GENERAL LOCATIONS AND SPECIFICATIONS 4
INSTRUMENTS AND CONTROLS 5
CHECK BEFORE STARTING 26
OPERATING YOUR MACHINE 31
ADJUSTMENT OF THE WORK EQUIPMENT (PC60U) 45
INVERSION AND REPLACEMENT OF BUCKET 47
COLD WEATHER OPERATION 48

MAINTENANCE

PERIODIC MAINTENANCE 53
MAINTENANCE TABLE 54
OIL FILLER AND LEVEL GAUGE POSITIONS 57
EVERY 50 HOURS SERVICE 58
EVERY 100 HOURS SERVICE 59
INITIAL 250 HOURS SERVICE 64
EVERY 250 HOURS SERVICE 64
EVERY 500 HOURS SERVICE 67
EVERY 1000 HOURS SERVICE 71
EVERY 2000 HOURS SERVICE 73
WHEN REQUIRED 77
ADJUSTMENT 89
TROUBLE SHOOTING GUIDE 91
SERVICE METER 94
MACHINE AND ENGINE SERIAL NUMBERS 95
FUEL, COOLANT AND LUBRICANTS 96

MidWestTech | Komatsu PC60-5, PC60L-5, PC60U-5 Hydraulic Excavator Oper... Order the manual at mid-west-tech.com >