MidWestTech | Komatsu PW60-3 Hydraulic Excavator Operation & Maintenance Manual |...

SEAM020B0303

Operation & Maintenance Manual

KOMATSU®

PW60-3

HYDRAULIC EXCAVATOR

SERIAL NUMBERS
PW60 -2001 and up

Order the manual at mid-west-tech.com >

CONTENTS

OPERATION

SAFETY HINTS ⚠ 4
GENERAL LOCATIONS AND SPECIFICATIONS 12
INSTRUMENTS AND CONTROLS 13
CHECK BEFORE STARTING 38
OPERATING YOUR MACHINE 44
EXCAVATOR'S WORK 59
INVERSION AND REPLACEMENT OF BUCKET 60
HANDLING THE TIRES 61
HANDLING OF BATTERY 63
TRANSPORTATION 66
COLD WEATHER OPERATION 68

MAINTENANCE

PERIODIC MAINTENANCE 73
PRECAUTIONS FOR MAINTENANCE 74
PERIODICAL REPLACEMENT OF SAFETY PARTS 79
MAINTENANCE TABLE 80
OIL FILLER AND LEVEL GAUGE POSITIONS 83
EVERY 50 HOURS SERVICE 84
EVERY 100 HOURS SERVICE 84
EVERY 250 HOURS SERVICE 87
EVERY 500 HOURS SERVICE 93
EVERY 1000 HOURS SERVICE 97
EVERY 2000 HOURS SERVICE 99
WHEN REQUIRED 105
ADJUSTMENT 115
HANDLING OUTRIGGER 119
TROUBLE SHOOTING GUIDE 121
STORAGE 125
SERVICE METER 126
MACHINE AND ENGINE SERIAL NUMBERS 127
FUEL, COOLANT AND LUBRICANTS 128

MidWestTech | Komatsu PW60-3 Hydraulic Excavator Operation & Maintenance Ma... Order the manual at mid-west-tech.com >