MidWestTech | Komatsu PC05-6, PC10-6, PC15-2 Hydraulic Excavator Operation & Mainten...

SEAM020MB600

Operation & Maintenance Manual

KOMATSU®

PC05-6, PC10-6
PC15-2

HYDRAULIC EXCAVATOR

SERIAL NUMBERS
PC05- 6006
PC10-21446 and up
PC15- 2809

Order the manual at mid-west-tech.com >

CONTENTS

OPERATION

GENERAL LOCATIONS AND SPECIFICATIONS 4
INSTRUMENTS AND CONTROLS 6
OIL FILLER AND LEVEL GAUGE POSITIONS 22
CHECK BEFORE STARTING 24
OPERATING YOUR MACHINE 28
REPLACEMENT OF BUCKET 50
METHOD OF LIFTING THE MACHINE 52
COLD WEATHER OPERATION 55

MAINTENANCE

PERIODIC MAINTENANCE 59
MAINTENANCE TABLE 60
INITIAL 50 HOURS SERVICE 63
EVERY 50 HOURS SERVICE 63
EVERY 100 HOURS SERVICE 66
INITIAL 250 HOURS SERVICE 68
EVERY 250 HOURS SERVICE 69
EVERY 500 HOURS SERVICE 80
EVERY 2000 HOURS SERVICE 84
WHEN REQUIRED 86
HANDLING RUBBER SHOES 93
SERVICE METER 98
MACHINE AND ENGINE SERIAL NUMBERS 99
FUEL, COOLANT AND LUBRICANTS 100

MidWestTech | Komatsu PC05-6, PC10-6, PC15-2 Hydraulic Excavator Operation & Ma... Order the manual at mid-west-tech.com >