# Operation & Maintenance Manual

SEAM021202T

# D155AX-5

## BULLDOZER

SERIAL NUMBERS D155AX-70001 and up

**WARNING**

Unsafe use of this machine may cause serious injury or death. Operators and maintenance personnel must read this manual before operating or maintaining this machine. This manual should be kept near the machine for reference and periodically reviewed by all personnel who will come into contact with it.

**NOTICE**

Komatsu has Operation & Maintenance Manuals written in some other languages. If a foreign language manual is necessary, contact your local distributor for availability.

KOMATSU®

MidWestTech | Komatsu D155AX-5 Bulldozer Operation & Maintenance Manual | Publicati... Order the manual at mid-west-tech.com >

# 5. CONTENTS


1. **Foreword** ..... 0- 1

2. **Safety information** ..... 0- 4

3. **Introduction** ..... 0- 5

4. **Location of plates, table to enter serial No. and distributor** ..... 0- 6

## SAFETY

6. **General precautions** ..... 1- 2

7. **Precautions during operation** ..... 1- 8
   - 7.1 Before starting engine ..... 1- 8
   - 7.2 After starting engine ..... 1-10
   - 7.3 Transportation ..... 1-16
   - 7.4 Battery ..... 1-17
   - 7.5 Towing ..... 1-19

8. **Precautions for maintenance** ..... 1-20
   - 8.1 Before carrying out maintenance ..... 1-20
   - 8.2 During maintenance ..... 1-24

9. **Position for attaching safety labels** ..... 1-29
   - 9.1 Position for attaching safety labels ..... 1-29
   - 9.2 Content and use of warning plates ..... 1-33

## OPERATION

10. **General view** ..... 2- 2
    - 10.1 General view of machine ..... 2- 2
    - 10.2 General view of controls and gauges ..... 2- 3

11. **Explanation of components** ..... 2- 6
    - 11.1 Front panel (meters, lamps, switches) ..... 2- 7
    - 11.2 Switches ..... 2-19
    - 11.3 Control levers, pedals, dial ..... 2-22
    - 11.4 Dust indicator ..... 2-28
    - 11.5 Power source ..... 2-28
    - 11.6 Fuse box ..... 2-28
    - 11.7 Door-open lock (machines equipped with cab) ..... 2-30
    - 11.8 Sash glass intermediate lock (machines equipped with cab) ..... 2-30
    - 11.9 Hot and cool box (machines equipped with cab) ..... 2-30
    - 11.10 Door pocket (machines equipped with cab) ..... 2-31
    - 11.11 Ashtray (machines equipped with cab) ..... 2-31
    - 11.12 Tool box ..... 2-31
    - 11.13 Using car radio (machines equipped with cab, car radio) ..... 2-32
    - 11.14 Handling air conditioner (machines equipped with cab) ..... 2-36
    - 11.15 Handling heater (machines equipped with cab) ..... 2-40
    - 11.16 Handling accumulator ..... 2-41
    - 11.17 Location of fire extinguisher ..... 2-42




MidWestTech | Komatsu D155AX-5 Bulldozer Operation & Maintenance Manual | Pu... Order the manual at mid-west-tech.com >

**12. Operation** ..... 2-43
12.1 Check before starting engine ..... 2-43
12.2 Starting engine ..... 2-57
12.3 Operations and checks after starting engine ..... 2-60
12.4 Moving machine ..... 2-62
12.5 Shifting gear ..... 2-64
12.6 Shifting between forward and reverse ..... 2-65
12.7 Steering machine ..... 2-66
12.8 Stopping machine ..... 2-68
12.9 Precautions for operation ..... 2-69
12.10 Parking machine ..... 2-71
12.11 Check after finishing work ..... 2-72
12.12 Stopping engine ..... 2-73
12.13 Check after stopping engine ..... 2-74
12.14 Locking ..... 2-74
12.15 Ripper operation ..... 2-75
12.16 Work possible using bulldozer ..... 2-77
12.17 Adjusting posture of work equipment ..... 2-79
12.18 Tips for longer undercarriage life ..... 2-85

**13. Transportation** ..... 2-88
13.1 Loading, unloading work ..... 2-88
13.2 Precautions for loading ..... 2-88
13.3 Method of lifting machine ..... 2-89
13.4 Precautions for transportation ..... 2-90
13.5 Removal of cab (machines equipped with cab) ..... 2-90

**14. Cold weather operation** ..... 2-91
14.1 Precautions for low temperature ..... 2-91
14.2 After completion of work ..... 2-93
14.3 After cold weather ..... 2-93

**15. Long-term storage** ..... 2-94
15.1 Before storage ..... 2-94
15.2 During storage ..... 2-94
15.3 After storage ..... 2-94

**16. Troubleshooting** ..... 2-95
16.1 After running out of fuel ..... 2-95
16.2 Method of towing machine ..... 2-95
16.3 If battery is discharged ..... 2-96
16.4 Other trouble ..... 2-99



MidWestTech | Komatsu D155AX-5 Bulldozer Operation & Maintenance Manual | Pu... Order the manual at mid-west-tech.com >

## MAINTENANCE

**17. Guides to maintenance** ..... 3- 2

**18. Outlines of service** ..... 3- 5
18.1 Outline of oil, fuel, coolant ..... 3- 5
18.2 Relating to electric system ..... 3- 7

**19. Wear parts list** ..... 3- 8

**20. Use of fuel, coolant and lubricants according to ambient temperature** ..... 3-10

**21. Standard tightening torques for bolts and nuts** ..... 3-14
21.1 Introduction of necessary tools ..... 3-14
21.2 Torque list ..... 3-15

**22. Periodic replacement of safety critical parts** ..... 3-16

**23. Maintenance schedule chart** ..... 3-19

**24. Service Procedure** ..... 3-22
24.1 Initial 250 hours service ..... 3-22
24.2 When required ..... 3-23
24.3 Check before starting ..... 3-42
24.4 Every 250 hours service ..... 3-52
24.5 Every 500 hours service ..... 3-61
24.6 Every 1000 hours service ..... 3-63
24.7 Every 2000 hours service ..... 3-69
24.8 Every 4000 hours service ..... 3-73

## SPECIFICATIONS

**25. Specifications** ..... 4- 2



MidWestTech | Komatsu D155AX-5 Bulldozer Operation & Maintenance Manual | Pu... Order the manual at mid-west-tech.com >