MidWestTech | Komatsu WA20-1 Wheel Loader Operation & Maintenance Manual | Public...

SEAM036101O2

# Operation & Maintenance Manual

KOMATSU®

# WA20-1

## WHEEL LOADER

SERIAL NUMBERS

**WA20-1773** and up

Order the manual at mid-west-tech.com >

# CONTENTS

## OPERATION


SAFETY HINTS ⚠ ..... 4
GENERAL LOCATIONS AND SPECIFICATIONS ..... 9
INSTRUMENTS AND CONTROLS ..... 10
CHECK BEFORE STARTING ..... 20
OPERATING YOUR MACHINE ..... 24
BUCKET OPERATION ..... 31
HOW TO USE INCHING PEDAL ..... 35
TIRE REPLACEMENT ..... 37
HANDLING THE TIRES ..... 38
HANDLING OF BATTERY ..... 39
MACHINE MOVEMENT ..... 41
COLD WEATHER OPERATION ..... 42
TRANSPORTATION ..... 45


## MAINTENANCE


PERIODIC MAINTENANCE ..... 47
PRECAUTIONS FOR MAINTENANCE ..... 48
PERIODIC REPLACEMENT OF PARTS FOR SAFETY ..... 52
MAINTENANCE TABLE ..... 53
OIL FILLER AND LEVEL GAUGE POSITIONS ..... 56
EVERY 50 HOURS SERVICE ..... 57
EVERY 250 HOURS SERVICE ..... 57
EVERY 500 HOURS SERVICE ..... 64
EVERY 1000 HOURS SERVICE ..... 68
EVERY 2000 HOURS SERVICE ..... 71
WHEN REQUIRED ..... 72
ADJUSTMENT ..... 77
STORAGE ..... 80
SERVICE METER ..... 82
MACHINE AND ENGINE SERIAL NUMBERS ..... 83
FUEL, COOLANT AND LUBRICANTS ..... 84




MidWestTech | Komatsu WA20-1 Wheel Loader Operation & Maintenance Manual | P... Order the manual at mid-west-tech.com >