MidWestTech | Komatsu WA40-1 Wheel Loader Operation & Maintenance Manual | Public...

SEAM03630102

Operation & Maintenance Manual

KOMATSU®

WA40-1

WHEEL LOADER

SERIAL NUMBERS

WA40-1001 and up

Order the manual at mid-west-tech.com >

CONTENTS

OPERATION

SAFETY HINTS ⚠ 4
GENERAL LOCATIONS AND SPECIFICATIONS . . 17
OPERATOR'S COMPARTMENT 18
INSTRUMENTS AND CONTROLS 20
OIL FILLER AND GAUGE POSITIONS 33
CHECK BEFORE STARTING 34
OPERATING YOUR MACHINE 39
COLD WEATHER OPERATION 48
BUCKET OPERATION 51
HOW TO USE INCHING PEDAL 55
TIRE REPLACEMENT 58
HANDLING OF BATTERY 59
TRAVELING WITH NO LOAD
FOR LONG DISTANCE 62
TRANSPORTATION 63

MAINTENANCE

PERIODIC MAINTENANCE 65
PRECAUTIONS FOR MAINTENANCE 66
PERIODIC REPLACEMENT OF
PARTS FOR SAFETY 74
MAINTENANCE TABLE 75
EVERY 50 HOURS SERVICE 77
EVERY 250 HOURS SERVICE 78
EVERY 500 HOURS SERVICE 84
EVERY 1000 HOURS SERVICE 88
EVERY 2000 HOURS SERVICE 92
WHEN REQUIRED 93
ADJUSTMENT 98
STORAGE 100
SERVICE METER 102
MACHINE AND ENGINE SERIAL NUMBERS . . . 103
FUEL, COOLANT AND LUBRICANTS 104

OPTION 109

MidWestTech | Komatsu WA40-1 Wheel Loader Operation & Maintenance Manual | P... Order the manual at mid-west-tech.com >