SEAM045200ATH

Operation & Maintenance Manual

GALEO

PC200-7
PC200LC-7

HYDRAULIC EXCAVATOR

SERIAL NUMBERS PC200-7 C70001 and up
PC200LC-7 C70001 and up

December 2004

KOMATSU

MidWestTech | Komatsu Galeo PC200-7 Hydraulic Excavator Operation & Maintenance Man... Order the manual at mid-west-tech.com >

BASIC CHECK ITEMS ... 3-5
SWITCHES ... 3-17
CONTROL LEVERS, PEDALS ... 3-22
CEILING WINDOW ... 3-25
FRONT WINDOW ... 3-26
EMERGENCY EXIT FROM OPERATOR'S CAB ... 3-31
DOOR LOCK ... 3-31
CAP, COVER WITH LOCK ... 3-32

MAGAZINE BOX ... 3-33
ASHTRAY ... 3-33
HANDLING COOLER ... 3-34
CAR RADIO ... 3-48
FUSE ... 3-53
FUSIBLELINK ... 3-54
CONTROLLER (COMPUTER) ... 3-55
TOOLBOX ... 3-55
GREASE GUN HOLDER ... 3-55
HANDLING ACCUMULATOR ... 3-56

MACHINE OPERATIONS AND CONTROLS ... 3-57
BEFORE STARTING ENGINE ... 3-57
STARTING ENGINE ... 3-70
AFTER STARTING ENGINE ... 3-74
IN COLD AREAS (AUTOMATIC WARMING-UP OPERATION) ... 3-77
STOPPING THE ENGINE ... 3-80
CHECK AFTER SHUT OFF ENGINE ... 3-80
MACHINE OPERATION ... 3-81
STEERING THE MACHINE ... 3-85
SWINGING ... 3-87
WORK EQUIPMENT CONTROLS AND OPERATIONS ... 3-88
OPERATING WORKING MODE ... 3-90
PROHIBITED OPERATIONS ... 3-91
GENERAL OPERATION INFORMATION ... 3-93
TRAVELING ON SLOPES ... 3-94
ESCAPE FROM MUD ... 3-96
RECOMMENDED APPLICATIONS ... 3-97
REPLACEMENT AND INVERSION OF BUCKET ... 3-99
PARKING MACHINE ... 3-102
CHECK AFTER FINISHING WORK ... 3-103
LOCKING ... 3-104

RANSPORTATION ... 3-105
TRANSPORTATION PROCEDURE ... 3-105
LOADING AND UNLOADING WITH TRAILER ... 3-106
LIFTING MACHINE ... 3-113

OLD WEATHER OPERATION ... 3-115

MidWestTech | Komatsu Galeo PC200-7 Hydraulic Excavator Operation & Maintenance Man... Order the manual at mid-west-tech.com >

COLD WEATHER OPERATION INFORMATION 3-115
AFTER DAILY WORK COMPLETION 3-117
AFTER COLD WEATHER SEASON 3-118

LONG TERM STORAGE 3-119
BEFORE STORAGE 3-119
DURING STORAGE 3-119
AFTER STORAGE 3-120

TROUBLESHOOTING 3-121
AFTER RUNNING OUT OF FUEL 3-121
PHENOMENA THAT ARE NOT FAILURES 3-121
TOWING THE MACHINE 3-122
LIGHTWEIGHT TOWING HOOK 3-122
PRECAUTIONS ON PARTICULAR JOBSITES 3-123
DISCHARGED BATTERY 3-124
OTHER TROUBLE 3-128

MAINTENANCE

MAINTENANCE INFORMATION 4-2

LUBRICANTS, COOLANT AND FILTERS 4-5
HANDLING OIL, FUEL, COOLANT, AND PERFORMING OIL CLINIC 4-5
ELECTRIC SYSTEM MAINTENANCE 4-8
HANDLING HYDRAULIC SYSTEM 4-8

WEAR PARTS LIST 4-10

USE OF FUEL, COOLANT AND LUBRICANTS ACCORDING TO AMBIENT TEMPERATURE 4-11
PROPER SELECTION OF FUEL, COOLANT AND LUBRICANTS 4-11

TIGHTENING TORQUE SPECIFICATIONS 4-15
TIGHTENING TORQUE LIST 4-15

PERIODIC REPLACEMENT OF SAFETY CRITICAL PARTS 4-16
SAFETY CRITICAL PARTS 4-16

MAINTENANCE SCHEDULE 4-17
MAINTENANCE SCHEDULE CHART 4-17
MAINTENANCE INTERVAL FOR HYDRAULIC BREAKER 4-19

MAINTENANCE PROCEDURE 4-20
INITIAL 250 HOURS MAINTENANCE (ONLY AFTER THE FIRST 250 HOURS) 4-20
WHEN REQUIRED 4-21
CHECK BEFORE STARTING 4-46
EVERY 100 HOURS MAINTENANCE 4-47
EVERY 250 HOURS MAINTENANCE 4-49
EVERY 500 HOURS MAINTENANCE 4-54

MidWestTech | Komatsu Galeo PC200-7 Hydraulic Excavator Operation & Maintenance Man... Order the manual at mid-west-tech.com >

EVERY 1000 HOURS MAINTENANCE 4-62
EVERY 2000 HOURS MAINTENANCE 4-66
EVERY 4000 HOURS MAINTENANCE 4-68
EVERY 5000 HOURS MAINTENANCE 4-69

SPECIFICATIONS

SPECIFICATIONS 5-2

ATTACHMENTS AND OPTIONS

GENERAL PRECAUTIONS 6-2
PRECAUTION RELATED TO SAFETY 6-2
PRECAUTION WHEN INSTALLING ATTACHMENTS 6-4

HANDLING BUCKET WITH HOOK 6-5
CHECKING FOR DAMAGE TO BUCKET WITH HOOK 6-5
PROHIBITED OPERATIONS 6-5

MACHINES READY FOR ATTACHMENTS 6-6
EXPLANATION OF COMPONENTS 6-6
HYDRAULIC CIRCUIT 6-9
ATTACHMENT MOUNTING/DISMOUNTING PROCEDURE 6-13
OPERATION 6-15
LONG-TERM STORAGE 6-17
SPECIFICATIONS 6-17

HANDLING SCS-I BUSHING 6-18
EVERY 500 HOURS MAINTENANCE 6-18

ATTACHMENT GUIDE 6-20
COMBINATIONS OF WORK EQUIPMENT 6-20
SELECTION OF TRACK SHOES 6-23
SELECTION OF BUCKET TEETH 6-24
STANDARDS FOR SELECTING VERTICAL PIN TYPE AND HORIZONTAL PIN TYPE TEETH 6-24
HANDLING OF RUBBER PAD SHOE AND ROAD LINER 6-25
HANDLING TRAPEZOIDAL BUCKET 6-27
HANDLING EXTENSION ARM 6-28
HANDLING CLAMSHELL BUCKET 6-29

RECOMMENDED ATTACHMENT OPERATIONS 6-30
HYDRAULIC BREAKER 6-30

AIR CONDITIONER 6-35

SUSPENSION SEAT 6-54

MidWestTech | Komatsu Galeo PC200-7 Hydraulic Excavator Operation & Maintenance Man... Order the manual at mid-west-tech.com >