MidWestTech | Komatsu HD325-5 Dump Truck Operation & Maintenance Manual | Publicat...

SEAM05660501

Operation & Maintenance Manual

KOMATSU®

HD325-5

DUMP TRUCK

SERIAL NUMBER
HD325-2001 and up

Order the manual at mid-west-tech.com >

CONTENTS

OPERATION

SAFETY HINTS ⚠ 4
GENERAL LOCATIONS AND SPECIFICATIONS .. 11
INSTRUMENTS AND CONTROLS 12
AIR CONDITIONER 36
CHECK BEFORE STARTING 40
OPERATING YOUR MACHINE 48
RELEASE OF PARKING BRAKE 67
EMERGENCY BRAKE 68
RELEASE OF EMERGENCY BRAKE 70
INSTRUCTIONS FOR TOWING THE MACHINE 71
DUMP BODY OPERATION 72
HANDLING THE TIRES 74
HANDLING OF BATTERY 77
COLD WEATHER OPERATION 80

MAINTENANCE

PERIODIC MAINTENANCE 85
PRECAUTIONS FOR MAINTENANCE 86
PERIODIC REPLACEMENT OF COMPONENT PARTS FOR SAFETY 89
MAINTENANCE TABLE 90
EVERY 50 HOURS SERVICE 94
INITIAL 250 HOURS SERVICE 97
EVERY 250 HOURS SERVICE 97
EVERY 500 HOURS SERVICE 104
EVERY 1000 HOURS SERVICE 107
EVERY 2000 HOURS SERVICE 113
EVERY 4000 HOURS SERVICE 115
WHEN REQUIRED 116
ADJUSTMENT 122
TROUBLE SHOOTING GUIDE 129
STORAGE 134
SERVICE METER 136
MACHINE AND ENGINE SERIAL NUMBERS ... 137
FUEL, COOLANT AND LUBRICANTS 138

MidWestTech | Komatsu HD325-5 Dump Truck Operation & Maintenance Manual | Pu... Order the manual at mid-west-tech.com >