MidWestTech | Komatsu HD352-5 Wheel Loader Operation & Maintenance Manual | Public...

SEAM05660503

Operation & Maintenance Manual

KOMATSU®

HD352-5

WHEEL LOADER

SERIAL NUMBER
HD325-12264 and up

Order the manual at mid-west-tech.com >

CONTENTS

OPERATION

GENERAL LOCATIONS AND SPECIFICATIONS . . 5
INSTRUMENTS AND CONTROLS 6
CHECK BEFORE STARTING 30
OPERATING YOUR MACHINE 40
METHOD OF RELEASING PARKING BRAKE AND EMERGENCY BRAKE WHEN ACTUATED IN A EMERGENCY 59
INSTRUCTIONS FOR TOWING THE MACHINE 61
DUMP BODY OPERATION 62
HANDLING THE TIRES 64
COLD WEATHER OPERATION 67

MAINTENANCE

PERIODIC MAINTENANCE 71
PERIODICAL REPLACEMENT OF SAFETY PARTS 72
MAINTENANCE TABLE 73
OIL FILLER AND LEVEL GAUGE POSITIONS 77
EVERY 50 HOURS SERVICE 78
INITIAL 250 HOURS SERVICE 81
EVERY 250 HOURS SERVICE 81
EVERY 500 HOURS SERVICE 87
EVERY 1000 HOURS SERVICE 91
EVERY 2000 HOURS SERVICE 97
EVERY 4000 HOURS SERVICE 99
WHEN REQUIRED 100
ADJUSTMENT 107
TROUBLE SHOOTING GUIDE 113
SERVICE METER 118
MACHINE AND ENGINE SERIAL NUMBERS . . . 119
FUEL, COOLANT AND LUBRICANTS 120
OPERATION AND MAINTENANCE (EQUIPPED WITH A ELECTRONIC INSTRUMENT PANEL) 123

MidWestTech | Komatsu HD352-5 Wheel Loader Operation & Maintenance Manual |... Order the manual at mid-west-tech.com >