MidWestTech | Komatsu HD325-5 Dump Truck Operation & Maintenance Manual | Publicat...

SEAM05660505

Operation & Maintenance Manual

KOMATSU®

HD325-5

DUMP TRUCK

SERIAL NUMBER
HD325-2441 and up

Order the manual at mid-west-tech.com >

CONTENTS

OPERATION

GENERAL LOCATIONS AND SPECIFICATIONS .. 5
INSTRUMENTS AND CONTROLS 6
CHECK BEFORE STARTING 30
OPERATING YOUR MACHINE 41
METHOD OF RELEASING PARKING BRAKE AND EMERGENCY BRAKE WHEN ACTUATED IN A EMERGENCY 60
INSTRUCTIONS FOR TOWING THE MACHINE 62
DUMP BODY OPERATION 63
HANDLING THE TIRES 65
COLD WEATHER OPERATION 68

MAINTENANCE

PERIODIC MAINTENANCE 73
PERIODICAL REPLACEMENT OF SAFETY PARTS 74
MAINTENANCE TABLE 75
OIL FILLER AND LEVEL GAUGE POSITIONS 79
EVERY 50 HOURS SERVICE 80
EVERY 250 HOURS SERVICE 83
EVERY 500 HOURS SERVICE 89
EVERY 1000 HOURS SERVICE 94
EVERY 2000 HOURS SERVICE 100
EVERY 4000 HOURS SERVICE 102
WHEN REQUIRED 103
ADJUSTMENT 110
TROUBLE SHOOTING GUIDE 115
SERVICE METER 120
MACHINE AND ENGINE SERIAL NUMBERS ... 121
FUEL, COOLANT AND LUBRICANTS 122
OPERATION AND MAINTENANCE (EQUIPPED WITH A ELECTRONIC INSTRUMENT PANEL) 125

MidWestTech | Komatsu HD325-5 Dump Truck Operation & Maintenance Manual | Pu... Order the manual at mid-west-tech.com >