MidWestTech | Komatsu HD465-3 Dump Truck Operation & Maintenance Manual | Publicat...

SEAM0569S300

Operation & Maintenance Manual

HD465-3

DUMP TRUCK

SERIAL NUMBERS HD465-2001 and up

KOMATSU®

Order the manual at mid-west-tech.com >

CONTENTS

OPERATION

SAFETY HINTS ... 4
GENERAL LOCATIONS AND SPECIFICATIONS ... 11
OPERATOR'S COMPARTMENT ... 12
INSTRUMENTS AND CONTROLS ... 14
AIR CONDITIONER ... 37
CHECK BEFORE STARTING ... 41
OPERATING YOUR MACHINE ... 49
HANDLING THE TIRES ... 67
RELEASE OF PARKING BRAKE ... 70
EMERGENCY BRAKE ... 71
RELEASE OF EMERGENCY BRAKE ... 73
HANDLING OF BATTERY ... 74
DUMP BODY OPERATION ... 77
INSTRUCTIONS FOR TOWING THE MACHINE ... 79
COLD WEATHER OPERATION ... 80

MAINTENANCE

PERIODIC MAINTENANCE ... 85
PRECAUTIONS FOR MAINTENANCE ... 86
PERIODIC REPLACEMENT OF COMPONENT PARTS FOR SAFETY DEVICES ... 89
MAINTENANCE TABLE ... 90
EVERY 50 HOURS SERVICE ... 94
INITIAL 250 HOURS SERVICE ... 97
EVERY 250 HOURS SERVICE ... 97
EVERY 500 HOURS SERVICE ... 103
EVERY 1000 HOURS SERVICE ... 107
EVERY 2000 HOURS SERVICE ... 114
EVERY 4000 HOURS SERVICE ... 115
WHEN REQUIRED ... 116
ADJUSTMENT ... 120
TROUBLE SHOOTING GUIDE ... 128
STORAGE ... 134
SERVICE METER ... 136
MACHINE AND ENGINE SERIAL NUMBERS ... 137
OPTIONAL PARTS ... 138
FUEL, COOLANT AND LUBRICANTS ... 140
OPERATION AND MAINTENANCE (EQUIPPED WITH A ELECTRONIC INSTRUMENT PANEL) ... 143

MidWestTech | Komatsu HD465-3 Dump Truck Operation & Maintenance Manual | Pu... Order the manual at mid-west-tech.com >