MidWestTech | Komatsu HD465-3 Dump Truck Operation & Maintenance Manual | Publicat...

SEAM0569S303

Operation & Maintenance Manual

KOMATSU®

HD465-3
DUMP TRUCK

SERIAL NUMBERS
HD465-2190 and up

Order the manual at mid-west-tech.com >

CONTENTS

OPERATION

SAFETY HINTS - - - ⚠ 4
GENERAL LOCATIONS AND SPECIFICATIONS . 11
OPERATOR'S COMPARTMENT 12
INSTRUMENTS AND CONTROLS 14
AIR CONDITIONER 37
CHECK BEFORE STARTING 41
OPERATING YOUR MACHINE 52
METHOD OF RELEASING PARKING BRAKE AND EMERGENCY BRAKE WHEN ACTUATED IN A EMERGENCY 70
INSTRUCTIONS FOR TOWING THE MACHINE 72
DUMP BODY OPERATION 73
HANDLING THE TIRES 75
HANDLING OF BATTERY 78
COLD WEATHER OPERATION 81

MAINTENANCE

PERIODIC MAINTENANCE 85
PRECAUTIONS FOR MAINTENANCE 86
PERIODIC REPLACEMENT OF SAFETY PARTS 90
MAINTENANCE TABLE 91
OIL FILLER AND LEVEL GAUGE POSITIONS 95
EVERY 50 HOURS SERVICE 96
INITIAL 250 HOURS SERVICE 99
EVERY 250 HOURS SERVICE 99
EVERY 500 HOURS SERVICE 105
EVERY 1000 HOURS SERVICE 109
EVERY 2000 HOURS SERVICE 117
EVERY 4000 HOURS SERVICE 119
WHEN REQUIRED 120
ADJUSTMENT 125
TROUBLE SHOOTING GUIDE 132
STORAGE 138
SERVICE METER 140
MACHINE AND ENGINE SERIAL NUMBERS ... 141
OPTIONAL PARTS 142
FUEL, COOLANT AND LUBRICANTS 144
OPERATION AND MAINTENANCE (EQUIPPED WITH A ELECTRONIC INSTRUMENT PANEL) 149

MidWestTech | Komatsu HD465-3 Dump Truck Operation & Maintenance Manual |... Order the manual at mid-west-tech.com >