MidWestTech | Komatsu D20A-5, D20P-5, D20PL-5, D20PLL-5, D20P-5A Bulldozer Operati...

SEAM101D01

Operation & Maintenance Manual

D20A,P,PL,PLL-5
D20P-5A

BULLDOZER

SERIAL NUMBERS D20A,20PL-50001
D20P-50004
D20PLL-50003
D20P-5A-50003
and up

KOMATSU®

Order the manual at mid-west-tech.com >

CONTENTS

OPERATION

SAFETY HINTS ••• ⚠ 4
GENERAL LOCATIONS 18
OPERATOR'S COMPARTMENT 20
INSTRUMENTS AND CONTROLS 22
CHECK BEFORE STARTING 31
OPERATING YOUR MACHINE 36
COLD WEATHER OPERATION 44
BULLDOZER'S WORK 48
TIPS FOR LONGER
UNDERCARRIAGE LIFE 50
REVERSING AND REPLACEMENT OF
CUTTING EDGE AND END BIT 51
HANDLING OF BATTERY 52
TRANSPORTATION 55

MAINTENANCE

PERIODIC MAINTENANCE 57
PRECAUTIONS FOR MAINTENANCE 58
MAINTENANCE TABLE 64
EVERY 50 HOURS SERVICE 68
EVERY 250 HOURS SERVICE 69
EVERY 500 HOURS SERVICE 77
EVERY 1000 HOURS SERVICE 80
EVERY 2000 HOURS SERVICE 84
WHEN REQUIRED 85
ADJUSTMENT 88
TROUBLE SHOOTING GUIDE 97
STORAGE 100
SERVICE METER 102
MACHINE AND ENGINE SERIAL NUMBERS ... 103
WEAR PARTS 104
SPECIFICATIONS 106
FUEL AND LUBRICANTS 110

MidWestTech | Komatsu D20A-5, D20P-5, D20PL-5, D20PLL-5, D20P-5A Bulldozer Op... Order the manual at mid-west-tech.com >