MidWestTech | Komatsu HD320-3, HD325-3 Dump Truck Operation & Maintenance Manual...

SEAM566D01

Operation & Maintenance Manual

KOMATSU®

HD320,325-3

DUMP TRUCK

SERIAL NUMBERS
HD320 -2501 and up
HD325 -1501

Order the manual at mid-west-tech.com >

CONTENTS

OPERATION

SAFETY HINTS 4
GENERAL LOCATIONS 16
OPERATOR'S COMPARTMENT 18
INSTRUMENTS AND CONTROLS 21
CHECK BEFORE STARTING 42
OPERATING YOUR MACHINE 50
INSTRUCTIONS FOR TOWING THE TRUCK 71
HANDLING THE TIRES 72
RELEASING PROCEDURE OF PARKING BRAKE 75
EMERGENCY BRAKE (OPTION) 76
DUMP BODY OPERATION 78
INSTRUCTIONS FOR LOADED MATERIALS 79

MAINTENANCE

PERIODIC MAINTENANCE 81
PRECAUTIONS FOR MAINTENANCE 82
MAINTENANCE TABLE 88
EVERY 50 HOURS SERVICE 98
EVERY 250 HOURS SERVICE 101
EVERY 500 HOURS SERVICE 113
EVERY 1000 HOURS SERVICE 115
EVERY 2000 HOURS SERVICE 120
EVERY 4000 HOURS SERVICE 121
WHEN REQUIRED 125
ADJUSTMENT 132
WEAR PARTS 140
TROUBLE SHOOTING GUIDE 141
COLD WEATHER OPERATION 144
STORAGE 150
SERVICE METER 152
MACHINE AND ENGINE SERIAL NUMBERS 153
SPECIFICATIONS 154
OPTIONAL PARTS 158
FUEL AND LUBRICANTS 160

MidWestTech | Komatsu HD320-3, HD325-3 Dump Truck Operation & Maintenance Ma... Order the manual at mid-west-tech.com >