MidWestTech | Komatsu WA320-1 Wheel Loader Operation & Maintenance Manual | Publi...

Operation & Maintenance Manual

SEAMU4190106



WA320-1

WHEEL LOADER

SERIAL NUMBERS **WA320-20001** and up

KOMATSU®

Order the manual at mid-west-tech.com >

CONTENTS

OPERATION

GENERAL LOCATIONS AND SPECIFICATIONS .. 4
INSTRUMENTS AND CONTROLS 5
CHECK BEFORE STARTING 31
OPERATING YOUR MACHINE 36
ADJUSTMENT OF WORK EQUIPMENT 45
USING ACCUMULATORS 47
HANDLING THE TIRES 48
TOWING 51
COLD WEATHER OPERATION 52

MAINTENANCE

PERIODIC MAINTENANCE 57
BLEEDING AIR FROM CIRCUIT 58
PERIODICAL REPLACEMENT OF SAFETY PARTS 59
MAINTENANCE TABLE 60
OIL FILLER AND LEVEL GAUGE POSITIONS .. 63
EVERY 50 HOURS SERVICE 64
EVERY 100 HOURS SERVICE 65
EVERY 250 HOURS SERVICE 68
EVERY 500 HOURS SERVICE 74
EVERY 1000 HOURS SERVICE 76
EVERY 2000 HOURS SERVICE 80
EVERY 4000 HOURS SERVICE 86
WHEN REQUIRED 87
ADJUSTMENT 101
TROUBLE SHOOTING GUIDE 104
SERVICE METER 108
MACHINE AND ENGINE SERIAL NUMBERS 109
FUEL, COOLANT AND LUBRICANTS 110

MidWestTech | Komatsu WA320-1 Wheel Loader Operation & Maintenance Manual |... Order the manual at mid-west-tech.com >