MidWestTech | Komatsu WA380-1 Wheel Loader Operation & Maintenance Manual | Publi...

SEAMU4230101

# Operation & Maintenance Manual

KOMATSU®

# WA380-1

## WHEEL LOADER

SERIAL NUMBER
**WA380-10001** and up

Order the manual at mid-west-tech.com >

# CONTENTS

## OPERATION


GENERAL LOCATIONS AND SPECIFICATIONS .. 4
INSTRUMENTS AND CONTROLS ..... 5
CHECK BEFORE STARTING ..... 29
OPERATING YOUR MACHINE ..... 34
ADJUSTMENT OF WORK EQUIPMENT ..... 43
HANDLING THE TIRES ..... 45
TOWING ..... 48
COLD WEATHER OPERATION ..... 50


## MAINTENANCE


PERIODIC MAINTENANCE ..... 55
BLEEDING AIR FROM CIRCUIT ..... 56
PERIODICAL REPLACEMENT OF SAFETY PARTS ..... 57
MAINTENANCE TABLE ..... 58
OIL FILLER AND LEVEL GAUGE POSITIONS .. 61
EVERY 50 HOURS SERVICE ..... 62
EVERY 100 HOURS SERVICE ..... 63
INITIAL 250 HOURS SERVICE ..... 65
EVERY 250 HOURS SERVICE ..... 65
EVERY 500 HOURS SERVICE ..... 71
EVERY 1000 HOURS SERVICE ..... 74
EVERY 2000 HOURS SERVICE ..... 80
EVERY 4000 HOURS SERVICE ..... 89
WHEN REQUIRED ..... 90
ADJUSTMENT ..... 104
TROUBLE SHOOTING GUIDE ..... 106
SERVICE METER ..... 110
MACHINE AND ENGINE SERIAL NUMBERS ..... 111
FUEL, COOLANT AND LUBRICANTS ..... 112





MidWestTech | Komatsu WA380-1 Wheel Loader Operation & Maintenance Manual |... Order the manual at mid-west-tech.com >