MidWestTech | Komatsu WA380-1, WA420-1 Wheel Loader Operation & Maintenance Manu...

SEAMU4230104

Operation & Maintenance Manual

KOMATSU®

WA380-1
WA420-1

WHEEL LOADER

SERIAL NUMBERS
WA380 -20001 and up
WA420 -20001

Order the manual at mid-west-tech.com >

CONTENTS

OPERATION

GENERAL LOCATIONS AND SPECIFICATIONS .. 4
INSTRUMENTS AND CONTROLS 5
CHECK BEFORE STARTING 33
OPERATING YOUR MACHINE 39
ADJUSTMENT OF WORK EQUIPMENT 49
HANDLING THE TIRES 51
TOWING 54
COLD WEATHER OPERATION 56

MAINTENANCE

PERIODIC MAINTENANCE 61
BLEEDING AIR FROM CIRCUIT 62
PERIODICAL REPLACEMENT OF SAFETY PARTS 63
MAINTENANCE TABLE 64
OIL FILLER AND LEVEL GAUGE POSITIONS .. 67
EVERY 50 HOURS SERVICE 68
EVERY 100 HOURS SERVICE 69
INITIAL 250 HOURS SERVICE 71
EVERY 250 HOURS SERVICE 71
EVERY 500 HOURS SERVICE 77
EVERY 1000 HOURS SERVICE 80
EVERY 2000 HOURS SERVICE 85
EVERY 4000 HOURS SERVICE 91
WHEN REQUIRED 92
ADJUSTMENT 106
TROUBLE SHOOTING GUIDE 110
SERVICE METER 114
MACHINE AND ENGINE SERIAL NUMBERS 115
FUEL, COOLANT AND LUBRICANTS 116

MidWestTech | Komatsu WA380-1, WA420-1 Wheel Loader Operation & Maintenanc... Order the manual at mid-west-tech.com >