SEAMU423KD10

Operation & Maintenance Manual

WA380-1LC

WHEEL LOADER

SERIAL NUMBERS **WA380-1 : A45001** and up

WARNING

Unsafe use of this machine may cause serious injury or death. Operators and maintenance personnel must read this manual before operating or maintaining this machine. This manual should be kept near the machine for reference and periodically reviewed by all personnel who will come into contact with it.

NOTICE

Komatsu has Operation & Maintenance Manuals written in some other languages. If a foreign language manual is necessary, contact your local distributor for availability.

KOMATSU®

MidWestTech | Komatsu WA380-1LC Wheel Loader Operation & Maintenance Manual | Pu... Order the manual at mid-west-tech.com >

CONTENTS

DESCRIPTION PAGE

OPERATION

GENERAL LOCATIONS AND SPECIFICATIONS 2
PERFORMANCE 2
OPERATING WEIGHT 2
ENGINE 2

INSTRUMENTS AND CONTROLS 3
MONITOR PANEL 3
CHECK MONITOR GROUP 5
Engine Oil Level Monitor 5
Coolant Level Monitor 6
CAUTION MONITOR GROUP 6
Charge Monitor 6
Fuel Level Monitor 6
CAUTION MONITOR GROUP 7
Brake Line Failure Monitor 7
Engine Oil Pressure Monitor 7
Coolant Level Monitor 7
Air Pressure Monitor 8
Coolant Temperature Monitor 8
Torque Converter Oil Temperature Monitor 8
METER GROUP PILOT DISPLAY 9
Parking Brake Pilot Lamp 9
Pilot Lamp for Working Lamp 10
Transmission Cut-Off Selector Pilot Lamp 10
Air Pressure Gauge 10
Engine Cooling Water Temperature Gauge 11
Torque Converter Oil Temperature Gauge 11
Fuel Gauge 11
Turn Signal Pilot Lamp 11
High Beam Pilot Lamp 12
Speedometer 12
Service Meter 12
SWITCHES 13
TRANSMISSION CUT-OFF SELECTOR SWITCH 13
ETHER START SWITCH 14
HORN BUTTON 14
HAZARD LAMP SWITCH 14
PARKING BRAKE SWITCH 15
WORKING LAMP SWITCH 16
STARTING SWITCH 16
LAMP SWITCHES 16
ROOM LAMP SWITCH 17
CIGARETTE LIGHTER 18
KICKDOWN SWITCH 18
FRONT WIPER SWITCH 19
REAR WIPER SWITCH 19

MidWestTech | Komatsu WA380-1LC... Order the manual at mid-west-tech.com >

CONTENTS - Continued

DESCRIPTION	PAGE
LEVERS AND PEDALS	20
DIRECTIONAL LEVER	20
SPEED CONTROL LEVER	21
SPEED CONTROL LEVER STOPPER	21
STEERING COLUMN TILT LEVER	21
ACCELERATOR PEDAL	21
BRAKE PEDALS	22
Right brake pedal	22
Left brake pedal	22
LIFT ARM CONTROL LEVER	23
BUCKET CONTROL LEVER	24
SAFETY LOCK	24
AIR CLEANER SERVICE INDICATOR	24
SAFETY BAR	25
WORK EQUIPMENT CONTROL LEVER	25
CIRCUIT BREAKER (MAIN)	26
DOOR-OPEN LOCK	26
HOOD TILT LOCK	27
FUSE BOX	27
OPERATOR'S SEAT	29
Forward-backward adjustment	29
Seat angle adjustment	29
Seat cushion adjustment	29
Backrest adjustment	29
Seat height adjustment	29
RIGHT SIDE ARMREST	29
Forward-backward adjustment	29
Angle adjustment	29
SEAT BELT	30
CHECK BEFORE STARTING	31
WALK-AROUND CHECK	31
CHECK MONITOR PANEL	31
CHECK AND REFILL COOLANT	32
CHECK OIL LEVEL AND REFILL IN ENGINE OIL PAN	32
CHECK FUEL LEVEL AND REFILL FUEL	33
CHECK AIR CLEANER SERVICE INDICATOR	33
DRAIN WATER FROM AIR TANK	34
CHECK FOR SEDIMENT AND WATER IN THE WATER SEDIMENTOR	34
FUEL/WATER SEPARATOR - DRAINING WATER AND SEDIMENT	35
DRIVE BELT - INSPECTION	35
FAN - INSPECTION	35
OPERATING YOUR MACHINE	37
BEFORE STARTING THE ENGINE	37
TO START THE ENGINE	38
SPECIAL STARTING	38
CHECKS AFTER STARTING	39
TO MOVE THE MACHINE OFF	39

MidWestTech | Komatsu WA380-1LC W... Order the manual at mid-west-tech.com >

CONTENTS - Continued

DESCRIPTION	PAGE
CHANGING GEAR SPEED	40
CHANGING DIRECTION	41
TURNING	41
TO STOP THE MACHINE	42
TO STOP THE ENGINE	43
MAXIMUM DEPTH OF WATER	43
IF WHEEL BRAKE DOES NOT WORK	43
PRECAUTIONS WHEN DRIVING UP OR DOWN SLOPES	44
LOWER THE CENTER OF GRAVITY WHEN TURNING	44
BRAKING ON DOWNHILL SLOPES	44
IF ENGINE STOPS	44
PROPER BUCKET AND TIRE	45
ADJUSTMENT OF WORK EQUIPMENT	46
ADJUSTING BOOM KICKOUT	46
ADJUSTING BUCKET POSITIONER	47
BUCKET LEVEL INDICATOR	47
HANDLING THE TIRES	48
PRECAUTIONS WHEN HANDLING TIRES	48
PRECAUTIONS WHEN DRIVING MACHINE	49
TIRE PRESSURE	50
INFLATING TIRES	50
TOWING	52
TOWING THE MACHINE	52
WHEN ENGINE CAN BE USED	52
WHEN ENGINE CANNOT BE USED	52
RELEASING PARKING BRAKE	53
COLD WEATHER OPERATION	54
PREPARATION FOR LOW TEMPERATURE	54
FUEL AND LUBRICANTS	54
COOLANT	54
BATTERY	54
STARTING IN COLD WEATHER	55
CAUTIONS AFTER COMPLETION OF WORK	56
AFTER COLD WEATHER	56

MAINTENANCE

PERIODIC MAINTENANCE	2
BLEEDING AIR FROM CIRCUIT	2
BLEEDING AIR FROM HYDRAULIC CIRCUIT	2
BLEEDING AIR FROM FUEL SYSTEM	3
LOW PRESSURE LINES AND FUEL FILTER(S) VENTING	3
HIGH PRESSURE LINES-VENTING	3

MidWestTech | Komatsu WA380-1LC... Order the manual at mid-west-tech.com >