SEAMW00203

Operation & Maintenance Manual

WD900-3

WHEEL DOZER

SERIAL NUMBERS WD900-3 50001 and up

September 2004

KOMATSU

MidWestTech | Komatsu WD900-3 Wheel Dozer Operation & Maintenance Manual | Public... Order the manual at mid-west-tech.com >

5. CONTENTS

1. Foreword 0- 1

2. Safety information 0- 2

3. Introduction 0- 3

4. Location of plates, table to enter serial No. and distributor 0- 4

SAFETY

6. General precautions 1- 2

7. Precautions during operation 1- 7
   - 7.1 Before starting engine 1- 7
   - 7.2 After starting engine 1-10
   - 7.3 Transportation 1-18
   - 7.4 Battery 1-19
   - 7.5 Towing 1-21

8. Precautions for maintenance 1-22
   - 8.1 Before carrying out maintenance 1-22
   - 8.2 During maintenance 1-27
   - 8.3 Tires 1-33

9. Position for attaching safety labels 1-35

OPERATION

10. General view 2- 2
    - 10.1 General view of machine 2- 2
    - 10.2 General view of controls and gauges 2- 3

11. Explanation of components 2- 4
    - 11.1 Machine monitor 2- 4
    - 11.2 Switches 2-14
    - 11.3 Control levers, pedals 2-22
    - 11.4 Steering column tilt lever 2-26
    - 11.5 Cap with lock 2-26
    - 11.6 Safety bar 2-27
    - 11.7 Grease pump 2-28
    - 11.8 Backup alarm 2-28
    - 11.9 Door-open lock 2-28
    - 11.10 Tool box 2-28
    - 11.11 Fuel stop lever 2-28
    - 11.12 Fuse 2-29
    - 11.13 Slow-blow fuse 2-30
    - 11.14 Lunch box tray 2-31
    - 11.15 Storaging place of this manual 2-31
    - 11.16 Taking off power 2-31
    - 11.17 Precautions when handling accumulator 2-32

MidWestTech | Komatsu WD900-3 Wheel Dozer Operation & Maintenance Manual | P... Order the manual at mid-west-tech.com >

12. Operation 2-33
12.1 Check before starting engine 2-33
12.2 Starting engine 2-48
12.3 Operations and checks after starting engine 2-50
12.4 Moving machine off 2-51
12.5 Changing gear speed 2-53
12.6 Changing direction 2-54
12.7 Turning 2-56
12.8 Stopping machine 2-57
12.9 Operation of work equipment 2-58
12.10 Work possible using wheel dozer 2-60
12.11 Precautions for operation 2-61
12.12 Parking machine 2-63
12.13 Checks after completion of operation 2-64
12.14 Stopping engine 2-64
12.15 Check after stopping engine 2-65
12.16 Locking 2-65
12.17 Handling the tires 2-66

13. Transportation 2-68
13.1 Lifting machine 2-68

14. Cold weather operation 2-69
14.1 Precautions for low temperature 2-69
14.2 Precautions after completion of work 2-71
14.3 After cold weather 2-71
14.4 Warming-up operation for steering hydraulic circuit in cold weather 2-72

15. Long-term storage 2-73
15.1 Before storage 2-73
15.2 During storage 2-73
15.3 After storage 2-73

16. Troubleshooting 2-74
16.1 When machine runs out of fuel 2-74
16.2 Towing the machine 2-75
16.3 If battery is discharged 2-78
16.4 Other trouble 2-82

MidWestTech | Komatsu WD900-3 Wheel Dozer Operation & Maintenance Manual | P... Order the manual at mid-west-tech.com >

MAINTENANCE

17. Guides to maintenance 3- 2

18. Outlines of service 3- 5
18.1 Handling oil, fuel, coolant, and performing oil clinic 3- 5
18.2 Outline of electric system 3- 8

19. Wear parts list 3- 9

20. Use of fuel, coolant and lubricants according to ambient temperature 3-10

21. Standard tightening torques for bolts and nuts 3-14
21.1 Introduction of necessary tools 3-14
21.2 Torque list 3-15

22. Periodic replacement of safety critical parts 3-16

23. Maintenance schedule chart 3-18
23.1 Maintenance schedule chart 3-18

24. Service Procedure 3-22
24.1 Initial 250 hours service 3-22
24.2 When required 3-23
24.3 Check before starting 3-46
24.4 Every 50 hours service 3-53
24.5 Every 100 hours service 3-54
24.6 Every 250 hours service 3-58
24.7 Every 500 hours service 3-62
24.8 Every 1000 hours service 3-68
24.9 Every 2000 hours service 3-74
24.10 Every 4000 hours service 3-84

SPECIFICATIONS

25. Specifications 4- 2

OPTIONS, ATTACHMENTS

26. Optional part and attachments 5- 2

27. Handling auto shift system 5- 3
27.1 Automatic shift system 5- 3
27.2 Precautions when changing direction 5- 4

28. Handling joystick steering system 5- 7
28.1 Explanation of components 5- 7
28.2 Structure and function of joystick steering 5- 8
28.3 Operation method of joystick steering system 5-11
28.4 Precautions for steering with joystick 5-13
28.5 Adjustment of joystick console 5-14
28.6 Adjustment operator's seat 5-15

MidWestTech | Komatsu WD900-3 Wheel Dozer Operation & Maintenance Manual | P... Order the manual at mid-west-tech.com >