SEAMW01900

Operation & Maintenance Manual

KOMATSU®

WD600-1H

-50° Specification

WHEEL DOZER

SERIAL NUMBERS WD600-1H 10169 and up

January 2003

Copyright 2003 Komatsu
DataKom Publications and Training Division

MidWestTech | Komatsu WD600-1H Wheel Dozer Operation & Maintenance Manual | Publi... Order the manual at mid-west-tech.com >

5. CONTENTS

1. **Foreword** 0- 1

2. **Safety information** 0- 4

3. **Introduction** 0- 6

4. **Location of plates, table to enter serial No. and distributor** 0- 7

SAFETY

6. **General precautions** 1- 2

7. **Precautions for operation** 1-11
   - 7.1 Before starting engine 1-11
   - 7.2 After starting engine 1-12
   - 7.3 Transportation 1-16
   - 7.4 Battery 1-17
   - 7.5 Towing 1-19

8. **Precautions for maintenance** 1-20
   - 8.1 Before carrying out maintenance 1-20
   - 8.2 During maintenance 1-22
   - 8.3 Precautions with tires 1-26

9. **Position for attaching safety labels** 1-27
   - 9.1 Position for attaching safety labels 1-27

OPERATION

10. **General view** 2- 2
    - 10.1 General view of machine 2- 2
    - 10.2 General view of controls and gauges 2- 3

11. **Explanation of components** 2- 5
    - 11.1 Meters and lamps 2- 5
    - 11.2 Switches 2-13
    - 11.3 Control levers, pedals 2-20
    - 11.4 Steering column tilt lever 2-25
    - 11.5 Dust indicator 2-25
    - 11.6 Cap with lock 2-26
    - 11.7 Safety bar 2-27
    - 11.8 Towing pin 2-27
    - 11.9 Backup alarm 2-27
    - 11.10 Circuit breaker 2-28
    - 11.11 Circuit breaker (main) 2-30
    - 11.12 Air conditioner 2-31

MidWestTech | Komatsu WD600-1H Wheel Dozer Operation & Maintenance Manual | Pu... Order the manual at mid-west-tech.com >

12. Operation 2-35
12.1 Check before starting engine 2-35
12.2 Starting engine 2-48
12.3 Operations and checks after starting engine 2-52
12.4 Moving machine off 2-53
12.5 Changing gear speed 2-55
12.6 Changing direction 2-56
12.7 Turning 2-57
12.8 Stopping machine 2-58
12.9 Operation of work equipment 2-59
12.10 Work possible using wheel dozer 2-61
12.11 Precautions for operation 2-62
12.12 Parking machine 2-64
12.13 Checks after completion of operation 2-65
12.14 Stopping engine 2-65
12.15 Check after stopping engine 2-66
12.16 Locking 2-66
12.17 Handling tires 2-67

13. Transportation 2-69
13.1 Loading, unloading work 2-69
13.2 Precautions for loading 2-70
13.3 Lifting machine 2-70
13.4 Precautions for transportation 2-73

14. Cold weather operation 2-74
14.1 Precautions for low temperature 2-74
14.2 Handling engine panel cover, air cleaner suction port panel 2-76
14.3 Handling radiator shutter 2-77
14.4 Handling brake oil 2-78
14.5 Precautions after completion of work 2-78
14.6 After cold weather 2-78
14.7 Warming-up operation 2-79

15. Long-term storage 2-80
15.1 Before storage 2-80
15.2 During storage 2-80
15.3 After storage 2-80

16. Troubleshooting 2-81
16.1 When machine runs out of fuel 2-81
16.2 Towing machine 2-82
16.3 If battery is discharged 2-84
16.4 Other trouble 2-88

MidWestTech | Komatsu WD600-1H Wheel Dozer Operation & Maintenance Manual |... Order the manual at mid-west-tech.com >

MAINTENANCE

17. Guides to maintenance 3- 2

18. Outlines of service 3- 4
18.1 Outline of oil, fuel, coolant 3- 4
18.2 Outline of electric system 3- 5

19. Wear parts list 3- 6

20. Use of fuel, coolant and lubricants according to ambient temperature 3- 7

21. Standard tightening torques for bolts and nuts 3-11
21.1 Torque list 3-11

22. Periodic replacement of safety critical parts 3-12

23. Maintenance schedule chart 3-14
23.1 Maintenance schedule chart 3-14

24. Service Procedure 3-18
24.1 Initial 250 hours service 3-18
24.2 When required 3-19
24.3 Check before starting 3-37
24.4 Every 50 hours service 3-38
24.5 Every 100 hours service 3-39
24.6 Every 250 hours service 3-41
24.7 Every 500 hours service 3-50
24.8 Every 1000 hours service 3-55
24.9 Every 2000 hours service 3-60
24.10 Every 4000 hours service 3-67

SPECIFICATIONS

25. Specifications 4- 2

MidWestTech | Komatsu WD600-1H Wheel Dozer Operation & Maintenance Manual | P... Order the manual at mid-west-tech.com >