SEAT000904

Operation & Maintenance Manual

PAYLOAD METER II
PLMII

HD325-6
HD405-6
HD465-5
HD605-5
HD785-3
HD785-5
HD985-3
HD985-5
HD1200-1

May 2004

KOMATSU

MidWestTech | Komatsu HD325-6, HD405-6, HD465-5, HD605-5, HD785-3, HD785-5, HD98... Order the manual at mid-west-tech.com >

3. CONTENTS

1. Introduction 1

2. Precise use 2

4. General locations 4
   - 4.1 Front face of controller 4
   - 4.2 Left face of controller 5
   - 4.3 External display lamps 7
   - 4.4 Communications cable connection port for personal computer 7

5. Content of display (controller, external display lamps) 8
   - 5.1 When power is ON 8
   - 5.2 Display during normal operations 9

6. External display lamps 13
   - 6.1 Display level for lamps 13
   - 6.2 Estimate display 14

7. Details of date stored in memory of payload meter 15
   - 7.1 Cycle date 16
   - 7.2 Engine ON/OFF data 17
   - 7.3 Abnormality, warning date 18
   - 7.4 Total payload, overall number of cycles date 19
   - 7.5 Other data 19

8. Operation of switches 20
   - 8.1 Carrying out calibration 21
   - 8.2 Forced display of total payload and overall number of cycles 22
   - 8.3 Operator check mode 26
   - 8.4 Dimming lights on monitor display 41
   - 8.5 Adjusting buzzer sound lever 41
   - 8.6 Setting mass unit 41
   - 8.7 Setting forced prohibition for switches 41
   - 8.8 Service check mode 42

9. Abnormality and warning display (error code) 43

10. When F-09 is displayed for the error code (procedure for replacing battery) 51
    - 10.1 Replacing battery 51
    - 10.2 After replacing the battery, do as follows 53

11. Operation if F-CAL is displayed as an error code or the controller is replaced 54

MidWestTech | Komatsu HD325-6, HD405-6, HD465-5, HD605-5, HD785-3, HD785-5, H... Order the manual at mid-west-tech.com >