SHOP MANUAL

KOMATSU®

155-4 SERIES

DIESEL ENGINE

© 2008 KOMATSU
All Rights Reserved
Printed in Japan 08-08 (01)

MidWestTech | Komatsu 155-4 Series Diesel Engine Service Manual | Publication SEBE6120A05
Order the manual at mid-west-tech.com >

CONTENTS

No. of page

01 GENERAL 01-001

11 STRUCTURE AND FUNCTION

GENERAL STRUCTURE 11-004
INTAKE AND EXHAUST SYSTEM 11-102
ENGINE 11-201
LUBRICATION SYSTEM 11-302
FUEL SYSTEM 11-401
COOLING SYSTEM 11-502
ACCESSORY 11-602

12 TESTING AND ADJUSTING

FUEL SYSTEM 12-402
PERFORMANCE TEST 12-701
TESTING AND ADJUSTING TOOL LIST 12-901
TESTING AND ADJUSTING, TROUBLESHOOTING CRITERIA 12-902

13 DISASSEMBLY AND ASSEMBLY

OVERALL DISASSEMBLY 13-004
OVERALL ASSEMBLY 13-102
DISASSEMBLY AND ASSEMBLY OF ASSEMBLY PART 13-202

14 MAINTENANCE STANDARD

INTAKE AND EXHAUST SYSTEM 14-004
ENGINE 14-008
LUBRICATION SYSTEM 14-030
COOLING SYSTEM 14-036
ACCESSORY 14-037

15 REPAIR AND REPLACEMENT 15-001

MidWestTech | Komatsu 155-4 Series Diesel Engine Service Manual | Publication SE... Order the manual at mid-west-tech.com >