SEBE61360109

SHOP MANUAL

KOMATSU®

6D105 SERIES DIESEL ENGINE

MidWestTech | Komatsu 110 Series Diesel Engine Service Manual | Publication SEBE61360109

Order the manual at mid-west-tech.com >

CONTENTS

		No. of page
01	GENERAL	01-001
11	STRUCTURE AND FUNCTION	11-001
12	TESTING AND ADJUSTING	12-001
13	DISASSEMBLY AND ASSEMBLY	13-001
14	MAINTENANCE STANDARD	14-001

Not to be reproduced in whole or in part without the prior written permission of KOMATSU , Tokyo, Japan.

MidWestTech | Komatsu 110 Series Diesel Engine Service Manual | Publication SEBE... Order the manual at mid-west-tech.com >

The affected pages are indicated by the use of the following marks. It is requested that necessary actions be taken to these pages according to the table below.

Mark	Indication	Action required
○	Page to be newly added	Add
●	Page to be replaced	Replace
( )	Page to be deleted	Discard

Pages having no marks are those previously revised or made aditions.

LIST OF REVISED PAGES

Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number
●	00-1	(9)		01-026			11-016			11-061			12-030	
	00-2	(8)		01-027		●	11-017	(9)		11-062			12-031	
●	00-2-1	(9)		01-028			11-018		●	11-063	(9)		12-032	
●	00-2-2	(9)		01-029			11-019			11-064			12-033	
	00-3			01-030		●	11-020	(9)	●	11-065	(9)		12-034	
	00-4			01-031			11-021			11-065-1	(7)		12-035	
	00-5			01-032			11-022			11-066			12-036	(8)
	00-6			01-033			11-023		●	11-067	(9)		12-037	(8)
	00-7			01-034			11-024		●	11-068	(9)		12-037-1	(7)
	00-8			01-035			11-025		○	11-068-1	(9)	●	12-038	(9)
	00-9			01-036			11-026			11-069			12-039	
	00-10			01-036-1	(7)		11-027		●	11-070	(9)		12-040	
	00-11			01-037			11-028		●	11-071	(9)		12-041	
	00-12			01-038			11-029		●	11-072	(9)		12-042	
	00-13			01-038-1	(8)		11-030			11-074			12-043	
	00-14			01-039		●	11-031	(9)		11-075			12-044	
	00-15			01-040			11-032					●	12-045	(9)
	00-16			01-041			11-033			12-001	(7)		12-046	
				01-042			11-035	(7)		12-002			12-047	
	01-001			01-043			11-036			12-003	(7)	●	12-048	(9)
	01-002			01-044			11-037			12-004			12-049	
	01-003			01-045			11-038			12-005			12-050	
	01-004			01-046			11-039			12-006			12-051	
	01-005			01-047	(7)		11-040			12-007			12-052	
	01-006			01-048	(7)		11-041	(7)		12-008			12-053	
●	01-007	(9)		01-049		●	11-042	(9)		12-009			12-054	
●	01-008	(9)	○	01-050	(9)		11-043			12-010			12-055	
●	01-009	(9)	○	01-051	(9)		11-044	(7)	●	12-011	(9)		12-056	
●	01-009-1	(9)	○	01-052	(9)		11-045		●	12-012	(9)		12-057	
●	01-010	(9)					11-046	(7)	●	12-013	(9)		12-058	
	01-011	(7)		11-001	(7)		11-047		●	12-014	(9)		12-058-1	(8)
○	01-011-1	(9)		11-002		●	11-048	(9)		12-015			12-058-2	(8)
	01-012			11-003			11-049			12-016		○	12-058-3	(9)
	01-013			11-004		●	11-050	(9)		12-017		○	12-058-4	(9)
	01-014			11-005		●	11-050-1	(9)		12-018		○	12-058-5	(9)
	01-015		●	11-006	(9)		11-050-2	(7)		12-019			12-059	
	01-016			11-007			11-051	(7)		12-020			12-060	
	01-017			11-008	(7)		11-052			12-021			12-061	
	01-018			11-008-1	(7)		11-053		●	12-022	(9)		12-062	
	01-019			11-009			11-054		●	12-023	(9)		12-063	
	01-020	(7)		11-010	(7)		11-055			12-024		●	12-064	(9)
	01-021			11-011			11-056			12-025			12-065	
	01-022	(7)		11-012			11-057			12-026			12-066	
	01-023			11-013	(7)		11-058			12-027			12-067	
●	01-024	(9)		11-014			11-059		●	12-028	(9)		12-068	
	01-025			11-015			11-060		●	12-029	(9)	●	12-069	(9)

MidWestTech | Komatsu 110 Series Diesel Engine Service Manual | Publication SEBE... Order the manual at mid-west-tech.com >