SEBES6161000

OEM USE

SHOP MANUAL

KOMATSU®

6D170-1 SERIES DIESEL ENGINE

APPLICABLE
ENGINE MODELS

S6D170-1

SA6D170-B-1

SA6D170-A-1

KOMATSU

MidWestTech | Komatsu S6D170-1, SA6D170-B-1, SA6D170-A-1 Series Diesel Engine Service Manual | Publication SEBES6161000

Order the manual at mid-west-tech.com >

ENGINE

11 STRUCTURE AND FUNCTION



GENERAL STRUCTURE 11- 2

INTAKE AND EXHAUST SYSTEM

Intake and exhaust system 11- 4
Turbocharger 11-11
After-cooler 11-15

ENGINE BODY

Cylinder head 11-16
Valve system 11-18
Cylinder block 11-20
Main circulation part 11-22
Timing gear 11-24
Flywheel and flywheel housing 11-26

LUBRICATION SYSTEM

Lubrication system chart 11-27
Oil pump 11-28
Oil filter and safety valve 11-29
Oil cooler 11-30
Main relief valve 11-32
Oil cooler by-pass valve 11-32
Piston cooling valve 11-33
Mechanical pump 11-34

FUEL SYSTEM

Fuel system chart 11-35
Fuel injection pump 11-36
Fuel injection nozzle 11-40
Fuel injection pump drive 11-41
Fuel filter 11-42
Fuel solenoid 11-43
Engine stop motor 11-45
Starting aid 11-50

COOLING SYSTEM

Cooling system chart 11-51
Water pump 11-52
Fan drive and tension pulley 11-53
Corrosion resistor 11-57
Thermostat 11-58

ACCESSORY

Air compressor mounting 11-59
Air compressor 11-60

ELECTRICAL SYSTEM

Alternator 11-61
Starting motor 11-63

MidWestTech | Komatsu S6D170-1, SA6D170-B-1, SA6D170-A-1 Series Diesel Engine... Order the manual at mid-west-tech.com >