SEBMU1440102

Shop Manual

D68E-1
D68P-1

BULLDOZER

SERIAL NUMBERS	D68E-1	1001 and up
	D68E-1A (BRAZILIAN)	B1001 and up
	D68P-1	45590 and up
	D68P-1A (BRAZILIAN)	B1001 and up

KOMATSU®

www.KomatsuAmerica.com

MidWestTech | Komatsu D68E-1, D68E-1A, D68P-1, D68P-1A Bulldozer Service Manual | Publication SEBMU1440102

Order the manual at mid-west-tech.com >

CONTENTS

No. of page

10 ENGINE

11 STRUCTURE AND FUNCTION 11-1
12 TESTING AND ADJUSTING 12-1
13 DISASSEMBLY AND ASSEMBLY 13-1

20 POWER TRAIN

21 STRUCTURE AND FUNCTION 21-1
22 TESTING AND ADJUSTING 22-1
23 DISASSEMBLY AND ASSEMBLY 23-1
24 MAINTENANCE STANDARD 24-1

30 UNDERCARRIAGE

31 STRUCTURE AND FUNCTION 31-1
33 DISASSEMBLY AND ASSEMBLY 33-1
34 MAINTENANCE STANDARD 34-1

60 HYDRAULIC SYSTEM

61 STRUCTURE AND FUNCTION 61-1
62 TESTING AND ADJUSTING 62-1
63 DISASSEMBLY AND ASSEMBLY 63-1
64 MAINTENANCE STANDARD 64-1

70 WORK EQUIPMENT


71 STRUCTURE AND FUNCTION 71-1
73 DISASSEMBLY AND ASSEMBLY 73-1
74 MAINTENANCE STANDARD 74-1

80 ELECTRIC AND ELECTRONIC SYSTEM

81 STRUCTURE AND FUNCTION 81-1

MidWestTech | Komatsu D68E-1, D68E-1A, D68P-1, D68P-1A Bulldozer Service Manual |... Order the manual at mid-west-tech.com >

ELECTRICAL CIRCUIT DIAGRAM



F14408009A

MidWestTech | Komatsu D68E-1, D68E-1A, D68P-1, D68P-1A Bulldozer Service Manual | Publication SEBMU1440102

Order the manual at mid-west-tech.com >