SHOP MANUAL

KOMATSU®

TOWING WINCH

Order the manual at mid-west-tech.com >

CONTENTS

No. of page

DWT031 ..... 031- 1

DWT045, 053 ..... 045- 1

DWC040,050

1. SPECIFICATION 050- 2
2. STRUCTURE AND FUNCTION 050- 3
3. SERVICE INFORMATION 050- 9
4. ASSEMBLING INFORMATION 050-10

DWC060

1. SPECIFICATION 060- 2
2. STRUCTURE AND FUNCTION 060- 3
3. TESTING AND ADJUSTING OF HYDRAULIC PRESSURE 060-15
4. SERVICE INFORMATION 060-16
5. ASSEMBLING INFORMATION 060-19
6. FAIRLEAD 060-22

DWC080

1. SPECIFICATION 080- 2
2. STRUCTURE AND FUNCTION 080- 3
3. MAINTENANCE STANDARD 080- 9
4. FAIRLEAD 080-10

DWT083

1. SPECIFICATION 083- 4
2. STURCTURE AND FUNCTION 083- 5
3. TESTING AND ADJUSTING OF HYDRAULIC PRESSURE 083-15
4. MAINTENANCE STANDARD 083-16
5. ASSEMBLING INFORMATION 083-19

DWT125

1. SPECIFICATION 125- 2
2. STRUCTURE AND FUNCTION 125-11
3. TESTING AND ADJUSTING OF HYDRAULIC PRESSURE 125-23
4. SERVICE INFORMATION 125-24
5. ASSEMBLING INFORMATION 125-28

MidWestTech | Komatsu Towing Winch Service Manual | Publication SEBT010WT04 Order the manual at mid-west-tech.com >