SEN05644-05

Shop Manual

HYDRAULIC
EXCAVATOR

PC290LC-10

SERIAL NUMBERS 15001 and up

KOMATSU®

MidWestTech | Komatsu PC290LC-10 Hydraulic Excavator Service Manual | Publication SEN05644-05

Order the manual at mid-west-tech.com >

Index (ALL-0310-001-A-00-A)

00 Index and foreword 00-1
Index 00-2
Foreword, safety and general information 00-14
Important safety notice 00-14
How to read the shop manual 00-21
Explanation of terms for maintenance standard 00-23
Handling equipment of fuel system devices 00-25
Handling of intake system parts 00-26
Handling of hydraulic equipment 00-27
Method of disconnecting and connecting of push-pull type coupler 00-29
Handling of electrical equipment 00-32
How to read electric wire code 00-40
Precautions when performing operation 00-43
Practical use of KOMTRAX 00-48
Standard tightening torque table 00-49
List of abbreviation 00-55
Conversion table 00-60
01 Specification 01-1
Table of contents 01-2
Specifications 01-3
Specification drawings 01-3
Working range drawings 01-4
Specifications 01-5
Weight table 01-8
Table of fuel, coolant and lubricants 01-9
10 Structure and function 10-1
Table of contents 10-2
Engine and cooling system 10-3
Engine related parts 10-3
KVGT 10-5
EGR system piping drawing 10-12
EGR system circuit diagram 10-14
EGR valve 10-16
EGR cooler 10-18
KCCV layout drawing 10-20
KCCV ventilator 10-22
KDPF 10-24
Cooling system 10-28
Power train 10-30
Power train system 10-30
Swing circle 10-32
Swing machinery 10-33
Final drive 10-35
Undercarriage and frame 10-37
Track frame and idler cushion 10-37
Hydraulic system 10-39
Hydraulic equipment layout drawing 10-39
Valve control 10-41
Hydraulic tank 10-43
CLSS 10-45
Main pump 10-50
Control valve 10-74
Swing motor 10-128
Travel motor 10-139
PPC valve 10-153
Solenoid valve 10-174
Attachment circuit selector valve (for high pressure circuit) 10-177

MidWestTech | Komatsu PC290LC-10 Hydraulic Excavator Service Manual | Publicatio... Order the manual at mid-west-tech.com >

Attachment circuit selector valve (for low pressure circuit) 10-179
Center swivel joint 10-182
Accumulator 10-184
Work equipment 10-185
Work equipment 10-185
Work equipment shim 10-186
Bucket play adjustment shim 10-187
Cab and its attachments 10-188
Cab mount and cab tipping stopper 10-188
ROPS cab 10-189
Electrical system 10-190
Electrical control system 10-190
Machine monitor system 10-234
KOMTRAX system 10-254
Sensor 10-256
20 Standard value tables 20-1
Table of contents 20-2
Standard service value table 20-3
Standard value table for engine related parts 20-3
Standard value table for chassis related parts 20-5
30 Testing and adjusting 30-1
Table of contents 30-2
Related information on testing and adjusting 30-3
Tools for testing and adjusting 30-3
Sketch of tools for testing and adjusting 30-7
Engine and cooling system 30-9
Testing engine speed 30-9
Testing boost pressure 30-10
Testing exhaust gas color 30-11
Testing and adjusting valve clearance 30-13
Testing compression pressure 30-16
Measuring blowby pressure 30-20
Measuring engine oil pressure 30-21
Measuring EGR valve and KVGT oil pressure 30-22
Measuring fuel pressure 30-23
Measuring fuel delivery, return and leakage 30-29
Bleeding air from fuel system 30-34
Testing fuel circuit for leakage 30-36
Handling cylinder cutout mode operation 30-37
Handling no-injection cranking operation 30-38
Testing and adjusting air conditioner compressor belt tension 30-39
Replacing fan belt 30-40
Power train 30-41
Testing swing circle bearing clearance 30-41
Undercarriage and frame 30-42
Testing and adjusting track tension 30-42
Hydraulic system 30-43
Releasing remaining pressure from hydraulic circuit 30-43
Measuring and adjusting oil pressure in work equipment, swing, and travel circuits 30-44
Testing oil pressure in control circuit 30-48
Testing and adjusting oil pressure in pump PC control circuit 30-49
Testing and adjusting oil pressure in pump LS control circuit 30-52
Testing output pressure of solenoid valve 30-57
Measuring PPC valve output pressure 30-61
Adjusting play of work equipment and swing PPC valves 30-63
Testing pump swash plate sensor 30-64
Isolating the parts causing hydraulic drift in work equipment 30-65
Testing oil leakage 30-67
Bleeding air from hydraulic circuit 30-70

MidWestTech | Komatsu PC290LC-10 Hydraulic Excavator Service Manual | Publicatio... Order the manual at mid-west-tech.com >

Cab and its attachments 30-72
Testing cab tipping stopper 30-72
Adjusting mirrors 30-73
Electrical system 30-75
Special functions of machine monitor 30-75
Adjusting rearview camera angle 30-141
Handling voltage circuit of engine controller 30-143
Handling battery disconnect switch 30-144
Testing diodes 30-145
Pm clinic 30-146
Pm clinic service 30-146
40 Troubleshooting 40-1
Table of contents 40-2
Related information on troubleshooting 40-9
Troubleshooting points 40-9
Sequence of events in troubleshooting 40-11
Testing before troubleshooting 40-13
Inspection procedure before troubleshooting 40-15
Preparation work for troubleshooting of electrical system 40-43
Classification and procedure for troubleshooting 40-47
Symptom of probable failure and troubleshooting No. 40-50
Information in troubleshooting table 40-53
Diagnostic procedure for wiring harness open curcuit of pressure sensor system 40-55
Connector list and layout 40-57
Connector contact identification 40-68
T-branch box and T-branch adapter table 40-107
Fuse list and location 40-112
Precautions for KDPF (KCSF and KDOC) Cleaning and Replacement 40-114
Failure codes table 40-117
Troubleshooting by failure code (Display of code) 40-126
Failure code [879AKA] A/C Inner Sensor Open Circuit 40-126
Failure code [879AKB] A/C Inner Sensor Short Circuit 40-127
Failure code [879BKA] A/C Outer Sensor Open Circuit 40-128
Failure code [879BKB] A/C Outer Sensor Short Circuit 40-129
Failure code [879CKA] Ventilating Sensor Open Circuit 40-130
Failure code [879CKB] Ventilating Sensor Short Circuit 40-131
Failure code [879DKZ] Sunlight Sensor Open or Short Circuit 40-132
Failure code [879EMC] Ventilation Damper Abnormality 40-133
Failure code [879FMC] Air Mix Damper Abnormality 40-134
Failure code [879GKX] Refrigerant Abnormality 40-135
Failure code [989L00] Engine Controller Lock Caution1 40-136
Failure code [989M00] Engine Controller Lock Caution2 40-137
Failure code [989N00] Engine Controller Lock Caution3 40-138
Failure code [A1U0N3] HC desorb request1 40-139
Failure code [A1U0N4] HC desorb request2 40-141
Failure code [AA10NX] Air Cleaner Clogging 40-143
Failure code [AB00KE] Charge Voltage Low 40-145
Failure code [B@BAZG] Engine Oil Pressure Low 40-147
Failure code [B@BAZK] Eng Oil Level Low 40-148
Failure code [B@BCNS] Engine Coolant Overheat 40-149
Failure code [B@BCZK] Radiator Coolant Level Low 40-150
Failure code [B@HANS] Hyd Oil Overheat 40-152
Failure code [CA115] Eng Ne and Bkup Speed Sens Error 40-153
Failure code [CA122] Chg Air Press Sensor High Error 40-154
Failure code [CA123] Chg Air Press Sensor Low Error 40-156
Failure code [CA131] Throttle Sensor High Error 40-158
Failure code [CA132] Throttle Sensor Low Error 40-160
Failure code [CA144] Coolant Temp Sens High Error 40-162
Failure code [CA145] Coolant Temp Sens Low Error 40-164

MidWestTech | Komatsu PC290LC-10 Hydraulic Excavator Service Manual | Publicatio... Order the manual at mid-west-tech.com >

Failure code [CA3315] KDOC Inlet Temp Sens In Range Error

(PC220_10-CA3315-400-A-00-A)

Action level	Failure code	Failure	KDOC inlet temperature sensor in-range error (Engine controller system)
L03	CA3315		
Details of failure	• Temperatures sensed by KDOC inlet temperature sensor and KDOC outlet temperature sensor deviate from estimated values (signal voltages are in normal range).		
Action of controller	• KDOC outlet temperature is substituted for KDOC inlet temperature to continue operation. (If the KDOC outlet temperature sensor is also abnormal, the default value (250° C) is taken as KDOC inlet temperature to continue operation.) • Closes EGR valve. • Limits engine output and allows engine to run. • Disables KDPF of its regeneration control.		
Problem on machine	• Engine output lowers.		
Related information	⚠ **Since the temperature of the KDPF and KDOC will become higher than 500°C, take care not to get burn injury.** • Signal voltage from the KDOC inlet temperature sensor can be checked by using monitoring function. (Code: 47301(V)) • Temperature sensed by the KDOC inlet temperature sensor can be checked by using monitoring function. (Code: 47300 (°C)) • Signal voltage from the KDOC outlet temperature sensor can be checked by using monitoring function. (Code: 47401(V)) • Temperature sensed by the KDOC outlet temperature sensor can be checked by using monitoring function. (Code: 47400 (°C)) • Signal voltage from the KDPF outlet temperature sensor can be checked by using monitoring function. (Code: 47201(V)) • Temperature sensed by the KDPF outlet temperature sensor can be checked by using monitoring function. (Code: 47200 (°C)) • The KDOC inlet temperature sensor connector label "TEMP1" is indicated on the KDPF temperature sensor integrated box in black embossed letters (same for KDOC outlet temperature sensor connector label "TEMP2" and KDPF outlet sensor connector label "TEMP3"). • Method of reproducing failure code: Starting switch: ON [Clearing failure codes] 1. Start the engine (from stopped state). 2. When warm-up operation is complete, set fuel dial to Full and put the work equipment pump in relief condition for 30 seconds. Repeat steps 1 and 2 several times. If this failure code is cleared, repair is complete.		

No.	Cause	Procedure, measuring location, criteria and remarks
1	Defective KDOC inlet temperature sensor	If failure code [CA3313] or [CA3314] is displayed, carry out troubleshooting for it first.
2	Defective wiring harness connector	1. See descriptions of wirings harness and connectors in "c: Electrical equipment" in "Checks before troubleshooting" of "General information on troubleshooting", and check them. 2. Starting switch: ON
		If this failure code does not appear, the wiring harness connector is defective. ★ If this failure code appears, perform the following.
3	Defective wiring harness or engine controller	1. Starting switch: OFF 2. Disconnect TEMP1 (KDOC inlet temperature sensor). 3. Starting switch: ON
		If failure code [CA3314] is not displayed, the wiring harness or engine controller is defective. ★ Carry out troubleshooting for cause 2 again.

MidWestTech | Komatsu PC290LC-10 Hydraulic Excavator Service Manual | Publicatio... Order the manual at mid-west-tech.com >

<table>
<tr><th>No.</th><th>Cause</th><th colspan="3">Procedure, measuring location, criteria and remarks</th></tr>
<tr><td rowspan="4">4</td><td rowspan="4">Open circuit in wiring harness
(wire breakage or defective contact of connectors)</td><td colspan="3">1. Turn starting switch to OFF position.
2. Disconnect connectors CP01 and P07, and connect T-adapters to each female side.</td></tr>
<tr><td rowspan="3">Resistance</td><td>★ If power supply voltage in check on cause 2 is normal, this check is not required.
Between CP01 (female) (18) and P07 (female) (1)</td><td>Max. 1 Ω</td></tr>
<tr><td>Between CP01 (female) (12) and P07 (female) (2)</td><td>Max. 1 Ω</td></tr>
<tr><td>★ If power supply voltage in check on cause 2 is normal, this check is not required.
Between CP01 (female) (6) and P07 (female) (3)</td><td>Max. 1 Ω</td></tr>
<tr><td rowspan="2">5</td><td rowspan="2">Ground fault in wiring harness
(contact with GND circuit)</td><td colspan="3">1. Turn starting switch to OFF position.
2. Disconnect connectors CP01 and P07, and connect T-adapters to either female side.</td></tr>
<tr><td>Resistance</td><td>Between ground and CP01 (female) (12) or P07 (female) (2)</td><td>Min. 1 MΩ</td></tr>
<tr><td rowspan="2">6</td><td rowspan="2">Hot short circuit in wiring harness
(contact with 5 V or 24 V circuit)</td><td colspan="3">1. Turn starting switch to OFF position.
2. Disconnect connector P07.
3. Connect T-adapters to female side of connector P07.
4. Turn starting switch to ON position.</td></tr>
<tr><td>Voltage</td><td>Between P07 (female) (2) and ground</td><td>Max. 1 V</td></tr>
<tr><td>7</td><td>Defective pump controller</td><td colspan="3">If no failure is found by above checks, pump controller is defective. (Since this is an internal defect, troubleshooting cannot be performed.)</td></tr>
</table>

MidWestTech | Komatsu PC290LC-10 Hydraulic Excavator Service Manual | Publicatio... Order the manual at mid-west-tech.com >

Install the hoses and tubes to the KVGT according to the following procedures.

1. Install tube (56).

V-clamp:
7 ± 1.1 Nm {0.7 ± 0.11 kgm}

- MIKALOR clamps

★ Use a new clamp.

1) Set the hose to the original position (marked position).

★ Reference
Air hose fitting length: 50 mm (aftercooler end)
Air hose fitting length: 40 mm (KVGT end)

2) Set the bridge (**BR**) under the clamp bolt and lap it over band (**BD**) by at least 5 mm (**b**).
Dimension (**b**): Min. 5 mm


Clamp bolt thread portion (BC): Lubricant (THREEBOND PANDO 18B)

★ Impact wrench is not allowed to use.

- If hoses are to be reused
Install the clamp to the clamp mark put on the hose.

Clamp bolt:
Min. 6 Nm {0.6 kgm}

- When using a new hose
Tighten the clamp so that BDG dimension is as follows.
BDG: 7 to 10 mm





2. Install hose (57).

Hose clamp:
10.0 to 11.0 Nm {1.02 to 1.12 kgm}

3. Install hose (58).

Hose clamp:
4.4 ± 0.49 Nm {0.45 ± 0.05 kgm}

4. Install hose (54).

Hose clamp:
3.3 ± 0.49 Nm {0.34 ± 0.05 kgm}

5. Install hose (53).



[*4]

When installing a connector of quick coupler type, observe the following points.

★ The internal parts of the fitting may be damaged when the hose or tube is removed. Accordingly, do not reuse the hose or tube.
When installing, replace it with a new one.

★ Ensure that mud or dirt is not sticking to the hose joint portions in advance.

★ Push the connector straight (in the direction of (**b**)). Do not pry it in or shake it.
If it is difficult to insert the connector, do not push it in forcibly but pull it out. Then, check the male and female couplings for damage and sticking mud.



[*5]

Fuel return hose mounting bolt:
19.6 to 29.4 Nm {2.0 to 3.0 kgm}

[*6]

Fuel supply hose mounting bolt:
25.4 to 34.3 Nm {2.6 to 3.5 kgm}


[*7]

MidWestTech | Komatsu PC290LC-10 Hydraulic Excavator Service Manual | Publicatio... Order the manual at mid-west-tech.com >

Electrical circuit diagram (1/6)

PC290LC-10

★ This figure covers the equipment and devices that are unavailable as optional items in some areas.



FUSE No.	RATED	SYSTEM
1	5A	EMERGENCY SWITCH, ROOM LAMP RELAY
2	10A	SOLENOID VALVE
3	5A	PPC LOCK SOLENOID
4	10A	WINDOW WASHER, CIGAR LIGHTER
5	10A	HORN
6	5A	AUTO PREHEATER
7	10A	BEACON
8	10A	RADIO, SPEAKER, LEFT DOOR SWITCH
9	20A	WORKING LAMP
10	20A	A/C UNIT
11	10A	HEAD LAMP
12	10A	OPT. POWER SUPPLY (1)
13	20A	OPT. POWER SUPPLY (2), CAB POWER SUPPLY (FOR SUSPENSION SEAT WITH HEATER)
14	5A	A/C ECU POWER
15	5A	KEY ACC SIGNAL
16	10A	RADIO BACK UP, DOOR LAMP, SYSTEM OPERATING LAMP
17	20A	MONITOR, PUMP CONTROLLER
18	20A	ENGINE CONTROLLER
19	5A	A/C ECU BACK UP
20	10A	OPT. POWER SUPPLY (CONTINUOUS)

MidWestTech | Komatsu PC290LC-10 Hydraulic Excavator Service Manual | Publication SEN05644-05
Order the manual at mid-west-tech.com >