
VIBROMAX

1103 SINGLE DRUM ROLLER

SERVICE MANUAL SM90001

July 1998



MidWestTech | JCB Vibromax 1103 Single Drum Roller Service Manual | Publication SM90... Order the manual at mid-west-tech.com >

SECTION ONE
GENERAL INFORMATION

MACHINE DESCRIPTION ..... 1 - 3
SERIAL NUMBERS ..... 1 - 5
IDENTIFYING MACHINE COMPONENTS ..... 1 - 6
SAFETY, GENERAL ..... 1 - 7
SPARK ARRESTER ..... 1 - 7
SAFETY, PERSONAL ..... 1 - 7
SAFETY, MACHINE OPERATION ..... 1 - 8
SAFETY, MAINTENANCE ..... 1 - 9
GENERAL INFORMATION ..... 1 - 12
CLEANING ..... 1 - 12
INSPECTION ..... 1 - 12
BEARINGS ..... 1 - 12
NEEDLE BEARINGS ..... 1 - 12
GEARS ..... 1 - 12
OIL SEALS, O-RINGS, & GASKETS ..... 1 - 12
SHAFTS ..... 1 - 12
SERVICE PARTS ..... 1 - 12
LUBRICATION ..... 1 - 12
STANDARD TORQUE DATA ..... 1 - 13
MACHINE SPECIFICATIONS ..... 1 - 15
FLUID SPECIFICATIONS ..... 1 - 17
DIESEL FUEL SPECIFICATION ..... 1 - 18
ENGINE OIL SPECIFICATION ..... 1 - 19
TIRE BALLAST ..... 1 - 20

SECTION TWO
ENGINE

CUMMINS ENGINE WARRANTY ..... 2 - 3
ENGINE REMOVAL ..... 2 - 4

SECTION THREE
ELECTRICAL

GENERAL INFORMATION ..... 3 - 2
INSTRUMENT PANEL ..... 3 - 4
UNDERSTANDING ELECTRICAL SCHEMATICS ..... 3 - 7
UNDERSTANDING RELAYS ..... 3 - 9
VIBROMAX RELAYS ..... 3 - 11
STARTER/CHARGING CIRCUIT (before JKC8302000) ..... 3 - 13
STARTER/CHARGING CIRCUIT (AFTER JKC8302000) ..... 3 - 15
UNDERSTANDING BATTERIES ..... 3 - 15
BATTERY DIAGNOSTICS ..... 3 - 16

MidWestTech | JCB Vibromax 1103 Single Drum Roller Service Manual | Publication SM90... Order the manual at mid-west-tech.com >

UNDERSTANDING ALTERNATORS ..... 3 - 17
CHARGING SYSTEM DIAGNOSTICS ..... 3 - 18
VOLTAGE CHECKS AT ALTERNATOR ..... 3 - 19
SYSTEM LEAKAGE ..... 3 - 19
CIRCUIT WIRING TEST ..... 3 - 19
MEASURING ALTERNATOR OUTPUT ..... 3 - 20
UNDERSTANDING STARTERS ..... 3 - 20
STARTER SOLENOID ..... 3 - 21
STARTER SYSTEM DIAGNOSTICS ..... 3 - 21
SOLENOID CIRCUIT TEST ..... 3 - 21
STARTER CIRCUIT WIRING TEST ..... 3 - 22
STARTER MOTOR TEST ..... 3 - 23
INSTRUMENTATION PANEL ..... 3 - 25
EMERGENCY STOP SWITCH/ BRAKE SWITCH ..... 3 - 27
VIBRATION CIRCUIT ..... 3 - 29
VIBRATION AFTER JKC8300700 ..... 3 - 31
LIGHTING CIRCUIT ..... 3 - 33
WORK LIGHTS, ACCESSORY PLUG, HEATER AND WIPERS ..... 3 - 35
CAB WIRING ..... 3 - 46
WIRE HARNESS 7250/16315 ..... 3 - 47
WIRE CHART 7250/16315 ..... 3 - 52
WIRE HARNESS 7250/16110 ..... 3 - 56
WIRE CHART 7250/16110 ..... 3 - 59

SECTION FOUR
HYDRAULIC

PUMP SUCTION LINES ..... 4 - 2
HYDRAULIC COOLING SYSTEM ..... 4 - 4
HYDRAULIC DRAIN LINES ..... 4 - 6
HYDRAULIC TEST SYSTEM ..... 4 - 8
HYDRAULIC TEST STATION ..... 4 - 9
CHARGE SYSTEM ..... 4 - 11
PROPULSION SYSTEM ..... 4 - 13
MULTIFUNCTION VALVES ..... 4 - 17
PROPULSION SYSTEM DIAGNOSTICS ..... 4 - 18
INTERNAL LEAKAGE ..... 4 - 18
PUMP SERVO CONTROL ..... 4 - 19
VIBRATION SYSTEM ..... 4 - 21
VIBRATION FREQUENCY ..... 4 - 23
VIBRATION AMPLITUDE ..... 4 - 25
VIBRATORY SYSTEM DIAGNOSTICS ..... 4 - 26
STEERING SYSTEM ..... 4 - 27
PARKING BRAKE SYSTEM ..... 4 - 30
TOWING YOUR MACHINE ..... 4 - 31
PARKING BRAKE DIAGNOSTICS ..... 4 - 31

MidWestTech | JCB Vibromax 1103 Single Drum Roller Service Manual | Publication SM90... Order the manual at mid-west-tech.com >

DIFFERENTIAL LOCK SYSTEM ..... 4 - 35
HYDRAULIC SCHEMATIC ..... 4 - 38

SECTION FIVE
FINAL DRIVES

GENERAL INFORMATION ..... 5 - 2
OPERATION ..... 5 - 3
KESSLER AXLE ..... 5 - 4
SPETH STANDARD AXLE ..... 5 - 5
REAR AXLE REMOVAL ..... 5 - 6
AXLE INSTALLATION ..... 5 - 7
AXLE TUBE DISASSEMBLY ..... 5 - 8
PLANETARY DISSASSEMBLY ..... 5 - 10
DIFFERENTIAL LOCK REMOVAL ..... 5 - 12
DIFFERENTIAL LOCK ASSEMBLY ..... 5 - 13
AXLE TUBE AND PLANETARY ASSEMBLY ..... 5 - 14
INTERMEDIATE GEARBOX DISASSEMBLY ..... 5 - 18
INTERMEDIATE GEARBOX ASSEMBLY ..... 5 - 20
DIFFERENTIAL DISASSEMBLY ..... 5 - 22
DIFFERENTIAL ASSEMBLY ..... 5 - 24
DRUM REMOVAL ..... 5 - 29
DRUM INSTALLATION ..... 5 - 29
DRUM DRIVE ..... 5 - 30
DRUM DRIVE BEARING REMOVAL ..... 5 - 34
DRUM DRIVE BEARING INSTALLATION ..... 5 - 36
DRUM DRIVE MOTOR REPAIRS ..... 5 - 36

SECTION SIX
PARKING BRAKE SYSTEM

DESCRIPTION ..... 6 - 2
RELEASE AND TOWING ..... 6 - 4
DRUM MOTOR BRAKE ..... 6 - 5
DISASSEMBLY OF MOTOR BRAKE ..... 6 - 6
ASSEMBLY OF MOTOR BRAKE ..... 6 - 6
STANDARD AXLE BRAKE ..... 6 - 8
BAND BRAKE ADJUSTMENT ..... 6 - 9
BAND BRAKE CYLINDER ..... 6 - 10
HEAVY DUTY AXLE BRAKE ..... 6 - 11


MidWestTech | JCB Vibromax 1103 Single Drum Roller Service Manual | Publication SM90... Order the manual at mid-west-tech.com >

FLUID SPECIFICATIONS

MACHINE PART	CAPACITY USA (metric)	SPECIFICATIONS
Fuel tank	74 gal (280 l)	see diesel fuel
Engine crankcase	15 qts(14.2 l)	engine oil API classification API-CD MIL-L-2104C multigrade engine oil (see oil chart) single grade engine oil (see oil chart)
Hydraulic system Reservoir only	29.1 gal (110 l) 18.5 gal (70 l)	cold weather HLP 46 DIN 51524/2 hot weather HLP 68 DIN 51524/2 Mobil DTE 25,26 Shell Tellus OL 46,68 Amoco Rykon HD 46,68 Texaco Rando HD 46,68
Vibration system	12.7 qts. (12 l)	CLP DIN 51517/3 Mobil Gear 629 Shell Omala 150 Texaco Meropa 150
Battery	as required	Distilled water
Grease	as required	KP3K DIN 51502 Mobil Oil - Mobilux 3 Shell Oil - Alvania 3 Texaco Oil - Starplex 3
Engine coolant	20 qts (19 l)	50% ethylene glycol and 50% water
Tire ballast	see chart	Calcium Chloride (77%$CaCl^2$)
Intermediate gear standard duty heavy duty Axle gear standard duty heavy duty Planetary gear standard duty heavy duty	 1.1 qts (1 ltr) 1.6 qts (1.5 ltr) 5.3 qts (5 ltr) 14.8 qts (14 ltr) 2.2 qts (2 ltr) 1.9 qts (1.8 ltr)	SAE 90 API GL-5 gear lubricant

MidWestTech | JCB Vibromax 1103 Single Drum Roller Service Manual | Publication SM90... Order the manual at mid-west-tech.com >

UNDERSTANDING ELECTRICAL SCHEMATICS



MidWestTech | JCB Vibromax 1103 Single Drum Roller Service Manual | Publication SM90... Order the manual at mid-west-tech.com >

REAR AXLE INSTALLATION


1. Position the axle under the machine frame rails. Install and tighten the axle bolts to 295 ft lbs. (400 Nm.).

2. Install both wheels with snug wheel lug nuts.

3. Remove the jack support stands from under the machine and allow the machine to sit on the ground.

4. Tighten and torque the wheel nuts to 288 ft lbs. (390 Nm.).
   NOTE: Re-tighten the wheel nuts every 8 hours until nut torque stabilizes.

Wheel torquing sequence



5. Reconnect the hydraulic lines to the axle drive motor. Use tie straps to group the hoses.
   NOTE: Be sure to fill the hydraulic motor case with oil!

6. Reconnect the electrical plug on the two speed valve.

7. Install the brake lever into the brake cylinder yoke and install the pin. Secure the pin with a new split pin.

8. Adjust the brake using the setting screw. The proper setting is measured between the cylinder end cap and the end of the cylinder rod. This measurement should be 1.0 inch (25.4 mm).

9. Refill the hydraulic reservoir with 18.5 gallons (70 liters) of filtered hydraulic fluid.

10. Fill the planetary drives with SAE 90 API GL-5 oil until it flows from the filler plug hole in the planetary drive hub. Be certain that the drain plug in the hub is located at the bottom of rotation during filling.

MidWestTech | JCB Vibromax 1103 Single Drum Roller Service Manual | Publication SM90... Order the manual at mid-west-tech.com >