TEN00062-04

Operation & Maintenance Manual

HYDRAULIC
EXCAVATOR

PC09-1

SERIAL NUMBERS 12001 and up

WARNING

Unsafe use of this machine may cause serious injury or death. Operators and maintenance personnel must read this manual before operating or maintaining this machine. This manual should be kept near the machine for reference and periodically reviewed by all personnel who will come into contact with it.

NOTICE

Komatsu has Operation & Maintenance Manuals written in some other languages. If a foreign language manual is necessary, contact your local distributor for availability.

KOMATSU®

MidWestTech | Komatsu PC09-1 Hydraulic Excavator Operation & Maintenance Manual | P... Order the manual at mid-west-tech.com >

CONTENTS

FOREWORD 1- 1
FOREWORD 1- 2
SAFETY INFORMATION 1- 5
INTRODUCTION 1- 7
DIRECTIONS OF MACHINE 1- 7
PRODUCT INFORMATION 1- 8
PRODUCT IDENTIFICATION NUMBER (PIN)/MACHINE SERIAL NO. PLATE 1- 8
ENGINE SERIAL NUMBER PLATE AND ITS LOCATION 1- 8
EMISSION CONTROL INFORMATION LABEL AND ITS LOCATION 1- 9
SERVICE METER LOCATION 1- 9
YOUR MACHINE SERIAL NUMBERS AND DISTRIBUTOR 1- 10
SAFETY 2- 1
SAFETY 2- 2
SAFETY LABELS 2- 4
LOCATION OF SAFETY LABELS 2- 4
SAFETY LABELS 2- 5
GENERAL PRECAUTIONS 2- 8
SAFETY MACHINE OPERATION 2- 16
STARTING ENGINE 2- 16
OPERATION 2- 17
TRANSPORTATION 2- 24
BATTERY 2- 25
TOWING 2- 27
LIFTING OBJECTS WITH BUCKET 2- 28
SAFETY MAINTENANCE INFORMATION 2- 29
OPERATION 3- 1
MACHINE VIEW ILLUSTRATIONS 3- 2
OVERALL MACHINE VIEW 3- 2
CONTROLS AND GAUGES 3- 3
DETAILED CONTROLS AND GAUGES 3- 4
METERS, LAMPS 3- 4
SWITCHES 3- 6
CONTROL LEVERS AND PEDALS 3- 8
VARIABLE BLADE 3- 15
ENGINE HOOD 3- 15
FUSE 3- 16
BLOCK FUSE 3- 16
OPERATION MANUAL STORAGE 3- 17
MACHINE OPERATIONS AND CONTROLS 3- 18
BEFORE STARTING ENGINE 3- 18
STARTING ENGINE 3- 29
AFTER STARTING ENGINE 3- 32
STOPPING THE ENGINE 3- 35
CHECK AFTER SHUT OFF ENGINE 3- 35
MACHINE OPERATION 3- 36
STEERING THE MACHINE 3- 40
SWINGING 3- 42
WORK EQUIPMENT CONTROLS AND OPERATIONS 3- 43
PROHIBITED OPERATIONS 3- 45

MidWestTech | Komatsu PC09-1 Hydraulic Excavator Operation & Maintenance Manual | P... Order the manual at mid-west-tech.com >


GENERAL OPERATION INFORMATION ---- 3- 48
TRAVELING ON SLOPES ---- 3- 49
ESCAPE FROM MUD ---- 3- 51
WORK POSSIBLE USING COMPACT HYDRAULIC EXCAVATOR ---- 3- 52
BUCKET REPLACEMENT ---- 3- 54
PARKING MACHINE ---- 3- 56
MACHINE INSPECTION AFTER DAILY WORK ---- 3- 57
RUBBER SHOES (MACHINE WITH RUBBER SHOES ONLY) ---- 3- 58
TRANSPORTATION ---- 3- 63
TRANSPORTATION PROCEDURE ---- 3- 63
LOADING AND UNLOADING WITH TRAILER ---- 3- 63
LIFTING MACHINE ---- 3- 65
SHIPPING MACHINE INFORMATION ---- 3- 67
COLD WEATHER OPERATION ---- 3- 68
COLD WEATHER OPERATION INFORMATION ---- 3- 68
AFTER DAILY WORK COMPLETION ---- 3- 70
AFTER COLD WEATHER SEASON ---- 3- 70
LONG TERM STORAGE ---- 3- 71
BEFORE STORAGE ---- 3- 71
DURING STORAGE ---- 3- 71
AFTER STORAGE ---- 3- 71
STARTING MACHINE AFTER LONG-TERM STORAGE ---- 3- 71
TROUBLES AND ACTIONS ---- 3- 72
RUNNING OUT OF FUEL ---- 3- 72
PHENOMENA THAT ARE NOT FAILURES ---- 3- 72
TOWING THE MACHINE ---- 3- 73
SEVERE JOB CONDITION ---- 3- 73
DISCHARGED BATTERY ---- 3- 74
OTHER TROUBLE ---- 3- 78
MAINTENANCE ---- 4- 1
MAINTENANCE INFORMATION ---- 4- 2
OUTLINE OF SERVICE ---- 4- 4
HANDLING OIL, FUEL, COOLANT, AND PERFORMING OIL CLINIC ---- 4- 4
ELECTRIC SYSTEM MAINTENANCE ---- 4- 7
WEAR PARTS ---- 4- 8
WEAR PARTS LIST ---- 4- 8
LUBRICANTS, FUEL AND COOLANT SPECIFICATIONS ---- 4- 9
PROPER SELECTION ---- 4- 9
TIGHTENING TORQUE SPECIFICATIONS ---- 4- 13
TIGHTENING TORQUE LIST ---- 4- 13
SAFETY CRITICAL PARTS ---- 4- 14
SAFETY CRITICAL PARTS LIST ---- 4- 14
MAINTENANCE SCHEDULE ---- 4- 15
MAINTENANCE SCHEDULE CHART ---- 4- 15
MAINTENANCE INTERVAL FOR HYDRAULIC BREAKER ---- 4- 16
MAINTENANCE PROCEDURE ---- 4- 17
INITIAL 250 HOURS MAINTENANCE (ONLY AFTER THE FIRST 250 HOURS) ---- 4- 17
WHEN REQUIRED ---- 4- 18
CHECK BEFORE STARTING ---- 4- 33
EXPLANATION OF SYMBOLS FOR LUBRICATION STANDARD TABLE ---- 4- 33

MidWestTech | Komatsu PC09-1 Hydraulic Excavator Operation & Maintenance Manual | P... Order the manual at mid-west-tech.com >

EVERY 100 HOURS MAINTENANCE ---- 4- 34
EVERY 250 HOURS MAINTENANCE ---- 4- 35
EVERY 500 HOURS MAINTENANCE ---- 4- 40
EVERY 1000 HOURS MAINTENANCE ---- 4- 47
EVERY 2000 HOURS MAINTENANCE ---- 4- 48
SPECIFICATIONS ---- 5- 1
SPECIFICATIONS ---- 5- 2
ATTACHMENTS AND OPTIONS ---- 6- 1
ATTACHMENTS AND OPTIONS - GENERAL INFORMATION ---- 6- 2
SAFETY FIRST ---- 6- 2
ATTACHMENT INSTALLATION ---- 6- 3
BUCKET WITH HOOK ---- 6- 4
HOOK CONDITION ---- 6- 4
PROHIBITED OPERATIONS ---- 6- 4
ATTACHMENT GUIDE ---- 6- 5
ATTACHMENT COMBINATIONS ---- 6- 5
HANDLING ARM WITH BUILT-IN BREAKER ---- 6- 6
BUCKET POSTURE ---- 6- 6
REMOVING AND INSTALLING CHISEL ---- 6- 6
PROCEDURE FOR BREAKER OPERATIONS ---- 6- 7
PRECAUTIONS WHEN CARRYING OUT BREAKER OPERATIONS ---- 6- 8
STOWING CHISEL, DUMMY CHISEL ---- 6- 9
PRECAUTIONS WHEN CARRYING OUT BUCKET OPERATIONS ---- 6- 9
HANDLING DUMMY LINK ---- 6- 10
CHECK BEFORE STARTING ---- 6- 11
SPECIFICATIONS ---- 6- 12
HANDLING BUCKET COUPLER ---- 6- 13
PROCEDURE FOR REMOVING BUCKET ---- 6- 13
PROCEDURE FOR INSTALLING BUCKET ---- 6- 15
HANDLING FOLDING TOPS CANOPY ---- 6- 17
RECOMMENDED ATTACHMENT OPERATIONS ---- 6- 19
HYDRAULIC BREAKER ---- 6- 19
INDEX ---- 7- 1

MidWestTech | Komatsu PC09-1 Hydraulic Excavator Operation & Maintenance Manual | P... Order the manual at mid-west-tech.com >

CONTROLS AND GAUGES



(1) Operator's seat
(2) Control pedal
(3) Lock lever
(4) Fuel control dial
(5) Left work equipment control lever
(6) Travel levers
(7) Horn switch
(8) Right work equipment control lever
(9) Blade control lever
(10) Swing lock lever
(11) Pedal lock
(12) Boom swing control pedal
(13) Engine oil pressure lamp
(14) Engine coolant temperature lamp
(15) Pre-heating monitor
(16) Service meter
(17) Variable gauge lever

MidWestTech | Komatsu PC09-1 Hydraulic Excavator Operation & Maintenance Manual | P... Order the manual at mid-west-tech.com >

MAINTENANCE PROCEDURE

INITIAL 250 HOURS MAINTENANCE (ONLY AFTER THE FIRST 250 HOURS)


Perform the following maintenance only after the first 250 hours.

- REPLACE FUEL FILTER ELEMENT
- REPLACE ENGINE OIL FILTER CARTRIDGE
- CHECK ENGINE VALVE CLEARANCES, ADJUST
  Special tools are needed for inspection and maintenance, so contact your Komatsu distributor.

For details of the method of maintaining, see EVERY 500 HOURS MAINTENANCE.

MidWestTech | Komatsu PC09-1 Hydraulic Excavator Operation & Maintenance Manual | P... Order the manual at mid-west-tech.com >

	Working ranges	Unit	PC09-1
A	Max. digging reach	mm (ft in)	2840 (9' 4")
B	Max. digging depth	mm (ft in)	1465 (4' 10")
C	Max. digging height	mm (ft in)	2825 (9' 3")
D	Max. vertical wall depth	mm (ft in)	1135 (3' 9")
E	Max. dumping height	mm (ft in)	2025 (6' 8")
F	Max. reach at ground level	mm (ft in)	2840 (9' 4")
G	Max. blade lifting height	mm (ft in)	180 (0' 7")
H	Max. blade lowering depth	mm (ft in)	115 (0' 5")



Order the manual at mid-west-tech.com >