TEN00330-02

Operation & Maintenance Manual

BULLDOZER

D65EX -16
D65PX -16
D65WX -16

SERIAL NUMBERS 80001 and up

ecot3

WARNING

Unsafe use of this machine may cause serious injury or death. Operators and maintenance personnel must read this manual before operating or maintaining this machine. This manual should be kept near the machine for reference and periodically reviewed by all personnel who will come into contact with it.

NOTICE

Komatsu has Operation & Maintenance Manuals written in some other languages. If a foreign language manual is necessary, contact your local distributor for availability.

KOMATSU®


MidWestTech | Komatsu D65EX-16, D65PX-16, D65WX-16 Bulldozer Operation & Maintena... Order the manual at mid-west-tech.com >

DOOR - OPEN LOCK ---- 3- 69
SASH GLASS INTERMEDIATE LOCK ---- 3- 69
DOOR POCKET ---- 3- 70
ASHTRAY ---- 3- 70
SHOVEL HOLDER ---- 3- 70
CAR RADIO, HANDLING ---- 3- 71
AIR CONDITIONER, HANDLING ---- 3- 76
OPERATION ---- 3- 90
CHECK BEFORE STARTING ENGINE, ADJUST ---- 3- 90
STARTING ENGINE ---- 3-111
OPERATIONS AND CHECKS AFTER STARTING ENGINE ---- 3-115
STOPPING ENGINE ---- 3-119
MACHINE OPERATION ---- 3-120
SHIFTING GEARS ---- 3-123
SHIFTING BETWEEN FORWARD AND REVERSE ---- 3-130
STEERING MACHINE ---- 3-131
PRECAUTIONS FOR OPERATION ---- 3-133
WORK POSSIBLE USING BULLDOZER ---- 3-136
RECOMMENDED MODE FOR EACH TYPE OF OPERATION ---- 3-138
ADJUSTING POSTURE OF WORK EQUIPMENT ---- 3-140
PARKING MACHINE ---- 3-149
CHECK AFTER FINISHING WORK ---- 3-151
LOCKING ---- 3-152
TIPS FOR LONGER UNDERCARRIAGE LIFE ---- 3-153
TRANSPORTATION ---- 3-156
TRANSPORTATION MEANS ---- 3-156
PRECAUTIONS WHEN REMOVING WORK EQUIPMENT ---- 3-156
LOADING, UNLOADING WORK ---- 3-157
LIFTING MACHINE ---- 3-160
TRAVELING ON ROADS ---- 3-162
COLD WEATHER OPERATION ---- 3-163
PRECAUTIONS FOR LOW TEMPERATURE ---- 3-163
AFTER COMPLETION OF WORK ---- 3-164
AFTER COLD WEATHER ---- 3-164
LONG-TERM STORAGE ---- 3-165
BEFORE STORAGE ---- 3-165
DURING STORAGE ---- 3-165
AFTER STORAGE ---- 3-165
STARTING MACHINE AFTER LONG-TERM STORAGE ---- 3-165
TROUBLESHOOTING ---- 3-166
AFTER RUNNING OUT OF FUEL ---- 3-166
METHOD OF TOWING MACHINE ---- 3-167
IF BATTERY IS DISCHARGED ---- 3-168
OTHER TROUBLE ---- 3-172
MAINTENANCE ---- 4- 1
GUIDE TO MAINTENANCE ---- 4- 2
OUTLINE OF SERVICE ---- 4- 5
HANDLING OIL, FUEL, COOLANT, AND PERFORMING OIL CLINIC ---- 4- 5
RELATING TO ELECTRIC SYSTEM ---- 4- 8
HANDLING HYDRAULIC SYSTEM ---- 4- 9

MidWestTech | Komatsu D65EX-16, D65PX-16, D65WX-16 Bulldozer Operation & Main... Order the manual at mid-west-tech.com >

AIR CONDITIONER, HANDLING

GENERAL LOCATIONS OF CONTROL PANEL




(1) OFF switch
(2) Fan switch
(3) Temperature control switch
(4) Vent selector switch
(5) Auto switch
(6) FRESH/RECIRC selector switch
(7) Display monitor
(8) Air conditioner switch
(9) Sunlight sensor

OFF SWITCH

Switch (1) is used to stop the fan and air conditioner.

REMARK

Even if this switch (1) is pressed, the monitor screen does not switch to the air conditioner adjustment screen.



MidWestTech | Komatsu D65EX-16, D65PX-16, D65WX-16 Bulldozer Operation & Main... Order the manual at mid-west-tech.com >


CHECK WINDOW WASHER FLUID LEVEL, ADD FLUID

(Machine equipped with cab)

Perform this check when the window washer fluid does not come out.

Open the battery cover at the rear of the machine and check the level of the fluid in window washer tank (1). If it is low, add automobile window washer fluid.

When adding fluid, be careful not to let any dust get in.



PROPORTION FOR MIXING FLUID WITH WATER

The proportion differs according to the ambient temperature, so dilute the washer fluid with water to the following proportions before adding.

Area, season	Proportions	Freezing temperature
Normal	Washer fluid 1/3: water 2/3	-10°C (14°F)
Winter in cold area	Washer fluid 1/2 : water 1/2	-20°C (-4°F)
Winter in extremely cold area	Pure washer fluid	-30°C (-22°F)

There are two types depending on the freezing temperature:
-10°C (14°F) (general use) and -30°C (-22°F) (cold area use), select according to the area and season.

MidWestTech | Komatsu D65EX-16, D65PX-16, D65WX-16 Bulldozer Operation & Main... Order the manual at mid-west-tech.com >

EVERY 500 HOURS SERVICE

Maintenance for every 50 and 250 hours service should be carried out at the same time.

REPLACE AIR CONDITIONER FRESH/RECIRC FILTERS


REMARK


- Filtering capability of the filter can lower due to aging, so be sure to replace it with new one once a year.
- Clean the filter more frequently when the machine is used in a sandy district, bushy or grassy land, etc. where the filter is clogged easily.
- When cleaning, remove the external air filter and internal air filter according to the following procedure and clean with compressed air.
- If the filter is stained with oil or very dirty, wash it in neutral detergent.
- After washing the filter in water, dry it out before using.
- If the filter is so clogged that it cannot be cleaned with compressed air or water, replace it with new one.

REPLACING FRESH AIR FILTER

1. Open and lock inspection door (1) of the battery cover at the left rear of the machine.

2. Loosen knob (2) and remove top cover (3).





MidWestTech | Komatsu D65EX-16, D65PX-16, D65WX-16 Bulldozer Operation & Main... Order the manual at mid-west-tech.com >