Perkins

Perkins 100 Series

Models 102-05, 103-07, 103-10, 103-13, 103-15, 104-19, 104-22

WORKSHOP MANUAL

102-05	Two cylinder diesel engines
103-07 103-10 103-13 103-15	Three cylinder diesel engines
104-19 104-22	Four cylinder diesel engines

Publication TPD 1377E, Issue 3
© Proprietary information of Perkins Engines Company Limited, all rights reserved.
The information is correct at the time of print.
Published in March 2002 by Technical Publications.

MidWestTech | JCB Perkins 100 Series 102-05, 103-07, 103-10, 103-13, 103-15, 104-19, 10... Order the manual at mid-west-tech.com >

Contents

1 General information

Introduction ... 1

Safety precautions ... 2

Engine preservation ... 4

POWERPART recommended consumable products ... 5

Engine I.D. location ... 6

Engine views - 3 cylinder front and rear ... 7

Engine views - 2 cylinder front and 4 cylinder front ... 8

Engine lift equipment ... 9

Viton seals ... 10

Compression test data ... 11

2 Specifications

Basic engine data ... 13

Recommended torque tensions ... 14

Data and dimensions ... 15

Injection timing ... 15

Cylinder bore dimensions ... 16

MidWestTech | JCB Perkins 100 Series 102-05, 103-07, 103-10, 103-13, 103-15, 104-1... Order the manual at mid-west-tech.com >

Piston and piston ring dimensions ... 17

Gudgeon pin ... 18

Crankshaft deflection ... 19

Crankshaft inspection ... 19

Crankshaft journal diameters ... 20

Crankshaft pin diameters ... 21

Bearing holder ... 22

Undersize bearing shell chart ... 23

Crankshaft bearing bush ... 24

3 Cylinder head assembly

Rocker cover and inlet manifold

Operation 3-1 To remove and to fit ... 25

Rocker assembly

Operation 3-2 To remove and to fit ... 26

Rocker shaft (102-05, 103-07, 103-10)

Operation 3-3 To dismantle, to inspect and to assemble ... 27

Rocker shaft (103-13, 103-15, 104-19, 104-22)

Operation 3-4 To dismantle, to inspect and to assemble ... 28

Fan and mounting

Operation 3-5 To remove ... 29

Coolant pump

Operation 3-6 To remove and to fit ... 30

Exhaust manifold and gasket

Operation 3-7 To remove and to fit ... 31

Fuel injection pipes / fuel return pipes

Operation 3-8 To remove and to fit ... 32

Oil pipes

Operation 3-9 To remove and to fit ... 33

MidWestTech | JCB Perkins 100 Series 102-05, 103-07, 103-10, 103-13, 103-15, 104-1... Order the manual at mid-west-tech.com >

Atomisers

Operation 3-10 To remove and to fit 34

Busbar / glowplugs

Operation 3-11 To remove and to fit 35

Cylinder head bolts

Operation 3-12 To remove and to fit 36

Cylinder head gasket

Operation 3-13 To remove and to fit 37

Cylinder head bolts - all variants

Operation 3-14 Tightening sequence 38

Valve and valve springs

Operation 3-15 To remove and to fit 39

Valve spring

Operation 3-16 To inspect 40

Valve stem diameter and thickness of valve head

Operation 3-17 To inspect 41

Valve guide clearance

Operation 3-18 To inspect 42

Cylinder head

Operation 3-19 To check the distortion of the lower face 43

Valve seat width

Operation 3-20 To correct 44

Valve depth

Operation 3-21 To correct 45

Valve seat contact face

Operation 3-22 Lapping 46

Valve tip clearance

Operation 3-23 To check 47

MidWestTech | JCB Perkins 100 Series 102-05, 103-07, 103-10, 103-13, 103-15, 104-1... Order the manual at mid-west-tech.com >

Cylinder bore dimensions

Engine model/Block specification	Bore dimension mm (in)	
	Standard	Service limit
102-05, 103-07		
New Block	67,000 - 67,019 (2.63780 - 2.63854)	67,2 (2.646)
1st oversize bore 0,5 mm (0.2 in)	67,500 - 67,519 (2.65750 - 2.65822)	67,7 (2.666)
2nd oversize bore 0,5 mm (0.2 in)	68,000 - 68,019 (2.67720 - 2.67791)	68,2 (2.685)
103-10		
New Block	75,000 - 75,019 (2.95280 - 2.95350)	75,2 (2.961)
1st oversize bore 0,5 mm (0.2 in)	75,500 - 75,519 (2.97244 - 2.97318)	75,7 (2.981)
2nd oversize bore 0,5 mm (0.2 in)	76,000 - 76,019 (2.99212 - 2.99287)	76,2 (2.999)
103-13, 103-15, 104-19, 104-22		
New Block	84,000 - 84,019 (3.30710 - 3.30783)	84,2 (3.315)
1st oversize bore 0,5 mm (0.2 in)	84,500 - 84,519 (3.32677 - 3.32751)	84,7 (3.335)
2nd oversize bore 0,5 mm (0.2 in)	85,000 - 85,019 (3.34650 - 3.34719)	85,2 (3.354)

Caution: *When service limits are exceeded following a second oversize bore operation, the block* ***must*** *be renewed.*

MidWestTech | JCB Perkins 100 Series 102-05, 103-07, 103-10, 103-13, 103-15, 104-1... Order the manual at mid-west-tech.com >

Wiring diagram 55 amp alternator - 103-15, 104-19, 104-22

Circuit	Cable number	Circuit current	Maximum circuit resistance	Maximum circuit volt drop	Remarks
Alternator charging	A A1 A11	55 amp	0.009 Ω	0.5 Volt	See Glow Plugs Circuit
Starter motor solenoid	A A2 A11	15.75 amp	0.04 Ω	0.63 Volt	See Glow Plugs Circuit
STD glow plugs (via glow signal)	A1 A5 A6 A7 A11	(Peak max) 39 amp (3 cyl) 52 amp (4 cyl)	0.0128 Ω (3 cyl)s 0.0096 Ω (4 cyl)s	0.5 Volt	

Wiring diagram maximum circuit resistance


The resistance of battery cables 1, 2 and 3 must not exceed 0.0018 Ω.

Note: Maximum cable size for 375 lucar terminals on the alternator is 65/0,3 mm (4,5 mm^2) therefore twin cables are required at the connection to the alternator.

1 Alternator warning lamp
2 Alternator
3 Battery
4 Starter motor
5 Oil pressure warning lamp
6 Oil pressure switch (1)
7 Water temperature warning lamp
8 Thermostat switch
9 Key switch
10 Glow signal
11 Glow plugs
12 Fuse
13 Solenoid switch
14 A delayed fuse can be fitted if desired

(1) Max current draw for standard oil pressure switch is 0.42 amps (5 Watt lamp max).

→|← = Diode. Capacity: Current 3 amp. Reverse Voltage: 600V. **(This is mandatory)**.



MidWestTech | JCB Perkins 100 Series 102-05, 103-07, 103-10, 103-13, 103-15, 104-1... Order the manual at mid-west-tech.com >

Auto shutdown wiring diagram 40 amp alternator - 103-15, 104-19, 104-22

Auto shutdown operation symptoms

If the conditions below last for more than 10 seconds during the start operation, the engine will shut down.

If the conditions below last for more than 2 seconds while the engine is operated, the engine will shut down.

Warning! *There is no protection against low water levels.*

Conditions


Water temperature switch: If the water temperature exceeds 105 °C ± 4 °C.

Oil Pressure Switch: If the oil pressure falls below 0,3 kgf/cm² (4.27 lbf/in²).

1 Alternator warning lamp
2 Alternator
3 Battery
4 Starter motor
5 Oil pressure warning lamp
6 Oil pressure switch (1)
7 Water temperature warning lamp
8 Thermostat switch
9 Key switch
10 Glow signal
11 Glow plugs
12 Fuse
13 Solenoid switch
14 Auto shutdown device
15 A delayed fuse can be fitted if desired

(1) Max current draw for standard oil pressure switch is 0.42 amps (5 Watt lamp max).

— ▶| — = Diode. Capacity: Current 3 amp. Reverse Voltage: 600V. **(This is mandatory)**.



MidWestTech | JCB Perkins 100 Series 102-05, 103-07, 103-10, 103-13, 103-15, 104-1... Order the manual at mid-west-tech.com >