PART NO. TTCGB-E-00

HITACHI

Technical Manual

Troubleshooting

ZAXIS

170W-3
190W-3

Wheeled Excavator

Service Manual consists of the following separate Part No;

Technical Manual (Operational Principle)	: Vol. No.TOCGB-E
Technical Manual (Troubleshooting)	: Vol. No.TTCGB-E
Workshop Manual	: Vol. No.WCGB-E

MidWestTech | Hitachi Zaxis 170W-3, 190W-3 Wheeled Excavator Troubleshooting Technic... Order the manual at mid-west-tech.com >

SECTION 4

OPERATIONAL PERFORMANCE TEST



CONTENTS

Group 1 Introduction

Operational Performance Tests T4-1-1
Preparation for Performance Tests T4-1-2

Group 2 Standard

Performance Standard (ZX170W-3) T4-2-1
Performance Standard (ZX190W-3) T4-2-6
Main Pump P-Q Diagram T4-2-12
Sensor Activating Range T4-2-14

Group 3 Engine Test

Engine Speed T4-3-1
Engine Compression Pressure T4-3-4
Valve Clearance T4-3-6
Lubricant Consumption T4-3-9

Group 4 Excavator Test

Travel Speed T4-4-1
Brake Control Function T4-4-3
Parking Brake Control Function T4-4-4
Swing Speed T4-4-5
Swing Function Drift Check T4-4-6
Swing Motor Leakage T4-4-8
Maximum Swingable Slant Angle T4-4-9
Swing Bearing Play T4-4-10
Hydraulic Cylinder Cycle Time T4-4-12
Hydraulic Cylinder Drift Check T4-4-14
Control Lever Operating Control Force T4-4-15
Control Lever Stroke T4-4-16
Combined Operation Boom Raise/Swing Function Check T4-4-17


Group 5 Component Test

Primary Pilot Pressure T4-5-1
Secondary Pilot Pressure T4-5-3
Solenoid Valve Set Pressure T4-5-4
Main Pump Delivery Pressure T4-5-6
Main Relief Set Pressure T4-5-8
Relief Pressure (When relieving Swing) T4-5-10
Overload Relief Valve Set Pressure T4-5-12
Main Pump Flow Rate Measurement T4-5-14
Swing Motor Drainage T4-5-24
Travel Motor Drainage T4-5-26
Steering Valve Relief Pressure T4-5-28
Brake Pressure (Front and Rear) T4-5-30
Brake Accumulated Pressure T4-5-32
Brake Warning Set Pressure (Decrease) T4-5-34
Brake Warning Set Pressure (Increase) T4-5-36


MidWestTech | Hitachi Zaxis 170W-3, 190W-3 Wheeled Excavator Troubleshooting Tec... Order the manual at mid-west-tech.com >

- Option Controller
  Between CAN Circuit (Low Side) and Power Circuit
  - Check for continuity between terminal #C22 (harness end) of connector C and terminal #A1 (harness end) of connector A.
  - Check for continuity between terminal #C22 (harness end) of connector C and terminal #A12 (harness end) of connector A.
  - Check for continuity between terminal #C22 (harness end) of connector C and terminal #B7 (harness end) of connector B.
  - Check for continuity between terminal #C22 (harness end) of connector C and terminal #B17 (harness end) of connector B.
  - Check for continuity between terminal #C22 (harness end) of connector C and terminal #B24 (harness end) of connector B.


Connector
Connector C
(Harness end)



Connector A
(Harness end)



Connector B
(Harness end)



MidWestTech | Hitachi Zaxis 170W-3, 190W-3 Wheeled Excavator Troubleshooting Tec... Order the manual at mid-west-tech.com >

TROUBLESHOOTING B PROCEDURE

Apply troubleshooting B procedure when no fault code is displayed on the service menu (built-in diagnosing system) in monitor unit and the diagnosing by Dr. ZX although the machine operation is abnormal. When the fault code is displayed, refer to the troubleshooting A group and diagnose.
On the front section pages of this group are the tables indicating the relationship between machine trouble symptoms and related parts which may cause such trouble if failed.
Start the troubleshooting with more probable causes selected by referring to these tablesHow to Read the Troubleshooting Flow Charts

- How to read troubleshooting flowchart



- After checking or measuring item (1), select either YES (OK) or NO (NOT OK) and proceed to item (2) or (3), as appropriate.



- Special instructions or reference item are indicated in the spaces under the box. Incorrect measuring or checking methods will render troubleshooting impossible, and may damage components as well.

Key switch: ON



- Explanation of how to use test harness kit required. Refer to "Electrical System Inspection" Group (Group 8) in this section.




- Use the service menu (built-in diagnosing system) in the monitor unit or the diagnosing system / monitor function in Dr. ZX.




- Causes are stated in a thick-line box. Scanning through thick-line boxes, possible causes can be seen without going through the flow chart.


NOTE: For all connector shown in this group, harness end connector viewed from the open end side are shown




MidWestTech | Hitachi Zaxis 170W-3, 190W-3 Wheeled Excavator Troubleshooting Tec... Order the manual at mid-west-tech.com >



Connector MC-B




Connector ICF-C



MidWestTech | Hitachi Zaxis 170W-3, 190W-3 Wheeled Excavator Troubleshooting Tec... Order the manual at mid-west-tech.com >

NOTE: If the measure pressures for all functions are lower than the specified range, the probable cause is a decrease of the main relief valve setting pressure.
If the relief pressure of a particular function is lower, the probable cause is other than main relief valve.




T16W-05-03-932

Main Relief Pressure Setting Adjustment Procedure

Adjustment:


1. Loosen lock nut (1).
   : 17 mm
   : 19.5 N·m (2 kgf·m, 14.5 lbf·ft)
2. Turn adjusting screw (2) to adjust the main relief set pressure referring to the table below.
3. Retighten lock nut (1).
4. Recheck the set pressures.



T17B-03-03-210

NOTE: Standard Change in Pressure (Reference)

Plug Turns		1/4	1/2	3/4	1
Change in Relief Pressure	MPa	2.79	5.59	8.36	11.2
	(kgf/cm^2)	(28.5)	(57)	(85.2)	(114)
	(psi)	(405)	(811)	(1212)	(1620)




T10B-08-05-902

MidWestTech | Hitachi Zaxis 170W-3, 190W-3 Wheeled Excavator Troubleshooting Tec... Order the manual at mid-west-tech.com >

Attach to Vol. No.: TTCEB-E-00, TTCGB-E-00, TTCJB-E-00

ZAXIS140W-3/170W-3/190W-3/210W-3/220W-3 ELECTRICAL CIRCUIT DIAGRAM (STANDARD)

CAUTION: Parts numbers on the drawing are provided only for reference purpose.
To order parts on the drawing,be sure to consult the Parts Catalog.



Order the manual at mid-west-tech.com >