FC 30
Poclain

Operators Manual

W00-440-65

Reprinted

CASE
CONSTRUCTION

MidWestTech | Case FC 30 Poclain Excavator Operator's Manual | Publication W00-440-65

Order the manual at mid-west-tech.com >

INDEX

A CHARACTERISTICS

		Page
1	Identification of machine	5
2	Identification of main components	5
3	General dimensions	7
4	General data	7
5	Description	8

B OPERATION

1	Cab control equipment	9
2	Cab ventilation and heating system	13
4	Opening and closing the cowling	13
5	Tool compartment	13
10	Pre-operation inspection	13
11	Refueling	14
12	Daily pre-operation checks	14
13	Starting and operating the engine	14
14	Stopping the engine	14
16	Operating the excavator	14
17	Signalling equipment and power line connection	15
19	Operating the excavator at low temperatures	15
30	Installing the upperstructure lock bar	16
31	Transporting the excavator	16
35	Storage instructions - over 30 days	17
40	Hints on operation and operator	17

C SAFETY

1	When working	19
2	Walking up to the operator under operation	19
3	Loading the machine on a low-bed trailer or railcar	20
4	Before traveling	20
5	When traveling	20
6	When waiting	20
7	When servicing or repairing the unit	20

D MAINTENANCE

I	Hourmeter	23
II	Lubricants	23
III	Cleanliness in service operations	23
IV	Fuel	24
V	Break-in period	24

1	Hydraulic fluid reservoir	24
2	Suction strainer	25
3	Magnetic filter	25
4	Cartridge-type LP oil filters	25
10	Engine crankcase	26
11	Engine oil filter	26
12	Engine air cleaner	27
19	Fuel filter	27
20	Fuel filter	28
21	Fuel injection pump	28
25	Engine rocker arms	29

MidWestTech | Case FC 30 Poclain Excavator Operator's Manual | Publication W00-440-65 Order the manual at mid-west-tech.com >

INDEX

28	Engine cooling fins	29
31	Generator drive belt	30
41	Hydraulic pump drive belts	30
50	Batteries	30
65	Swing joint	31
66	Swing gear	31
67	Swing gear teeth	31
75	Final drive housings	32
76	Track rollers and front idler wheels	32
114	Special "Heavy Duty" air cleaners (optional)	33

E HYDRAULIC SYSTEM

1	Troubleshooting chart	35
2	Fluid reservoir	39
3	Pumps	40
4	Cylinders and gland packing	40
5	Operational speeds	41
6	Performance	41
7	Valve pressure setting (Main regulators)	43
8	Relief valves	43
20	Flexible hoses	44
21	Connections	45
22	Piping	46

F MECHANICAL COMPONENTS

1	Engine troubleshooting table	47
2	Hardware	49
3	Bleeding and priming the fuel system	49
4	Engine maintenance	49
6	Engine oil consumption	50
7	Drive belt on engine	50
9	Hydraulic pump drive belts	51
	TRACK ASSEMBLY	51
15	Cleaning the track assembly	51
16	Replacing a track pad	51
17	Replacing the track assembly	51
18	Tensioning the tracks	53
19	Replacing a track roller	53

G ELECTRICAL SYSTEM

1	Generator and regulator	56
3	Starting motor	55
5	Warning light bulbs	55
12	Working light	55
15	Fuses	55
16	Windshield wiper	55

MidWestTech | Case FC 30 Poclain Excavator Operator's Manual | Publication W00-440-65 Order the manual at mid-west-tech.com >

INDEX

J FRONT LOADER ATTACHMENT

1 Selection . . . 3
2 Application . . . 4
3 Maintenance . . . 5
4 Removal-Installation . . . 6
– Bucket . . . 7
– Attachment . . . 7

K BACKHOE ATTACHMENT

1 Selection . . . 9
– Trenching . . . 10
– Earthmoving, excavating . . . 11
– Ditching, ditch-cleaning . . . 12
– Ripping, stumping, backfilling . . . 13

2 Application . . . 14
3 Maintenance . . . 15
4 Removal-Installation . . . 16
– Bucket . . . 17
– Ejector plate . . . 17
– Dippersticks . . . 17
– Boom . . . 18

L CLAMSHELL ATTACHMENT

1 Selection . . . 19
– Trenching . . . 20
– Earthmoving . . . 20
– Boring . . . 21

2 Application . . . 21
3 Maintenance . . . 23
4 Removal-Installation . . . 24
– Clamshell . . . 25
– Dippersticks . . . 25
– Boom . . . 25

M REHANDLING ATTACHMENT

1 Selection . . . 27
– Lifting hook, rehandling jib . . . 28
– Crane jib . . . 28
– Lifting fork . . . 29

2 Application . . . 29
3 Maintenance . . . 35
4 Removal-Installation . . . 36
– Rehandling jib . . . 36
– Dippersticks . . . 36
– Boom . . . 37
– Hoist cable . . . 37
– Jib extension . . . 37
– Attachment . . . 38

MidWestTech | Case FC 30 Poclain Excavator Operator's Manual | Publication W00-440-65 Order the manual at mid-west-tech.com >