PART NO. WDAS50-EN-00

HITACHI

Reliable solutions

Workshop Manual

ZX
135US-6
Hydraulic Excavator

Service Manual consists of the following separate Part No.

Technical Manual (Operational Principle)	: Vol. No.TODAS50-EN
Technical Manual (Troubleshooting)	: Vol. No.TTDAS50-EN
Workshop Manual	: Vol. No.WDAS50-EN
Engine Manual	: Vol. No.EDBR50-EN

MidWestTech | Hitachi ZX135US-6 Excavator Workshop Service Manual | Publication WDAS50-EN-00

Order the manual at mid-west-tech.com >

SECTION 1

GENERAL

CONTENTS

Group 1 Precautions for Disassembling and Assembling

Precautions for Disassembling and Assembling W1-1-1-1

Group 2 Tightening

Tightening Bolts and Nuts W1-2-1-1
Piping Joint W1-2-1-4

Group 3 Painting

Painting W1-3-1-1

Group 4 Bleeding Air

Bleeding Air from Hydraulic System W1-4-1-1
Bleeding Air from Fuel System W1-4-1-2
Air Bleeding from the DEF Defrosting Piping W1-4-1-4

Group 5 Preparation

Preparation before Inspection and Maintenance W1-5-1-1
Hydraulic Circuit Pressure Release Procedure W1-5-1-3
Pressure Release from Hydraulic Oil Tank W1-5-1-4
Pressure Release from Expansion Tank W1-5-1-5

MidWestTech | Hitachi ZX135US-6 Excavator Workshop Service Manual | Publication... Order the manual at mid-west-tech.com >

SECTION 2

MAINTENANCE STANDARD

CONTENTS

Group 1 Upperstructure

Pump Device W2-1-1-1
Swing Motor W2-1-2-1
Swing Parking Brake W2-1-2-3

Group 2 Undercarriage

Travel Motor W2-2-1-1
Parking Brake W2-2-1-3
Sprocket W2-2-1-4
Front Idler W2-2-2-1
Upper Roller W2-2-3-1
Lower Roller W2-2-3-2
Track W2-2-4-1

Group 3 Front Attachment

Pin and Bushing W2-3-1-1
Side Cutter (2015428, 2015429) W2-3-1-3
Point (963228) W2-3-1-4
Standard Dimensions for Arm and Bucket Connection W2-3-1-5
Standard Dimensions for Arm and Boom Connection W2-3-1-6
Cylinder W2-3-2-1

MidWestTech | Hitachi ZX135US-6 Excavator Workshop Service Manual | Publication... Order the manual at mid-west-tech.com >

SECTION 3

UPPERSTRUCTURE

CONTENTS

Group 1 Cab
Removal and Installation of Cab W3-1-1-1
Dimensions of Cab Glass W3-1-2-1

Group 2 Counterweight
Removal and Installation of Counterweight W3-2-1-1

Group 3 Main Frame
Removal and Installation of Main Frame W3-3-1-1

Group 4 Engine
Removal and Installation of Engine W3-4-1-1

Group 8 Pump Device
Removal and Installation of Pump Device W3-8-1-1
Removal and Installation of Coupling W3-8-2-1
Disassembly of Pump Device W3-8-3-1
Assembly of Pump Device W3-8-3-8
Disassembly of Regulator W3-8-4-1
Assembly of Regulator W3-8-4-3
Disassembly of Solenoid Valve Unit W3-8-5-1
Assembly of Solenoid Valve Unit W3-8-5-3
Structure of Pilot Pump and Blade Pump W3-8-6-1

Group 9 Control Valve
Removal and Installation of Control Valve W3-9-1-1
Removal and Installation of Blade Control Valve W3-9-2-1
Disassembly of Housing W3-9-3-1
Assembly of Housing W3-9-3-3
Disassembly of A-Side Control Valve W3-9-4-1
Assembly of A-Side Control Valve W3-9-4-9
Disassembly of B-Side Control Valve W3-9-5-1
Assembly of B-Side Control Valve W3-9-5-12
Disassembly of Blade Control Valve W3-9-6-1
Assembly of Blade Control Valve W3-9-6-3

Group 10 Swing Device
Removal and Installation of Swing Device W3-10-1-1
Disassembly of Swing Reduction Gear W3-10-2-1
Assembly of Swing Reduction Gear W3-10-2-6
Disassembly of Swing Motor W3-10-3-1
Assembly of Swing Motor W3-10-3-4
Disassembly of Valve Unit W3-10-4-1
Assembly of Valve Unit W3-10-4-3

Group 11 Pilot Valve
Removal and Installation of Pilot Valve (Left) W3-11-1-1
Removal and Installation of Pilot Valve (Right) W3-11-2-1
Removal and Installation of Travel Pilot Valve W3-11-3-1
Removal and Installation of Blade Pilot Valve W3-11-4-1
Disassembly of Pilot Valves (Right and Left) W3-11-5-1
Assembly of Pilot Valves (Right and Left) W3-11-5-4
Disassembly of Travel Pilot Valve W3-11-6-1
Assembly of Travel Pilot Valve W3-11-6-5
Disassembly of Blade and Positioning Pilot Valves W3-11-7-1
Assembly of Blade and Positioning Pilot Valves W3-11-7-4

Group 12 Solenoid Valve
Removal and Installation of Pilot Shut-Off Solenoid Valve W3-12-1-1
Removal and Installation of 4-Spool Solenoid Valve Unit W3-12-2-1
Removal and Installation of 2-Spool Solenoid Valve Unit W3-12-3-1
Removal and Installation of Maximum Pump 1 Flow Rate Limit Control Solenoid Valve W3-12-4-1
Disassembly of Pilot Shut-Off Solenoid Valve W3-12-5-1
Assembly of Pilot Shut-Off Solenoid Valve W3-12-5-3
Structure of 4-Spool Solenoid Valve Unit W3-12-6-1
Structure of 2-Spool Solenoid Valve Unit W3-12-7-1
Structure of Maximum Pump 1 Flow Rate Limit Control Solenoid Valve W3-12-8-1

Group 13 Signal Control Valve
Removal and Installation of Signal Control Valve W3-13-1-1
Structure of Signal Control Valve W3-13-2-1


Group 14 Aftertreatment Device
Removal and Installation of Aftertreatment Device W3-14-1-1

Group 15 DEF Tank
Removal and Installation of DEF Tank W3-15-1-1

Group 16 Coolant Control Valve
Removal and Installation of Coolant Control Valve W3-16-1-1

MidWestTech | Hitachi ZX135US-6 Excavator Workshop Service Manual | Publication... Order the manual at mid-west-tech.com >

Side Cutter (2015428, 2015429)



W1T1-04-01-004

Unit: mm


	Standard	Allowable Limit	Remedy
A	229	149	Replace
B	245	-	
C	330	-	
D	135	-	

MidWestTech | Hitachi ZX135US-6 Excavator Workshop Service Manual | Publication... Order the manual at mid-west-tech.com >



a: Lifting Bracket

WDAE-03-01-030



WDAE-03-01-016

CAUTION: The cab (1) assembly weight: 370 kg

16. Attach nylon slings onto lifting brackets (a) (4 places) of cab (1). Hoist the cab (1) assembly.
17. Install the cab (1) assembly to the main frame with washers (4) (4 used) and nuts (3) (4 used).
    - : 24 mm
    - : 210 N·m
18. Install washers (8) (2 used) and socket bolts (7) (2 used).
    - : 8 mm
    - : 50 N·m
19. Install the bolts, washers (2) (4 used).
    - : 17 mm
    - : 50 N·m
20. Install washers (6) (6 used) and socket bolts (5) (6 used).
    - : 8 mm
    - : 50 N·m
21. Install washers (13) and socket bolts (12).
    - : 8 mm
    - : 50 N·m

MidWestTech | Hitachi ZX135US-6 Excavator Workshop Service Manual | Publication... Order the manual at mid-west-tech.com >