WEAM007700

Operation & Maintenance Manual

GALEO

PC14R-2

HYDRAULIC EXCAVATOR

SERIAL NUMBER

PC14R-2 F00003 and up

WARNING

Unsafe use of this machine may cause serious injury or death. Operators and maintenance personnel must read this manual before operating or maintaining this machine. This manual should be kept near the machine for reference and periodically reviewed by all personnel who will come into contact with it.

NOTICE

Komatsu has Operation & Maintenance Manuals written in some other languages. If a foreign language manual is necessary, contact your local distributor for availability.

KOMATSU Utility

MidWestTech | Komatsu Galeo PC14R-2 Hydraulic Excavator Operation & Maintenance Ma... Order the manual at mid-west-tech.com >

TABLE OF CONTENTS

FOREWORD

1.1 FOREWORD 1

1.2 INFORMATION ON SAFETY 2

1.3 INTRODUCTION 4

1.3.1 INTENDED USE OF THE MACHINE 4
1.3.2 IMPROPER OR UNAUTHORIZED USES 4
1.3.3 MAIN CHARACTERISTICS 4
1.3.4 RUNNING-IN 5
1.3.5 POSITIONS AND DIRECTIONS OF THE MACHINE 5

1.4 PRODUCT IDENTIFICATION 6

1.4.1 MACHINE SERIAL NUMBER 6
1.4.2 MACHINE IDENTIFICATION PLATE AND PRODUCT IDENTIFICATION NUMBER (PIN) 6
1.4.3 ENGINE SERIAL NUMBER AND EXHAUST GAS EMISSION PLATE 7
1.4.4 TRAVEL REDUCTION GEAR SERIAL NUMBER 7
1.4.5 SWING REDUCTION GEAR SERIAL NUMBER 8
1.4.6 SERIAL NUMBERS AND DEALER'S ADDRESS 9

TABLE OF CONTENTS 10

SAFETY AND ACCIDENT PREVENTION

2.1 SAFETY, NOISE AND VIBRATION PLATES 18

2.1.1 POSITION OF THE SAFETY PLATES 18
2.1.2 PICTOGRAMS AND RELEVANT MEANINGS 19
2.1.3 POSITION OF THE NOISE PLATES 24
2.1.4 VIBRATIONS TO WHICH THE OPERATOR IS SUBJECTED 24

2.2 GENERAL PRECAUTIONS 25

2.2.1 GENERAL SAFETY RULES 25
2.2.2 SAFETY DEVICES AND GUARDS 25
2.2.3 CLOTHING AND PERSONAL PROTECTION ITEMS 25
2.2.4 UNAUTHORIZED MODIFICATIONS 26
2.2.5 LEAVING THE OPERATOR SEAT 26
2.2.6 GETTING ON AND OFF THE MACHINE 27
2.2.7 PREVENTING FIRES DUE TO FUEL AND OIL 28
2.2.8 PREVENTING BURNS 28
2.2.9 PREVENTING DAMAGE DUE TO ASBESTOS POWDER 29
2.2.10 PREVENTING DAMAGE CAUSED BY THE WORK EQUIPMENT 29
2.2.11 FIRE EXTINGUISHERS AND FIRST AID KIT 30
2.2.12 PRECAUTIONS CONCERNING THE ROPS STRUCTURE 30
2.2.13 PRECAUTIONS CONCERNING THE EQUIPMENT 30

2.3 PRECAUTIONS TO BE TAKEN BEFORE STARTING THE ENGINE 31

2.3.1 SAFETY AT THE WORK SITE 31
2.3.2 FIRE PREVENTION 31
2.3.3 PRECAUTIONS CONCERNING THE OPERATOR SEAT 31
2.3.4 ROOM VENTILATION 32
2.3.5 PRECAUTIONS TO BE TAKEN FOR THE LIGHTS 32

MidWestTech | Komatsu Galeo PC14R-2 Hydraulic Excavator Operation & Maintenanc... Order the manual at mid-west-tech.com >

2.4 PRECAUTIONS TO BE TAKEN WHEN WORKING 33
2.4.1 STARTING THE ENGINE 33
2.4.2 CHECK THE DIRECTION BEFORE STARTING THE MACHINE 33
2.4.3 HAND SIGNALS 34
2.4.4 CHECKS FOR TRAVELLING IN REVERSE 39
2.4.5 MOVING THE MACHINE 39
2.4.6 MOVING ON SLOPES 40
2.4.7 WORKING ON SLOPES 41
2.4.8 UNAUTHORIZED OPERATIONS 41
2.4.9 PREVENTING ELECTROCUTION 43
2.4.10 VISIBILITY 43
2.4.11 WORKING ON ICY OR SNOW-COVERED SURFACES 43
2.4.12 PREVENTING DAMAGE CAUSED BY THE WORK EQUIPMENT 44
2.4.13 WORKING ON LOOSE GROUND 44
2.4.14 PARKING THE MACHINE 44
2.5 TRANSPORTING THE MACHINE ON MOTOR VEHICLES 45
2.5.1 LOADING AND UNLOADING THE MACHINE 45
2.5.2 TRANSPORTING THE MACHINE 45
2.6 BATTERY 46
2.6.1 PREVENTING RISKS THAT MAY BE DUE TO THE BATTERY 46
2.6.2 STARTING WITH BOOSTER CABLES 46
2.7 PRECAUTIONS FOR THE REMOVAL OF THE MACHINE 47
2.8 PRECAUTIONS FOR MAINTENANCE 48
2.8.1 WARNING PLATES 48
2.8.2 TOOLS 48
2.8.3 MAINTENANCE STAFF 48
2.8.4 EQUIPMENT 49
2.8.5 WORKING UNDER THE MACHINE 49
2.8.6 CLEANING THE MACHINE 49
2.8.7 USE OF THE ENGINE DURING MAINTENANCE 50
2.8.8 PERIODICAL CHANGE OF THE PARTS THAT ARE CRITICAL FOR SAFETY 50
2.8.9 STOP THE ENGINE BEFORE CARRYING OUT ANY MAINTENANCE OPERATION OR INSPECTION 50
2.8.10 RULES TO BE FOLLOWED WHEN REFUELLING OR ADDING OIL 51
2.8.11 CHECKING THE COOLANT LEVEL IN THE RADIATOR 51
2.8.12 USING LAMPS 51
2.8.13 PRECAUTIONS TO BE TAKEN WHEN HANDLING THE BATTERY AND THE ALTERNATOR 52
2.8.14 PRECAUTIONS CONCERNING THE STARTER 52
2.8.15 HANDLING HIGH-PRESSURE HOSES 52
2.8.16 PRECAUTIONS TO BE TAKEN WHEN HANDLING HIGH-PRESSURE OIL 53
2.8.17 PRECAUTIONS FOR MAINTENANCE OPERATIONS AT HIGH TEMPERATURES AND HIGH PRESSURE 53
2.8.18 PRECAUTIONS TO BE TAKEN WHEN USING HIGH-PRESSURE GREASE TO ADJUST THE TRACK TENSION 54
2.8.19 DO NOT REMOVE THE SHOCK ABSORBING SPRING FROM THE SHOCK ABSORBER UNIT 54
2.8.20 HYDRAULIC ACCUMULATOR 54
2.8.21 COOLING FAN AND BELT 55
2.8.22 WASTE MATERIALS 55
2.8.23 COMPRESSED AIR 55

MidWestTech | Komatsu Galeo PC14R-2 Hydraulic Excavator Operation & Maintenanc... Order the manual at mid-west-tech.com >

2.8.24 PRECAUTIONS TO BE TAKEN WHEN HANDLING TECHNOPOLYMERS AND ELASTOMERS 56
2.8.25 PRECAUTIONS TO BE TAKEN WHEN USING SYNTHETIC BIODEGRADABLE OIL TYPE HEES 56

THE MACHINE AND ITS OPERATIONS

3.1 MACHINE ILLUSTRATIONS 58
3.1.1 OVERALL VIEW OF THE MACHINE 58
3.1.2 CONTROLS AND GAUGES 59
3.2 INSTRUMENTS AND CONTROLS 60
3.2.1 WARNING LIGHTS AND GAUGES 60
3.2.1.1 EMERGENCY WARNING LIGHTS 61
3.2.1.2 GAUGES 62
3.2.1.3 WARNING LIGHTS 63
3.2.2 SWITCHES AND PUSH BUTTONS 65
3.2.3 CONTROL LEVERS AND PEDALS 68
3.2.4 COVERSWITH LOCK 75
3.2.5 ENGINE HOOD 76
3.2.6 RADIATOR COVER 77
3.2.7 BATTERY COVER 78
3.2.8 TILTING THE CAB FLOOR 79
3.2.9 FUSES 82
3.2.10 MAIN FUSE 83
3.2.11 TECHNICAL DOCUMENTATION COMPARTMENT 83
3.2.12 TOOL BOX 83
3.3 USE OF THE MACHINE AND RELATED CONTROLS 84
3.3.1 BEFORE STARTING THE ENGINE 84
3.3.1.1 VISUAL CHECKS 84
3.3.1.2 CHECKS TO BE CARRIED OUT BEFORE STARTING THE ENGINE 85
3.3.1.3 ADJUSTMENTS 92
3.3.1.4 OPERATIONS TO BE CARRIED OUT BEFORE STARTING THE ENGINE 94
3.3.2 STARTING THE ENGINE 96
3.3.2.1 STARTING WITH WARM ENGINE OR IN WARM CLIMATES 96
3.3.2.2 STARTING WITH COLD ENGINE OR IN COLD CLIMATES 98
3.3.3 AFTER STARTING THE ENGINE 100
3.3.3.1 RUNNING IN A NEW MACHINE 100
3.3.3.2 WARMING-UP OPERATIONS 101
3.3.4 STOPPING THE ENGINE 103
3.3.5 HOW TO MOVE THE MACHINE 104
3.3.5.1 PRELIMINARY OPERATIONS TO BE CARRIED OUT BEFORE MOVING THE MACHINE 104
3.3.5.2 MOVING THE MACHINE FORWARD 104
3.3.5.3 MOVING THE MACHINE IN REVERSE 106
3.3.5.4 STOPPING THE MACHINE 107
3.3.6 STEERING THE MACHINE 108
3.3.6.1 STEERING (CHANGING DIRECTION) 108
3.3.7 SWINGING THE TURRET 110
3.3.8 WORK EQUIPMENT CONTROLS AND FUNCTIONS 111
3.3.9 UNAUTHORIZED OPERATIONS 114
3.3.10 PRECAUTIONS FOR USE 116
3.3.11 PRECAUTIONS TO BE TAKEN WHEN TRAVELLING ON SLOPES 118
3.3.12 GETTING THE MACHINE OUT OF MUD 120
3.3.13 OPERATIONS THAT CAN BE PERFORMED WITH THE HYDRAULIC EXCAVATOR 121

MidWestTech | Komatsu Galeo PC14R-2 Hydraulic Excavator Operation & Maintenanc... Order the manual at mid-west-tech.com >

1. Safety lever (control locking lever)

⚠ WARNING

- **Before leaving the driver seat, lower the equipment to the ground and shift the safety lever to the "locked" position (L). If the safety lever is not in the "locked" position and the control levers are touched by mistake, this may lead to serious injury.**
- **If the safety lever is not in the "locked" position, the control levers may move, causing accidents or serious injury. Always make sure that the lever is in the "locked" position, as shown in the figure.**
- **When shifting the safety lever, take care to avoid touching the equipment control levers.**


This lever operates the safety device that locks the work equipment, the swing and travel functions and the attachments. When pulled upwards, it is in "locked" position (L).
The safety device is hydraulic, therefore even if the control levers and the pedals move, the work equipment and the machine cannot be operated.

NOTE

- If the safety lever on the right or left side is not in the "locked" position (L), the engine cannot be started. Before operating the ignition switch, always make sure that the safety lever is in the "locked" position. If the engine stops while the safety lever is in "free" position (F), shift the lever back to the "locked" position before operating the ignition switch.

(F): free

(L): locked



MidWestTech | Komatsu Galeo PC14R-2 Hydraulic Excavator Operation & Maintenanc... Order the manual at mid-west-tech.com >

ADJUSTMENT

⚠ DANGER


- **The grease contained in the hydraulic cylinder is pressurized. For this reason, do not give the grease valve (1) more than one turn when loosening it; in fact, if the valve is loosened excessively it may be pushed out due to the grease pressure and this is very dangerous for the operator..**
  Do not loose any component apart from the valve (1). If the track tension does not decrease after this operation, contact your Komatsu Dealer.

⚠ WARNING


- **If the resistance met when injecting the grease is excessive, move the machine forward and backward covering a short distance.**

To increase the track tension, proceed as follows:

1. Carefully clean the grease valve (1) and inject grease through the grease nipple (2) until reaching the desired tension.



2. When after the injection of grease the idler roller sliding plate reaches the measure «S» of 0 mm and the track is not sufficiently stretched, this means that the pins and bushings are excessively worn. Therefore, it is necessary to exchange or replace the pins and bushings.
   For any replacement or repair, contact your Komatsu Dealer.



MidWestTech | Komatsu Galeo PC14R-2 Hydraulic Excavator Operation & Maintenanc... Order the manual at mid-west-tech.com >

5.2 LIFTING CAPACITIES


5.2.1 LIFTING CAPACITIES

⚠ DANGER

- **According to the harmonized standard EN474-5 (§ 4.1.7.5), the machine cannot lift weights exceeding 1000 kg, unless it is provided with appropriate equipment.**
- **Carry out lifting operations only with the machine positioned on firm and flat ground.**

NOTE

- The load does not exceed 87% of the hydraulic lifting capacity or 78% of the tipping limit.



* Load limited by the hydraulic lifting capacity and not by the tipping limit.

ROPS CANOPY + STANDARD ARM + STANDARD COUNTERWEIGHT + LOWERED BLADE Unit: kg

A / B-	1 m		1.5 m		2 m		2.5 m		3 m		3.5 m		Max.	
														
3.0 m					-	-	-	-	-	-	-	-	-	-
2.5 m					*220	*220	-	-	-	-	-	-	*229	*229
2.0 m					*225	*225	*218	200	-	-	-	-	*220	179
1.5 m					*276	*276	*235	198	-	-	-	-	*219	154
1.0 m					*353	267	*266	192	*222	143	-	-	*221	143
0.5 m					*411	255	*292	186	*227	141	-	-	*226	140
0 m			*661	374	*424	249	*299	182	-	-	-	-	*231	147
- 0.5 m	*970	728	*579	377	*389	248	*270	182	-	-	-	-	*234	167
- 1.0 m	*698	*698	*434	385	*293	253	-	-	-	-	-	-	*227	215
- 1.5 m					-	-	-	-	-	-	-	-	-	-

MidWestTech | Komatsu Galeo PC14R-2 Hydraulic Excavator Operation & Maintenanc... Order the manual at mid-west-tech.com >