600
Crawler

Service Manual

X27053A

CASE CONSTRUCTION

Order the manual at mid-west-tech.com >

INDEX

SECTION I — GENERAL INFORMATION

Four Cylinder L-Head Engine Specifications 5
Six Cylinder L-Head Engine Specifications 6
How to Order Parts 7
Continental L-Head Engine Features 8

SECTION II — LUBRICATION

Engine Lubricating System 11
Oil Pump 12
Air Cleaner 13
Lubrication Recommendations 14
Transmission and Converter Lubrication Recommendations 16

SECTION III — OPERATION

Preparation of New Engine for Operation 17
Starting the Engine 18
Stopping the Engine 20
10 Operating Precautions 21
Cold Weather Operation 21
Seasonal Storage of Engine 22

SECTION IV — PREVENTIVE MAINTENANCE

Daily Preventive Maintenance Schedule 23
50-Hour Preventive Maintenance Schedule 25
250-Hour Preventive Maintenance Schedule 26
500-Hour Preventive Maintenance Schedule 27

SECTION V — COOLING SYSTEM

Continental L-Head Cooling System 28
Effect of Altitude on Cooling 29
Anti-Freezes 29
Cleaning Cooling System 30
Testing Thermostat 31
Radiator Pressure Cap 32
Fan Belt Tension 33
Water Pump 33

SECTION VI — FUEL SYSTEM

Gravity Fuel System 35
Mechanical Fuel Pump 35
Electrical Fuel Pump 36
Zenith Carburetor 36
Marvel-Schebler Carburetor 37
Carburetor Chokes 37
Governors 39
Pierce Governor 41
Cam Gear Governor 42
Tail-Shaft Governors 42

MidWestTech | Case 600 Crawler Service Manual | Publication x27053a Order the manual at mid-west-tech.com >

INDEX

SECTION VII — IGNITION

Battery — Ignition System 43
Ignition Coil — Distributor & Condenser 44
Distributor Maintenance 45
Spark Plugs 46
Distributor — Ignition Timing, with Timing Light 47
Ignition Timing, without Timing Light 48
Magneto — Ignition 49
Magneto Impulse Coupling 50
Timing Magneto to Engine 51
Charging Circuit 51A

SECTION VIII — ENGINE REPAIR AND OVERHAUL

Cylinder Head 52
Cylinder Block 53
Valve Seat Inserts 54
Valves 55
Valve Springs 56
Preparing Cylinder Bores 57
Pistons 58
Connecting Rods 59
Piston Rings 60
Bearings 61
Crankshaft 63
Camshaft 64
Valve Tappets 64
Timing Gears 65
Crankshaft End Play 66
Rear Oil Seals 67
Oil Pumps 69
Flywheels and Housings 71
Reassembling Engine 72

SECTION IX — TROUBLE-SHOOTING

Starting Motor Will Not Crank Engine 73
Engine Will Not Start 73
Engine Runs Unevenly 74
Poor Compression 74
High Oil Pressure 75
Engine Knocks 75
Engine Vibration 75

SECTION X — TORQUE SPECIFICATIONS 76

SECTION XI — LIMITS & CLEARANCE DATA 77

MidWestTech | Case 600 Crawler Service Manual | Publication x27053a Order the manual at mid-west-tech.com >