TOYOTA

INDUSTRIAL EQUIPMENT

PARTS CATALOG FOR MODEL

6BPU15

Serial Number 70,001 and Up

M/N 00715-00050-13

Issued: 21 Mar 2013

MidWestTech | Toyota 6BPU15 Order Picker Parts Catalog | Publication 00715-00050-13 Order the manual at mid-west-tech.com >

Table of Contents

SECTION 1 General Information

To Our Customer 1-2
How To Use Parts Catalog if Part Number Is Not Known 1-3
How To Use Parts Catalog if Part Number Is Known 1-4
Major Assemblies 1-5
Recommended Spare Parts List 1-6
Hardware Parts List 1-8

SECTION 2 Finish and Accessories

Major Assemblies 2-2
Finish Details 2-5
Battery Gate Installation 2-14
Battery Roller Assembly, S/N 71616 and Below 2-16
Sidegate Installation 2-17
Platform and Pallet Clamp Assembly 2-20
Pedal Assembly, Pallet Clamp 2-23
Platform Extension Assembly (47 to 55 in.) 2-24
Platform Extension Assembly (59 to 63 in.) 2-26
Guide Roller Assembly Weldment (71.75 in. Width) 2-28
Guide Roller Installation (45.25 to 47 in. / 49.50 in. / 53.50 in. Roller Width) 2-30
Wheel Assembly, Switched 2-32
Guide Roller Installation (47.50 to 52.75 in. Roller Width) 2-35
Roller Switch Assembly (2.25 x 3.12 in. Wheel) 2-40
Guide Roller Installation (52 to 67 in. / 56.50 to 69.75 in. Roller Width) 2-43
Guide Roller Installation (61.25 to 66.75 in. Roller Width) 2-48
Fire Extinguisher Installation 2-50
Mast Guards 2-51
Tether Installation, Mechanical 2-54
Battery Accessories 2-56

SECTION 3 Steering and Controls

Steering and Control Components 3-3
Steering Wheel Assembly 3-8
Steer Motor and Gearbox Assembly 3-10

SECTION 4 Drive and Brake

Drive and Brake Components 4-2
Motor and Drive Unit Assembly 4-4
Lower Drive Unit Assembly 4-6
Deadman Brake Components 4-9
Brake Subassembly 4-12
Brake Assembly 4-14
Pedal Assembly, Deadman Brake 4-16
Wheel Assembly, Standard, Rounded 4-18

SECTION 5 Electrical Components and Systems

Electrical System 5-3
Carriage Electrical Assembly 5-11

MidWestTech | Toyota 6BPU15 Order Picker Parts Catalog | Publication 00715-00050-13 Order the manual at mid-west-tech.com >

Contactor Panel Assembly 5-14
Contactor 5-16
Steer Control Assembly, Toyota Tracker 5-18
Controller Assembly, Display 5-20
Wire Guide Installation 5-21
Wire Guidance Sensor, Tractor End 5-24
Wire Guidance Sensor, Load End 5-26
Warning Light Installation 5-29
Warning Light Assembly 5-30
Battery Connector Assembly 5-32
Operator Compartment Lights and Fan 5-35
Light and Fan Assembly, Fluorescent 5-38
Light and Fan Assembly, Incandescent 5-42
Bin Lights Installation 5-47
Bin Light Assembly 5-50
Auxiliary Power Hook-up 5-52
Lift-Limit Cutout Switch Installation 5-54
Travel Limit Switch Installation 5-57
Lower Limit Switch 5-60
Tractor Heaters, Cold Storage 5-63
Motion Alarm Installation 5-67
Motor, Drive, 24 Volt 5-68
Motor, Lift, 24 Volt 5-70
Control Handle Assembly 5-73

SECTION 6 Hydraulic Components

Hydraulic Installation 6-2
Reservoir Assembly 6-4
Lift/Lower Manifold Assembly, Three Stage 6-6
Valve, Lift/Lower, Three Stage 6-8
Lift/Lower Manifold Assembly, Two Stage 6-10
Valve, Lift/Lower, Two Stage 6-12
Lift Pump and Motor Assembly 6-14
Lift Ram, Main Lift, 1.75 inch Diameter 6-16
Lift Ram, Free Lift, 2.5 inch Diameter 6-20

SECTION 7 Mast

Two Stage Mast Assembly 7-2
Three Stage Mast Assembly 7-7
Two and Three Stage Mast Cables, Hoses, and Pulleys 7-13
Fork Assembly, Standard 7-22
End Cap Pulley Assembly 7-24
Pulley Assembly 7-28
Pulley Assembly 7-29
Pulley Assembly 7-30
Bumper Assembly 7-31
Load Wheel Assembly 7-32

APPENDIX A Alphabetical Parts Index

APPENDIX B Numerical Parts Index

MidWestTech | Toyota 6BPU15 Order Picker Parts Catalog | Publication 00715-00050-13 Order the manual at mid-west-tech.com >

SECTION 1 General Information

To Our Customer 1-2
How To Use Parts Catalog if Part Number Is Not Known 1-3
How To Use Parts Catalog if Part Number Is Known 1-4
Major Assemblies 1-5
Recommended Spare Parts List 1-6
Hardware Parts List 1-8

MidWestTech | Toyota 6BPU15 Order Picker Parts Catalog | Publication 00715-00050-13 Order the manual at mid-west-tech.com >

List 5-2: Carriage Electrical Assembly

FIGURE 5-2 ITEM NO.	QTY	PART NUMBER	DESCRIPTION	USED ON
1	4	00590-39782-71	Screw	
2	1	00590-03577-71	Jack, Banana	
3	1	00590-03484-71	Washer, Lock	
4	1	00590-40877-71	Card Assembly, Carriage Interface	R
5	4	00590-03434-71	Screw	
6	4	00590-03103-71	Spacer, Threaded	
7	1	00590-03396-71	Cable Assembly	
8	2	00590-03242-71	Clamp, Loop, Cushioned	
9	2	00590-03591-71	Screw, Self-Tapping	
10	1	00590-03284-71	Bracket, Control Box	
11	8	00590-03021-71	Screw	
12	1	00590-45436-71	Handle Assembly, Control (See Figure 5-26a.)	
	1	00590-45702-71	Handle Assembly, Control (See Figure 5-26b.)	B
13	2	00590-03432-71	Screw	
14	1	00590-03395-71	Harness, Wiring	
15	1	00590-48151-71	Switch, Emergency Power OFF (S21)	R
17	1	00590-39784-71	Cover, Switch	
18	2	00590-00556-71	Cable Tie	
26	1	00590-03449-71	Horn, Piezo Ceramic	
27	2	00590-03431-71	Screw	
28	1	00590-39785-71	Plate, Cover	
29		Ref.	Controller Assembly, Display (See Figure 5-6.)	
30	4	00590-03144-71	Nut	
31	4	00590-03289-71	Spacer	
32	1	00590-48165-71	Switch, Keyed, Operator's (S1)	R
	1	00590-04577-71	Key, Set (Quantity - 2) (Not Shown)	R
33	1	00590-03286-71	Harness, Wiring	
34	1	00590-03247-71	Switch, Wire Guidance	A, R
35	1	00590-03394-71	Cable Assembly	A
36	1	00590-03383-71	Display Assembly, Operator	
37	1	00590-03508-71	Decal, ESD	
38	1	00590-03393-71	Bezel	
39	1	00590-41880-71	Clamp	

A= With Wire Guidance
B= Cold Storage
R= Recommended Spare

MidWestTech | Toyota 6BPU15 Order Picker Parts Catalog | Publication 00715-00050-13 Order the manual at mid-west-tech.com >

List 5-13: *Operator Compartment Lights and Fan*

FIGURE 5-13 ITEM NO.	QTY	PART NUMBER	DESCRIPTION	USED ON
		00590-39646-71	Lights and Fan Installation, Standard	
		00590-39800-71	Lights and Fan Installation, Cold Storage	
1	1	00590-39641-71	Light and Fan Assembly, Fluorescent, Right-Hand (See Figure 5-14a.)	B
	1	00590-39642-71	Light and Fan Assembly, Fluorescent, Left-Hand (See Figure 5-14a.)	B
	1	00590-39801-71	Light and Fan Assembly, Incandescent, Right-Hand (See Figure 5-15a.)	C
	1	00590-39802-71	Light and Fan Assembly, Incandescent, Left-Hand (See Figure 5-15a.)	C
2	1	00590-02864-71	Cable Assembly, Light and Fan, Left-Hand (TS12-3 to TS12-1)	
	1	00590-02865-71	Cable Assembly, Light and Fan, Left-Hand (TS12-3 to TS12-1)	A
	1	00590-39803-71	Cable Assembly, Light and Fan, Left-Hand (JC5-2 to JC5-1)	
	1	00590-39804-71	Cable Assembly, Light and Fan, Left-Hand (JC5-2 to JC5-1)	A
3	1	00590-02925-71	Cable Assembly, Light and Fan, Right-Hand (TS12-3 to TS12-1)	
	1	00590-02926-71	Cable Assembly, Light and Fan, Right-Hand (TS12-3 to TS12-1)	A
	1	00590-39805-71	Cable Assembly, Light and Fan, Right-Hand (JC5-4 to JC5-3)	
	1	00590-39806-71	Cable Assembly, Light and Fan, Right-Hand (JC5-4 to JC5-3)	A
4	10	00590-00811-71	Cable Tie	
5	8	00590-03036-71	Nut	
	8	00590-03037-71	Nut, Lock	
6	8	00590-00568-71	Washer, Flat	
7	16	00590-03134-71	Spacer, Mounting, Shock	
8	2	00590-03125-71	Screw	
9	1	00590-03220-71	Strip, Terminal Marker	
10	1	00590-03241-71	Strip, Terminal Marker	

A= Extended Overhead Guard Height (Item 2 = 97 in., Item 3 = 77 in. long)
B= Standard
C= Cold Storage

MidWestTech | Toyota 6BPU15 Order Picker Parts Catalog | Publication 00715-00050-13 Order the manual at mid-west-tech.com >

List 6-9: Lift Ram, Free Lift, 2.5 inch Diameter

FIGURE 6-9 ITEM NO.	QTY	PART NUMBER	DESCRIPTION	USED ON
		00590-03322-71	Ram Assembly, Free Lift, 2.5 in. Diameter	A
		00590-03323-71	Ram Assembly, Free Lift, 2.5 in. Diameter	B
		00590-03324-71	Ram Assembly, Free Lift, 2.5 in. Diameter	C
		00590-03325-71	Ram Assembly, Free Lift, 2.5 in. Diameter	D
		00590-03326-71	Ram Assembly, Free Lift, 2.5 in. Diameter	E
		00590-03327-71	Ram Assembly, Free Lift, 2.5 in. Diameter	F
		00590-49580-71	Ram Assembly, Free Lift, 2.5 in. Diameter	G
1		Ref.	Housing, Cylinder (Contact Technical Support)	
2	1	00590-02879-71	Ring, Snap	
3	1	00590-02942-71	Sleeve, Bearing	
4	1	00590-47703-71	Screw	
5	1	00590-03104-71	Ring, Backup	R
6	1	00590-03105-71	Piston, Tube	A
	1	00590-03106-71	Piston, Tube	B
	1	00590-03107-71	Piston, Tube	C
	1	00590-03108-71	Piston, Tube	D
	1	00590-03109-71	Piston, Tube	E
	1	00590-03110-71	Piston, Tube	F
	1	00590-49581-71	Piston, Tube	G
7	2	00590-03143-71	Ring, Snap	H
8	1	00590-03188-71	Seal, Oil	H, R
9	1	00590-03460-71	Ring, Packing	R
10	1	00590-03442-71	Seal	H, R
11	1	00590-03459-71	Adapter, Bearing	
12	1	00590-03440-71	Packing, O-Ring	R
13	1	00590-03253-71	Plug, Piston, Mechanical	
14	NSS	00590-03373-71	Plug, Cylinder, Mechanical	
15	NSS	00590-03461-71	Stud, Stop	
16	1	00590-03141-71	Ring, Snap	H
17	1	00590-03598-71	Ring, Retainer	
18	1	00590-03587-71	Cushion, Lowering, Piston	
19	1	00590-02878-71	Seal, Oil	H, R
20	1	00590-03583-71	Spring	R
21	NSS	00590-03250-71	Manifold, Cylinder	
22	1	00590-03549-71	Pin, Locator	
23	NSS	00590-03356-71	Stud, Pivot	
24	1	00590-42195-71	Kit, Seal (Not Shown)	R

A= OACH 88 in.
B= OACH 95 in.
C= OACH 107 in.
D= OACH 118 in.
E= OACH 127 in.
F= OACH 132 in.
G= OACH 147 in.
H= Included in Item 24
R= Recommended Spare

MidWestTech | Toyota 6BPU15 Order Picker Parts Catalog | Publication 00715-00050-13 Order the manual at mid-west-tech.com >

Part No.	Description	Page
00590-02913-71	Plate, Mounting	5-27
00590-02914-71	Decal	5-19
00590-02914-71	Decal	5-20
00590-02915-71	Plug, Dipstick	4-5
00590-02916-71	Valve, Solenoid	4-11
00590-02918-71	Plug, Mechanical	4-5
00590-02919-71	Gear, Helical	4-7
00590-02921-71	Holder, Fuse	5-15
00590-02922-71	Spring, Main	5-17
00590-02923-71	Spacer, Hex	5-19
00590-02924-71	Bushing	5-33
00590-02925-71	Cable Assembly, Light and Fan, Right-Hand (TS12-3 to TS12-1)	5-37
00590-02926-71	Cable Assembly, Light and Fan, Right-Hand (TS12-3 to TS12-1)	5-37
00590-02931-71	Lever, Limit Switch, Mast	2-19
00590-02931-71	Lever, Limit Switch, Mast	2-33
00590-02931-71	Lever, Limit Switch, Mast	2-41
00590-02931-71	Lever, Limit Switch, Mast	5-55
00590-02931-71	Lever, Limit Switch, Mast	5-59
00590-02931-71	Lever, Limit Switch, Mast	5-61
00590-02936-71	Valve, Relief	6-3
00590-02937-71	Plug, O-Ring	6-11
00590-02937-71	Plug, O-Ring	6-7
00590-02941-71	Seal, Oil	6-17
00590-02942-71	Sleeve, Bearing	6-21
00590-02943-71	Ball, Check	6-5
00590-02946-71	Pin, Fork	7-23
00590-02947-71	Spacer, Pulley	7-27
00590-02955-71	Bumper, Carriage	7-31
00590-02956-71	Stud	2-11
00590-02956-71	Stud	2-12
00590-02958-71	Spacer, Battery	2-15
00590-02959-71	Sidegate, Machine, Right-Hand	2-19
00590-02961-71	Spring, Tension	2-23
00590-02961-71	Spring, Tension	3-9
00590-02962-71	Weldment, Platform Extension	2-25
00590-02963-71	Weldment, Platform Extension	2-25
00590-02964-71	Weldment, Platform Extension	2-25
00590-02965-71	Weldment, Platform Extension	2-27
00590-02966-71	Weldment, Platform Extension	2-27
00590-02970-71	Plate, Lexan	2-53
00590-02971-71	Guard, Mast, Glass	2-53
00590-02972-71	Guard, Screen	2-53
00590-02974-71	O-Ring	4-5
00590-02975-71	Gear, Spur	3-7
00590-02976-71	Shaft	3-9
00590-02978-71	Cable, Antenna, Tractor	5-23
00590-02982-71	Rod, Push	4-13
00590-02984-71	Plate, Cover	4-7
00590-02987-71	Contactor Assembly	5-15
00590-02987-71	Contactor Assembly	5-17
00590-02988-71	Spacer, Hex	5-19
00590-02990-71	Terminal	5-33
00590-02993-71	Connector, Plug	5-51
00590-02994-71	Strip, Terminal Marker	5-49
00590-02994-71	Strip, Terminal Marker	5-53
00590-02995-71	Switch	2-19
00590-02995-71	Switch	2-33
00590-02995-71	Switch	2-41
00590-02995-71	Switch	5-55
00590-02995-71	Switch	5-59
00590-02995-71	Switch	5-61
00590-02998-71	Connector, O-Ring	6-3
00590-02999-71	Elbow, 90 Degree	6-11
00590-02999-71	Elbow, 90 Degree	6-7
00590-03000-71	Connector, Hydraulic, Beaded	6-15
00590-03002-71	Cap, Filler, Breather	6-5
00590-03009-71	Pulley, Cable	7-30
00590-03014-71	Decal, Toyota	2-11
00590-03017-71	Sidegate, Machine, Left-Hand	2-19
00590-03024-71	Plate, Mounting, Steer	3-9
00590-03026-71	Spacer	5-25
00590-03026-71	Spacer	5-27
00590-03028-71	Cable Assembly, Proximity	5-9
00590-03031-71	Connector Assembly, Battery	5-33
00590-03031-71	Connector Assembly, Battery	5-9
00590-03034-71	Guard, Light, Warning	5-29
00590-03035-71	Decal, Label	5-27
00590-03038-71	Deflector, Air	5-41
00590-03039-71	Deflector, Air	5-45
00590-03041-71	Contact, Pin	5-51
00590-03042-71	Strip, Terminal Marker	5-49
00590-03042-71	Strip, Terminal Marker	5-53
00590-03043-71	Cable Assembly	5-55
00590-03044-71	Cable Assembly	5-55
00590-03045-71	Cable Assembly	5-55
00590-03046-71	Cable Assembly	5-55
00590-03047-71	Cable Assembly	5-55
00590-03048-71	Cable Assembly	5-55
00590-03049-71	Cable Assembly	5-55
00590-03050-71	Cable Assembly	5-59
00590-03051-71	Cable Assembly	5-59
00590-03052-71	Cable Assembly	5-59
00590-03053-71	Cable Assembly	5-59
00590-03054-71	Tee, O-Ring	6-3
00590-03055-71	Adapter, Housing	6-11
00590-03055-71	Adapter, Housing	6-7
00590-03057-71	Pump	6-15
00590-03058-71	Kit, Seal	6-15
00590-03059-71	Plug, Packing, Backup	6-17
00590-03060-71	Ring, Backup	6-17
00590-03061-71	Filter, Cartridge, Mechanical	6-5
00590-03062-71	Bearing, Roller, Mast	7-11
00590-03062-71	Bearing, Roller, Mast	7-5
00590-03064-71	Spacer	7-28
00590-03069-71	Decal, Toyota	2-11
00590-03072-71	Bearing, Sleeve, Flanged	2-19
00590-03083-71	Plate, Steering Wheel	3-9
00590-03086-71	Housing, Sensor, Wire Guidance	5-25
00590-03086-71	Housing, Sensor, Wire Guidance	5-27
00590-03088-71	Key, Woodruff	4-5
00590-03088-71	Key, Woodruff	4-7
00590-03089-71	Tee, Fitting, Tube	4-11
00590-03090-71	Guard, Cable Assembly	5-10
00590-03091-71	Gear, Axle	4-7
00590-03095-71	Switch, Rocker	5-41
00590-03095-71	Switch, Rocker	5-45
00590-03099-71	Harness, Wiring	5-49
00590-03099-71	Harness, Wiring	5-53
00590-03101-71	Hose	6-3
00590-03102-71	Packing, O-Ring	6-11
00590-03102-71	Packing, O-Ring	6-7
00590-03103-71	Spacer, Threaded	3-7
00590-03103-71	Spacer, Threaded	5-13
00590-03104-71	Ring, Backup	6-21
00590-03105-71	Piston, Tube	6-21
00590-03106-71	Piston, Tube	6-21
00590-03107-71	Piston, Tube	6-21
00590-03108-71	Piston, Tube	6-21
00590-03109-71	Piston, Tube	6-21
00590-03110-71	Piston, Tube	6-21
00590-03112-71	Spacer, Roller	7-11
00590-03112-71	Spacer, Roller	7-5

MidWestTech | Toyota 6BPU15 Order Picker Parts Catalog | Publication 00715-00050-13 Order the manual at mid-west-tech.com >

Recommended Spare Parts List

Description	Part No.	Qty.	Page
Bearing	00590-39736-71	2	2-38
Bearing	00590-39736-71	2	2-41
Bearing	00590-39736-71	2	2-46
Bearing Set	00590-41862-71	1	4-7
Bearing	00590-02893-71	2	7-32
Bearing	00590-03419-71	1	4-5
Bearing	00590-39699-71	2	2-33
Bearing	00590-39701-71	1	2-33
Bearing, Ball	00590-02833-71	2	2-29
Bearing, Ball	00590-02835-71	2	2-31
Bearing, Ball	00590-02835-71	2	2-33
Bearing, Ball	00590-02835-71	2	2-49
Bearing, Ball	00590-02835-71	2	3-9
Bearing, Commutator End	00590-04566-71	1	5-69
Bearing, Commutator End	00590-04566-71	1	5-71
Bearing, Cone	00590-41860-71	1	4-7
Bearing, Cone	00590-41861-71	1	4-7
Bearing, Cone	00590-41895-71	1	4-7
Bearing, Drive End	00590-39827-71	1	5-69
Bearing, Drive End	00590-39837-71	1	5-71
Bearing, Roller, Mast	00590-03062-71	12	7-11
Bearing, Roller, Mast	00590-03062-71	8	7-5
Bearing, Sleeve	00590-00920-71	1	3-7
Bearing, Sleeve	00590-00920-71	2	2-41
Bearing, Sleeve	00590-02701-71	2	5-75
Bearing, Sleeve	00590-03259-71	1	5-75
Bearing, Sleeve	00590-03260-71	1	5-75
Bearing, Sleeve	00590-03420-71	1	5-75
Bearing, Sleeve	00590-03623-71	1	5-75
Bearing, Sleeve, Flanged	00590-03072-71	4	2-19
Bearing, Sleeve, Flanged	00590-46101-71	1	2-21
Brush	00590-41782-71	8	5-69
Brush Assembly	00590-41886-71	1	3-10
Brush Set	00590-39840-71	1	5-71
Bulb	00590-39793-71	1	5-31
Bulb, Light	00590-02792-71	1	5-51
Bulb, Light	00590-03451-71	2	5-45
Cable Assembly, Proximity	00590-03028-71	1	5-9
Cable Assembly, Proximity	00590-03287-71	1	3-7
Cable Assembly, Proximity	00590-03287-71	1	5-10
Cable Assembly, Proximity	00590-03288-71	1	5-10
Card Assembly, Carriage Interface	00590-40877-71	1	5-13
Card Assembly, Display Controller	00590-02845-71	1	5-20
Card Assembly, Filter	00590-03133-71	1	5-19
Card Assembly, Interface	00590-39581-71	1	5-10
Card Assembly, Multivoltage	00590-39795-71	1	5-31
Card Assembly, Steer Encoder	00590-39761-71	1	3-9
Card Assembly, Steer Manager	00590-47112-71	1	5-19
Card Assembly, Wire Guidance	00590-02843-71	1	5-25
Card Assembly, Wire Guidance	00590-02843-71	1	5-27
Controller, Lift	00590-42650-71	1	5-9
Controller, Traction	00590-45693-71	1	5-9
Coupling, Mechanical	00590-43062-71	1	3-7
Cylinder, Slave	00590-03575-71	1	4-11
Encoder Assembly	00590-03299-71	1	3-7
Filter, Cartridge, Mechanical	00590-03061-71	1	6-5
Fuse, 10 Amp	00590-39822-71	1	5-65
Fuse, 15 Amp	00590-00552-71	3	5-15
Fuse, 350 Amp	00590-02856-71	1	5-15
Fuse, 450 Amp	00590-03182-71	1	5-15
Fuse, 5 Amp	00590-03446-71	1	5-41
Fuse, 6 Amp	00590-03447-71	2	5-15
Fuse, 70 Amp	00590-02781-71	1	5-15
Key, Set (Quantity - 2)	00590-04577-71	1	5-13
Kit, Field Coil	00590-41872-71	1	5-69
Kit, Guide and Insulator	00590-02857-71	1	5-17
Kit, Hardware	00590-39794-71	1	5-31
Kit, Hose Clamp	00590-42213-71	1	7-20
Kit, Hose Clamp	00590-42215-71	1	7-20
Kit, Lead Assembly	00590-39832-71	1	5-69
Kit, Lead Assembly	00590-39842-71	1	5-71
Kit, Ring Set	00590-46372-71	1	4-5
Kit, Seal	00590-42195-71	1	6-21
Kit, Seal	00590-42999-71	1	6-18
Kit, Seal	00590-03058-71	1	6-15
Kit, Seal	00590-41903-71	1	6-9
Kit, Seal	00590-41904-71	1	4-11
Kit, Seal, Proportional Valve	00590-41899-71	1	6-9
Kit, Service, Brush Wear Indicator	00590-40415-71	1	5-69
Kit, Tip, Contactor	00590-02782-71	1	5-17
Lamp Assembly, Warning, Amber	00590-02785-71	1	5-31
Module, WSI (Firmware)	00590-46660-71	1	5-20
O-Ring	00590-02974-71	1	4-5
O-Ring	00590-03441-71	1	6-5
O-Ring	00590-39798-71	1	5-31
O-Ring	00590-41868-71	1	6-5
Packing, O-Ring	00590-03102-71	1	6-11
Packing, O-Ring	00590-03440-71	1	6-21
Relay	00590-42175-71	1	5-10
Resistor, Variable	00590-43053-71	1	5-76
Resistor, Variable	00590-43054-71	1	5-76
Return, Spring	00590-04521-71	2	4-15
Ring, Backup	00590-03060-71	1	6-17
Ring, Backup	00590-03104-71	1	6-21
Ring, Packing	00590-03460-71	1	6-21
Seal	00590-02802-71	1	6-17
Seal	00590-03442-71	1	6-21
Seal	00590-39824-71	1	5-69
Seal, Oil	00590-02779-71	1	4-7
Seal, Oil	00590-02878-71	1	6-17
Seal, Oil	00590-02878-71	1	6-21
Seal, Oil	00590-02941-71	1	6-17
Seal, Oil	00590-03188-71	1	6-21
Shoe Assembly	00590-04520-71	2	4-15
Spring Assembly, Gas	00590-49033-71	2	2-19
Spring	00590-03583-71	1	6-17
Spring	00590-03583-71	1	6-21
Spring	00590-39949-71	1	2-21
Spring	00590-40750-71	1	2-41
Spring	00590-45842-71	1	5-75
Spring, Brush	00590-41873-71	8	5-69
Spring, Brush	00590-04574-71	1	5-71
Spring, Compression	00590-03566-71	1	4-11
Spring, Compression	00590-03567-71	1	6-5
Spring, Compression	00590-03568-71	1	5-76
Spring, Compression, Hose Take-Up	00590-03565-71	1	2-33
Spring, Compression, Hose Take-Up	00590-03565-71	1	4-17
Spring, Leaf	00590-03382-71	2	5-41
Spring, Leaf	00590-03382-71	2	5-45
Spring, Main	00590-02922-71	1	5-17
Spring, Tension	00590-02882-71	5	7-19
Spring, Tension	00590-02961-71	1	2-23
Spring, Tension	00590-02961-71	1	3-9
Spring, Torsion	00590-45841-71	1	5-75
Switch (S2)	00590-03180-71	1	5-10
Switch	00590-02995-71	1	2-33
Switch	00590-02995-71	1	2-41
Switch	00590-02995-71	1	5-55

MidWestTech | Toyota 6BPU15 Order Picker Parts Catalog | Publication 00715-00050-13 Order the manual at mid-west-tech.com >