TOYOTA

INDUSTRIAL EQUIPMENT

PARTS CATALOG FOR MODELS

7BNCU15/18/20/25

Serial Number 50,001 and Up

M/N 00715-00085-09

12/01/2009

MidWestTech | Toyota 7BNCU15, 7BNCU18, 7BNCU20, 7BNCU25 Forklift Parts Catalog |... Order the manual at mid-west-tech.com >

Table of Contents

SECTION 1 General Information

To Our Customer 1-2
How To Use Parts Catalog - If Part Number Not Known 1-3
How To Use Parts Catalog - If Part Number Is Known 1-4
Major Sections 1-5
Recommended Spare Parts List 1-7
Hardware Parts List 1-8

SECTION 2 Finish and Accessories

Major Assemblies 2-2
Power Section Mechanical Parts 2-4
Finish Instructions 2-8
Handle Decals 2-20
Battery Gates and Rollers (Standard) 2-22
Battery Spacer Installation (Battery Length 36.51 in. to 39.32 in.) 2-23
Weighted Battery Spacer and Roller Assembly 2-24
Roller Assembly 2-26
Battery Cover Assembly, EE 2-28
Rear Door Assembly 2-30
Load Backrest Installation 2-31
Fire Extinguisher 2-32

SECTION 3 Steering and Controls

Steering and Controls 3-2
Steer Wheel Assembly 3-4
Wheel Hub Assembly 3-7
Steer Piping Installation 3-8
Steering Tiller Assembly 3-10

SECTION 4 Drive and Brake

Drive and Brake Installation 4-3
Gear Reducer 4-6
Wheel Hub Assembly (7 in. Wide) 4-8
Wheel Hub Assembly (6 in. Wide) 4-10
Brake, Electric 4-12
Deadman Brake Assembly 4-14

SECTION 5 Electrical Systems and Components

Electrical System 5-3
Contactor Panel Assembly 5-16
Contactor Assembly 5-20
Operator Display Assembly 5-22
Handle Installation 5-24
Handle Assembly 5-26
Horn Installation 5-30
Battery Connector 5-32
Traction Motor, 4K, Standard 5-34
Traction Motor, 5K, Standard 5-36

MidWestTech | Toyota 7BNCU15, 7BNCU18, 7BNCU20, 7BNCU25 Forklift Parts Catalog |... Order the manual at mid-west-tech.com >

Traction Motor, 4K and 5K, EE 5-38
Lift Motor, 4K, Standard 5-40
Lift Motor, EE 5-42
Lift Motor, 5K, Standard 5-44
Steer Motor 5-46
Auxiliary Motor 5-48
Warning Light Installation 5-50
Warning Light Assembly 5-52
Working Light Installation 5-55
Travel Alarm Installation 5-62
Operator Cooling Fan Installation 5-63
Limit Switch Installation 5-65
Lift Limit With Bypass Installation 5-67

SECTION 6 Hydraulic Components

Hydraulic System 6-3
Hose Installation 6-11
Manifold Assembly 6-20
Manifold Assembly 6-22
Manifold Assembly, Auxiliary 6-24
Sideshift and Auxiliary Manifolds 6-27
Manifold Assembly (High Speed Valve) 6-28
Manifold Assembly (High Speed) 6-30
Manifold (High Speed) 6-32
Spool Assembly 6-34
Spool Valve, Manual 6-35
Handle Assembly 6-37
Lift and Steer Pump Motor Installation 6-38
Lift Motor Assembly 6-40
Auxiliary Pump and Motor Installation 6-41
Pump and Motor Assembly 6-43
Steer Motor Assembly 6-44
Hydraulic Motor 6-47
Orbitrol Valve 6-48
Lift Pump 6-50
Steer/Auxiliary Pump 6-51
Cylinder Assembly, Free Lift (Three Stage) 6-52
Cylinder Assembly, Main Lift (Three Stage) 6-54
Free Lift Cylinder (Two Stage, 3K and 3.5K) 6-56
Main Lift Cylinder (Two Stage, 3K and 3.5K) 6-58
Free Lift Cylinder (Two Stage, 4K Only) 6-60
Main Lift Cylinder, Right-Hand (Two Stage, 4K Only) 6-62
Main Lift Cylinder, Left-Hand (Two Stage, 4K Only) 6-64
Free Lift Cylinder (Two Stage, 5K Only) 6-66
Main Lift Cylinder, Right-Hand (Two Stage, 5K Only) 6-68
Main Lift Cylinder, Left-Hand (Two Stage, 5K Only) 6-70
Free Lift Cylinder (Three Stage) 6-72
Main Lift Cylinder, Right-Hand (Three Stage) 6-74
Main Lift Cylinder, Left-Hand (Three Stage) 6-76
Free Lift Cylinder (Quad Mast, Serial Number 1377 and Up*) 6-78
Main Lift Cylinder, Right-Hand (Quad Mast, Serial Number 1377 and Up*) 6-80
Main Lift Cylinder, Left-Hand (Quad Mast, Serial Number 1377 and Up*) 6-82

MidWestTech | Toyota 7BNCU15, 7BNCU18, 7BNCU20, 7BNCU25 Forklift Parts Catalog |... Order the manual at mid-west-tech.com >

Tilt Ram Assembly 6-85

SECTION 7 Mast

Elevating Section (Two Stage, 3K Only) 7-3
Mast Finish Instructions 7-7
Elevating Section (Two Stage, 4K Only) 7-10
Carriage (4 Roller), One Auxiliary Function Only 7-14
Carriage (6 Rollers), Class II 7-16
Lowering Control Valve (Two Stage, 4K Only) 7-19
Internal Hose Reeving (Two Stage, 4K Only) 7-20
Mast Installation (Two Stage, 4K Only) 7-22
Mast Finish Instructions (Two Stage, 5K Only) 7-25
Mast Assembly (Two Stage, 5K Only) 7-26
Lowering Control Valve (Two Stage, 5K Only) 7-29
Carriage, Class II (6 Rollers, Two Stage, 5K Only) 7-30
Internal Hose Reeving (Two Stage, 5K Only) 7-32
Elevating Section (Three Stage) 7-35
Mast Finish Instructions (Quad Mast Only) 7-41
Hoist Chains and Free Lift Hoses (Quad Mast Only) 7-42
Mast Assembly (Quad Mast Only) 7-44
Control Valve, Lowering (Quad Mast Only) 7-47
Carriage, Class II (Quad Mast Only) 7-48
Internal Hose Reeving Group (Single, Quad Mast Only) 7-51
Internal Hose Reeving Group (Double, Quad Mast Only) 7-55
Mast Tilt Assembly 7-59
Sideshift Carriage Installation (Three Stage) 7-62
Sideshift Carriage Installation (Two Stage) 7-66
Sideshift Carriage Assembly (Cascade) 7-72
Sideshift Carriage Assembly (Bolzoni) 7-74
High Speed Auxiliary Installation 7-76
Standoff Assembly 7-81
Fork Assembly 7-84

APPENDIX A Alphabetical Parts Index

APPENDIX B Numerical Parts Index

MidWestTech | Toyota 7BNCU15, 7BNCU18, 7BNCU20, 7BNCU25 Forklift Parts Catalog |... Order the manual at mid-west-tech.com >

FIGURE 2-3 ITEM NO.	QTY	PART NUMBER	DESCRIPTION	USED ON
6	1	00590-44367-71	Guard, Cable	
7	1	00590-39658-71	Screw	
12	1	Ref.	Plate, Type EE (Consult Technical Support)	E
14	1	00590-01265-71	Rivet, Tag	
15	1	00590-44380-71	Pad, Elbow	
16	1	00590-44370-71	Pad, Deadman Pedal	
17	1	00590-44360-71	Pad, Backseat	
18	1	00590-44372-71	Pad, Floor	
19	1	00590-44373-71	Cover Assembly, Console (Without High Speed Auxiliary) (includes:)	
	1	00590-39627-71	Clip	
20	1	00590-44374-71	Cover Assembly, Console (With High Speed Auxiliary) (includes:)	D
	1	00590-39627-71	Clip	
21	2	00590-44375-71	Screw	
22	14	00590-44376-71	Screw	
23	4	00590-44377-71	Screw	
24	2	00590-44378-71	Washer, Flat	
25	7	00590-44350-71	Nut, Retainer	
28	2	00590-44371-71	Decal, EE	E
29	2	00590-44369-71	Decal, Toyota	
30	1	00590-44341-71	Cover, Steer	
31	1	00590-44342-71	Cover, Eyebrow	A
32	1	00590-44343-71	Cover, Eyebrow	B
33	1	00590-44344-71	Cover, Eyebrow	C
34	1	00590-44345-71	Cover, Front, Left-Hand	
35	1	00590-44346-71	Cover, Knee	
36	1	00590-44347-71	Cover, Front, Center	
37	1	00590-44359-71	Cover, Front, Right-Hand	
39	1	00590-02770-71	Screw	D
40	1	00590-44349-71	Decal, Warning	
41	1	00590-44340-71	Brace, Cover (Without HAS)	
42	1	00590-44351-71	Brace, Cover (With HAS)	D
48	1	00590-44352-71	Decal, Warning	
44	1	00590-44353-71	Cover, HSA Handle	D
45	2	00590-44354-71	Decal, Warning	
46	1	00590-03578-71	Bag, Case	
47	1	00590-01255-71	Pocket	
48	1	00590-44355-71	Plate, Specification	
49	1	00590-44356-71	Decal, Control Handle (Standard)	
50	1	00590-44357-71	Decal, Control Handle (LSA)	

A= 18.5 in. Battery
B= 21.25 in. Battery
C= 23.75 in. Battery
D= High Speed Auxiliary (HSA)
E= Electrically Enclosed (EE)

List 2-3: Finish Instructions (Sheet 1 of 2)

MidWestTech | Toyota 7BNCU15, 7BNCU18, 7BNCU20, 7BNCU25 Forklift Parts Catalog |... Order the manual at mid-west-tech.com >

FIGURE 4-1 ITEM NO.	QTY	PART NUMBER	DESCRIPTION	USED ON
3	1	00590-43600-71	Gear Reducer, Drive Unit, Right-Hand (See Figure 4-2.)	
4	1	00590-43601-71	Gear Reducer, Drive Unit, Left-Hand (See Figure 4-2.)	
5	6	00590-44536-71	Spacer, Brake Mount	
6	2	Ref.	Wheel, Hub Assembly (See Figure 4-3.)	
7	2	00590-44537-71	Spacer, Brake Rotor	
8	16	00590-44538-71	Bolt, Drive Tire	
9	2	00590-44539-71	Switch, Proximity	
11	2	00590-03422-71	Screw	
12	6	00590-02770-71	Screw	
13	6	00590-44540-71	Screw	
14	4	00590-03092-71	Washer, Flat	
15	4	00590-03088-71	Key, Woodruff	
16	12	00590-44541-71	Screw	
17	2	00590-03177-71	Nut	
18	2	00590-02881-71	Nut	
20	2	00590-45290-71	Motor, Traction (See Figure 5-9.)	A, B, C
	2	00590-45291-71	Motor, Traction (See Figure 5-10.)	D
	2	00590-44542-71	Motor, Traction (See Figure 5-11.)	E
21	2	00590-44514-71	Washer, Flat	
22	12	00590-44535-71	Washer, Flat, Hard	
23	2	00590-44533-71	Fitting, Reducer	
24	2	00590-02918-71	Plug, Mechanical	
25	2	00590-44505-71	Fitting, Air Vent	
26	2	00590-44506-71	Brake, Electric, 36 Volt (See Figure 4-5.)	
31	4	00590-44507-71	Screw	
32	8	00590-02940-71	Washer, Flat	
33	Ref.	00590-44515-71	Wrench, Spanner	
34	2	00590-44516-71	Shroud, Fan	
35	2	00590-44517-71	Spacer, Brake Mount	

A= 7BNCU15
B= 7BNCU18
C= 7BNCU20
D= 7BNCU25
E= Electrically Enclosed (EE)

List 4-1: Drive and Brake Installation

MidWestTech | Toyota 7BNCU15, 7BNCU18, 7BNCU20, 7BNCU25 Forklift Parts Catalog |... Order the manual at mid-west-tech.com >

FIGURE 6-1 ITEM NO.	QTY	PART NUMBER	DESCRIPTION	USED ON
1	1	00590-44189-71	Plug, Mechanical	
2	1	00590-44178-71	Reservoir Weldment	
3	1	00590-44157-71	Hose, Steer, Suction, Formed	
4	1	00590-44137-71	Hose, Suction, Auxiliary	
5	2	00590-47074-71	Hose Assembly	
7	1	00590-44123-71	Bracket, Auxiliary	
8	1	00590-44138-71	Hose, Lift, Suction	
9	1	Ref.	Manifold Assembly, Main (See Figure 6-3.)	
10	1	Ref.	Manifold Valve Assembly, High Speed (See Figure 6-7.)	B, C, D, F
11	1	Ref.	Manifold Assembly, Auxiliary (See Figure 6-5.)	B, C, E, F
12	1	00590-41882-71	Tray, Funnel	
13	1	00590-03189-71	Adapter, Filter	
14	1	00590-03551-71	Nut	
15	1	00590-03572-71	Ball	
16	8	00590-03029-71	Screw	
17	2	00590-03127-71	Screw	
18	2	00590-42003-71	Screw	
19	2	00590-03424-71	Screw	
20	6	00590-02940-71	Washer, Flat	
21	1	00590-03061-71	Filter, Element	R
22	4	00590-43234-71	Screw	
23	2	00590-47906-71	Clamp, Hose	
24	2	00590-44174-71	Clamp, Hose	
25	4	00590-03541-71	Clamp, Hose	
26	1	00590-03002-71	Cap, Filler, Breather	
27	1	00590-03441-71	O-Ring	R
28	1	00590-44238-71	Screw	
29	2	00590-03548-71	Hose, Drain	
30	1	00590-03567-71	Spring, Compression	R
31	1	00590-44237-71	Fitting, Hose	
32	1	00590-44236-71	Cap, Dust (Not Shown)	
33	1	Ref.	Guard, Hose	

A= Standard Mast (Without Auxiliary)
B= Standard Mast (With Sideshift)
C= Standard Mast (With HSA1)
D= Standard Mast (With Sideshift, HSA1, HSA2)
E= Quad Mast (With Sideshift)
F= Quad Mast (HSA1)
R= Recommended Spare

List 6-1: Hydraulic System

MidWestTech | Toyota 7BNCU15, 7BNCU18, 7BNCU20, 7BNCU25 Forklift Parts Catalog |... Order the manual at mid-west-tech.com >