TOYOTA

INDUSTRIAL EQUIPMENT

PARTS CATALOG FOR MODEL

8BNCU15, 8BNCU18, and 8BNCU20

Serial Number 55,001 and Up

M/N 00715-00145-14

Issued: 12 June 2014

MidWestTech | Toyota 8BNCU15, 8BNCU18, 8BNCU20 Forklift Parts Catalog | Publication... Order the manual at mid-west-tech.com >

Table of Contents

SECTION 1 General Information

Hardware 1-2
Critical 1-9
Recommended 1-16

SECTION 2 Finish & Accessories

Major Assemblies 2-2
Frame Components 2-4
Overhead Guard Installation 2-6
Finish Instructions 2-8
Operator Backrest 2-13
Battery Gate Installation 2-15
Weighted Battery Spacer and Battery Roller Assembly 2-17
Battery Roller Assembly 2-20
Operator Floor Assembly 2-23
Floor Pad Installation 2-25

SECTION 3 Steering & Controls

Steer Valve Installation 3-2
Steer Motor Installation 3-4
Steer Hoses 3-6
Steer Wheel Assembly 3-8
Steer Hub and Tire Assembly 3-10
Control Handle Installation 3-12
Control Handle Assembly 3-14
Steering, Tiller Installation 3-18

SECTION 4 Drive & Brake

Drive Unit Installation 4-2
Traction Motor Installation 4-4
Drive Unit Assembly 4-6
Drive Wheel Assembly 4-9
Brake Installation 4-12
Brake Assembly 4-14
Deadman Pedal Installation 4-16
Deadman Pedal Assembly 4-18

SECTION 5 Electrical Comp. & System

Electrical System 5-2
Motor Controller Assembly 5-8
Contactor Panel and Fuse Relay Installation 5-10
Vehicle Manager Installation 5-12
Contactor Panel Assembly, Standard 5-14
Contactor Panel Assembly, EE 5-16

MidWestTech | Toyota 8BNCU15, 8BNCU18, 8BNCU20 Forklift Parts Catalog | Publication... Order the manual at mid-west-tech.com >

Table of Contents

Contactor Assembly 5-18
Fuse/Relay Card Installation 5-20
Battery Connector Assembly 5-22
Operator Display Assembly 5-24
Horn Installation 5-26
Drive Motor Assembly 5-28
Drive Motor (EE) 5-30
Lift Motor 5-32
Auxiliary Motor Assembly 5-34
Tractor Fan Installation 5-36

SECTION 6 Hydraulic Components

Hydraulic Hoses,Tractor 6-2
Mast Hose Installation 6-5
Manifold Assembly 6-7
Lift Pump and Motor Installation 6-11
Lift Pump and Motor Assembly 6-13
Steering Pump and Motor Installation 6-15
Steering Pump and Motor Assembly 6-17
Orbital, Steering Valve 6-19
Motor, Hydraulic, Steer 6-21
Reservoir Installation 6-23
Main Lift Cylinder, Right-Hand, FV Mast 6-25
Main Lift Cylinder, Left-Hand, FV Mast 6-27
Free Lift Cylinder, FV Mast 6-29
Main Lift Cylinder Assembly FSV Mast 6-31
Free Lift Cylinder Assembly FSV Mast 6-33
Free Lift Cylinder Quad Mast 6-35
Main Lift Cylinder, Right-Hand, Quad Mast 6-38
Main Lift Cylinder, Left-Hand, Quad Mast 6-41
Tilt Cylinder Assembly 6-44

SECTION 7 Mast

Mast Decals and Mounting Kit, FV Mast 7-2
Mast Installation FV 7-4
FV Mast Assembly 7-6
Hose Reeving, FV Mast Assembly 7-9
Carriage, 4 Roller, FV Mast 7-11
Hang On Sideshift Carriage Assembly 7-13
FSV Mast Assembly 7-15
Mast Main Frame Assembly FSV Mast 7-18
Outer Telescopic Assembly FSV Mast 7-21
Inner Telescopic Assembly FSV Mast 7-23
Free Lift Cylinder Installation FSV Mast 7-25

MidWestTech | Toyota 8BNCU15, 8BNCU18, 8BNCU20 Forklift Parts Catalog | Publication... Order the manual at mid-west-tech.com >

Table of Contents

Integrated Sideshift Installation FSV Mast 7-27
Integrated Sideshift Carriage Assembly FSV Mast 7-29
Integrated Sideshift Attachment Piping FSV Mast 7-31
Chain Reeving FSV Mast 7-33
Free Lift Cylinder Piping FSV Mast 7-35
Internal Hose Reeving FSV Mast 7-37
Sideshift plumbing, Dual Hose Reeving FSV Mast 7-39
Quad Mast Assembly 7-42
Valve Assembly, Lowering Installation, Quad Mast 7-46
Free Lift Hose and Lift Chains - Quad Mast 7-48
Fixed Carriage Assembly - Quad Mast 7-50
Single Function Auxiliary Hose Reeving - Quad Mast 7-52
Double Function Auxiliary Hose Reeving - Quad Mast 7-57
Integrated Sideshift, Quad Mast 7-62
Side Shift Cylinder Piping, Integrated Carriage, Quad Mast' 7-64
Auxiliary Function Carriage Piping Quad Mast 7-66
Hang On Side Shift Carriage Assembly 7-68
Mast Tilt Installation 7-70
Fork Assembly 7-73

SECTION 8 Options & Kits

Load Backrest 8-2
Fire Extinguisher Installation 8-5
Rear Door Assembly 8-7
Quick Disconnect Installation 8-9
Warning Light Installation (LED) 8-11
Auxiliary Light Installation 8-14
Auxiliary Light Assembly 8-18
Battery Gate Sensor 8-20
Travel Alarm Installation 8-22
High Speed Limit Switch Installation (FSV Mast) 8-24
Lift Limit Switch Installation 8-26
High Speed Limit Switch Installation (Quad Mast) 8-28
Bottler's Tilt Limit Switch Installation (FSV Mast Only) 8-30
Tilt Centering Installation 8-32
Dome Light Installation 8-34
Rapid Charge Cover 8-36
Pillar Mounted Clipboard Assembly 8-38
12 Volt Power Hook-up Installation 8-40
Deflector- Fender Installation 8-42
Motion Sensor Installation (CSS) 8-44
Rapid Charge Cover 8-47

MidWestTech | Toyota 8BNCU15, 8BNCU18, 8BNCU20 Forklift Parts Catalog | Publication... Order the manual at mid-west-tech.com >

List 7-3B: Hang On Sideshift Carriage Assembly

FIGURE 7-3B ITEM NO.	QTY	PART NUMBER	DESCRIPTION	SERVICE TYPE	USED ON
			Hang On Sideshift Carriage Assembly		
		00590-44864-71	Cascade Carriage Assembly, Side Shift (37 in. x 8 in.)		
		00590-51667-71	Cascade Carriage Assembly, Side Shift (37 in. x 8 in.) (Bronze Bearings)		
		00590-45602-71	Carriage Assembly, Side Shift (37 in. x 8 in. Wide)		
		00590-51676-71	Carriage Assembly, Side Shift, Cascade		
1	2	00590-45611-71	Bearing, Upper Composite	R	
	2	00590-45612-71	Bearing, Lower Composite	R	A
2	1	00590-44898-71	Cylinder, Assembly, Side Shift (2 in. Each Way, 4 in. Long)	C	
	1	00590-44899-71	Kit, Seal, Rod	R	
3	AR	00590-44900-71	Bearing, Lower Composite	R	
4	4	00590-44901-71	Nut	H	
	4	00590-44914-71	Nut	H	
5	2	00590-44903-71	Hook, Lower		
6	4	00590-44893-71	Washer	H	
7	4	00590-44905-71	Screw, Cap	H	
8		Ref.	(Frame Weldment Not Available)		
9	2	00590-44906-71	Decal, Safety		
10	1	00590-45121-71	Kit, Stop, Fork (Quantity 2 Included)		
11	2	00590-44907-71	Restrictor, Flow (1.5 mm)		
12	2	00590-44908-71	Hook, Lower, Quick Disconnect		
13	2	00590-44909-71	Pin, Quick Disconnect		
14	4	00590-44910-71	Screw, Cap	H	
15	2	00590-44911-71	Guide		
16	2	00590-44912-71	Pin, Roll		
17	1	00590-44828-71	Guard, Pallet		
18	2	00590-44926-71	Screw, Cap	H	
19	2	00590-44869-71	Washer, Lock	H	
20		Ref.	Fitting, 90°, JIC 6-6		
21	1	00590-44784-71	Kit, Lower Hook (Not Shown)		

A = Optional (Bronze)

Service Type R = Recommended Spare

Service Type C = Critical Part

Service Type H = Hardware

MidWestTech | Toyota 8BNCU15, 8BNCU18, 8BNCU20 Forklift Parts Catalog | Publication... Order the manual at mid-west-tech.com >

List 7-25: Hang On Side Shift Carriage Assembly

FIGURE 7-25 ITEM NO.	QTY	PART NUMBER	DESCRIPTION	SERVICE TYPE	USED ON
			Hang On Side Shift Carriage Assembly		
		00590-44864-71	Cascade Carriage Assembly, Side Shift (37 in. x 8 in.)		
		00590-51667-71	Cascade Carriage Assembly, Side Shift (37 in. x 8 in.) (Bronze Bearings)		
		00590-45602-71	Carriage Assembly, Side Shift (37 in. x 8 in. Wide)		
		00590-51676-71	Carriage Assembly, Side Shift, Cascade		
1	2	00590-45611-71	Bearing, Upper Composite	R	
	2	00590-44897-71	Kit, Bearing, Upper Composite (Bronze)	R	A
2	1	00590-44898-71	Cylinder, Assembly, Side Shift (2 in. Each Way, 4 in. Long)	C	
	1	00590-44899-71	Kit, Seal, Rod	R	
3	AR	00590-45612-71	Bearing, Lower Composite	R	
4	4	00590-44901-71	Nut	H	
	4	00590-44914-71	Nut	H	
5	2	00590-44903-71	Hook, Lower		
6	4	00590-44893-71	Washer	H	
7	4	00590-44905-71	Screw, Cap	H	
8		Ref.	(Frame Weldment Not Available)		
9	2	00590-44906-71	Decal, Safety		
10	1	00590-45121-71	Kit, Stop, Fork (Quantity 2 Included)		
11	2	00590-44907-71	Restrictor, Flow (1.5 mm)		
12	2	00590-44908-71	Hook, Lower, Quick Disconnect		
13	2	00590-44909-71	Pin, Quick Disconnect		
14	4	00590-44910-71	Screw, Cap	H	
15	2	00590-44911-71	Guide		
16	2	00590-44912-71	Pin, Roll		
17	1	00590-44828-71	Guard, Pallet		
18	2	00590-44926-71	Screw, Cap	H	
19	2	00590-44869-71	Washer, Lock	H	
20		Ref.	Fitting, 90°, JIC 6-6		
21	1	00590-44784-71	Kit, Lower Hook (Not Shown)		

A = Optional (Bronze)

Service Type R = Recommended Spare

Service Type C = Critical Part

Service Type H = Hardware

MidWestTech | Toyota 8BNCU15, 8BNCU18, 8BNCU20 Forklift Parts Catalog | Publication... Order the manual at mid-west-tech.com >

List 8-5: Warning Light Installation (LED)

FIGURE 8-5 ITEM NO.	QTY	PART NUMBER	DESCRIPTION	SERVICE TYPE	USED ON
			Warning Light Installation (LED)		
1	1	00590-52305-71	Decal, Black		
2	1	00590-51691-71	Wire-Multiconductor		
	1	00590-51735-71	Harness, Wiring (JW5, TS1)		
3	1	00590-52170-71	Guard, Warning Light (LED)		
	1	00590-03034-71	Guard, Warning Light		
4	2	00590-44250-71	Grommet		
5	AR	00590-00811-71	Strap	H	
6	1	00590-00557-71	Mount, Strap		
7	3	00590-50453-71	Screw, Pan	H	
11	3	00590-02992-71	Nut, Hex, Nylon, Locking	H	
12	3	00590-52203-71	Bolt, Metric J	H	
13	1	00590-51828-71	Light Assembly, Warning,Strob (LED), Red		A
	1	00590-51829-71	Light Assembly, Warning, Strob (LED), Amber		B
	1	00590-51830-71	Light Assembly, Warning, Strob (LED), Blue		C
14	1	00590-51671-71	Plate, Mounting, Light		
15	3	00590-03092-71	Washer, Flat	H	
16	3	00590-02912-71	Nut	H	
17	AR	00590-43236-71	Washer, Flat	H	
18	AR	00590-51740-71	Deflector		

A = Red
B = Amber
C = Blue
Service Type H = Hardware

MidWestTech | Toyota 8BNCU15, 8BNCU18, 8BNCU20 Forklift Parts Catalog | Publication... Order the manual at mid-west-tech.com >

Description	Part No.	Page
Cylinder Assembly, Left Hand, 89 in. OACH (Not Shown Includes Items 1 thru 19)	00590-45353-71	6-30
Cylinder Assembly, Left Hand, 95 in. OACH (Not Shown Includes Items 1 thru 19)	00590-45352-71	1-11
Cylinder Assembly, Left Hand, 95 in. OACH (Not Shown Includes Items 1 thru 19)	00590-45352-71	6-28
Cylinder Assembly, Left Hand, 95 in. OACH (Not Shown Includes Items 1 thru 19)	00590-45352-71	6-30
Cylinder Assembly, Main Lift 107/251 OACH/ELVH	00590-52063-71	1-11
Cylinder Assembly, Main Lift 107/251 OACH/ELVH	00590-52063-71	7-17
Cylinder Assembly, Main Lift 107/251 OACH/ELVH 107/251 OACH/ELVH	00590-52063-71	1-11
Cylinder Assembly, Main Lift 107/251 OACH/ELVH 107/251 OACH/ELVH	00590-52063-71	6-32
Cylinder Assembly, Main Lift 83/188 OACH/ELVH	00590-52231-71	1-11
Cylinder Assembly, Main Lift 83/188 OACH/ELVH	00590-52231-71	7-17
Cylinder Assembly, Main Lift 83/188 OACH/ELVH 83/188 OACH/ELVH	00590-52231-71	1-11
Cylinder Assembly, Main Lift 83/188 OACH/ELVH 83/188 OACH/ELVH	00590-52231-71	6-32
Cylinder Assembly, Main Lift 84/191 OACH/ELVH	00590-52060-71	1-11
Cylinder Assembly, Main Lift 84/191 OACH/ELVH	00590-52060-71	7-17
Cylinder Assembly, Main Lift 84/191 OACH/ELVH 84/191 OACH/ELVH	00590-52060-71	1-11
Cylinder Assembly, Main Lift 84/191 OACH/ELVH 84/191 OACH/ELVH	00590-52060-71	6-32
Cylinder Assembly, Main Lift 88/203 OACH/ELVH	00590-52232-71	1-11
Cylinder Assembly, Main Lift 88/203 OACH/ELVH	00590-52232-71	7-17
Cylinder Assembly, Main Lift 88/203 OACH/ELVH 88/203 OACH/ELVH	00590-52232-71	1-11
Cylinder Assembly, Main Lift 88/203 OACH/ELVH 88/203 OACH/ELVH	00590-52232-71	6-32
Cylinder Assembly, Main Lift 95/224 OACH/ELVH	00590-52061-71	1-11
Cylinder Assembly, Main Lift 95/224 OACH/ELVH	00590-52061-71	7-17
Cylinder Assembly, Main Lift 95/224 OACH/ELVH 95/224 OACH/ELVH	00590-52061-71	1-11
Cylinder Assembly, Main Lift 95/224 OACH/ELVH 95/224 OACH/ELVH	00590-52061-71	6-32
Cylinder Assembly, Main Lift 99/227 OACH/ELVH	00590-52062-71	1-11
Cylinder Assembly, Main Lift 99/227 OACH/ELVH	00590-52062-71	7-17
Cylinder Assembly, Main Lift 99/227 OACH/ELVH 99/227 OACH/ELVH	00590-52062-71	1-11
Cylinder Assembly, Main Lift 99/227 OACH/ELVH 99/227 OACH/ELVH	00590-52062-71	6-32
Cylinder Assembly, Main Lift, Right-Hand, 107 in. OACH	00590-52297-71	1-11
Cylinder Assembly, Main Lift, Right-Hand, 107 in. OACH	00590-52297-71	6-39
Cylinder Assembly, Right Hand, 77 in. OACH (Not Shown Includes Items 1 thru 19)	00590-45359-71	1-11
Cylinder Assembly, Right Hand, 77 in. OACH (Not Shown Includes Items 1 thru 19)	00590-45359-71	6-26
Cylinder Assembly, Right Hand, 83 in. OACH (Not Shown Includes Items 1 thru 19)	00590-45358-71	1-11
Cylinder Assembly, Right Hand, 83 in. OACH (Not Shown Includes Items 1 thru 19)	00590-45358-71	6-26
Cylinder Assembly, Right Hand, 89 in. OACH (Not Shown Includes Items 1 thru 19)	00590-45357-71	1-11
Cylinder Assembly, Right Hand, 89 in. OACH (Not Shown Includes Items 1 thru 19)	00590-45357-71	6-26
Cylinder Assembly, Right Hand, 95 in. OACH (Not Shown Includes Items 1 thru 19)	00590-45356-71	1-12
Cylinder Assembly, Right Hand, 95 in. OACH (Not Shown Includes Items 1 thru 19)	00590-45356-71	6-26
Cylinder Assembly, Tilt	00590-51747-71	1-12
Cylinder Assembly, Tilt	00590-51748-71	1-12
Cylinder Assembly, Tilt	00590-51747-71	6-45
Cylinder Assembly, Tilt	00590-51748-71	6-45
Cylinder, Assembly, Side Shift (2 in. Each Way, 4 in. Long)	00590-44898-71	1-12
Cylinder, Assembly, Side Shift (2 in. Each Way, 4 in. Long)	00590-44898-71	7-14
Cylinder, Assembly, Side Shift (2 in. Each Way, 4 in. Long)	00590-44898-71	7-69
Deadman Pedal Assembly	00590-51979-71	1-12
Deadman Pedal Assembly		4-19
Deadman Pedal Assembly	00590-51979-71	4-19
Deadman Pedal Installation		4-17
Decal	00590-47854-71	6-24
Decal, Black	00590-52305-71	8-13
Decal, ESD	00590-45917-71	2-12
Decal, Fork Warning, Cylinder	00590-45272-71	7-17
Decal, Fork Warning, Upper Cross Tie	00590-45272-71	7-3
Decal, Hands Clear	00590-45270-71	7-3
Decal, Label	00590-41928-71	3-16
Decal, Label	00590-05283-71	5-15
Decal, Label	00590-05283-71	5-17
Decal, Label	00590-05283-71	5-21
Decal, Label, AC	00590-48392-71	2-12
Decal, Light	00590-44151-71	8-16
Decal, No Riding	00590-04444-71	2-12
Decal, No Step	00590-52206-71	7-17
Decal, No Step, Lower Cross Tie	00590-45271-71	7-3
Decal, No Step, Warning	00590-45273-71	7-3
Decal, Operator	00590-51456-71	2-12
Decal, Operator Manual	00590-50071-71	2-12
Decal, Operator Manual	00590-50072-71	2-12
Decal, Overhead Guard	00590-52304-71	2-12
Decal, Safety	00590-44906-71	7-14
Decal, Safety	00590-44906-71	7-69
Decal, Toyota	00590-44369-71	2-12
Decal, Toyota Mast	00590-04497-71	2-12
Decal, Toyota, Overhead Guard	00590-04496-71	2-12
Decal, Warning	00590-51493-71	2-12
Decal, Warning	00590-44404-71	2-12
Decal, Warning	00590-45169-71	7-17
Decal, Warning	00590-51493-71	7-17
Decal, Warning, Bat. Remov	00590-51457-71	2-12
Deflector	00590-51740-71	8-13
Deflector- Fender Installation		8-43

MidWestTech | Toyota 8BNCU15, 8BNCU18, 8BNCU20 Forklift Parts Catalog | Publication... Order the manual at mid-west-tech.com >

Part No.	Description	Page
00590-51713-71	Hub, Steer Tire	3-11
00590-51714-71	Kit, Motor Band	6-16
00590-51715-71	Bracket, Sensor Mounting	7-72
00590-51716-71	Pad, Deadman, Pedal	4-19
00590-51717-71	Harness, Wiring	5-7
00590-51718-71	Bearing, Flanged	1-16
00590-51718-71	Bearing, Flanged	4-19
00590-51719-71	Assembly, Bracket	5-21
00590-51720-71	Cover, Cushion, Backrest Pad	2-14
00590-51721-71	Cover, Cushion, Backrest Pad	2-14
00590-51722-71	Bracket	2-5
00590-51723-71	Bracket	2-5
00590-51724-71	Bracket	2-5
00590-51725-71	Bracket, Support	2-5
00590-51726-71	Plate	4-19
00590-51727-71	Plate	4-19
00590-51728-71	Bracket, Tiller	3-3
00590-51729-71	Bracket, Tray	8-37
00590-51729-71	Bracket, Tray	8-48
00590-51730-71	Plate, Shield	2-5
00590-51731-71	Hose Assembly, (Manifold TR Port to Left Tilt Cyl. Rod End)	6-4
00590-51732-71	Hose Assembly, (Manifold TR Port to Left Tilt Cyl. Rod End)	6-4
00590-51733-71	Bracket, Fan, Mouting	5-37
00590-51734-71	Bracket, Bin Light	8-19
00590-51735-71	Harness, Wiring (JW5, TS1)	8-13
00590-51736-71	Light Assembly, Auxiliary (LED)	8-19
00590-51738-71	Bracket, Bin Light	8-19
00590-51739-71	Clamp	8-16
00590-51740-71	Deflector	8-13
00590-51741-71	Bracket, Tilt Sensor	8-33
00590-51742-71	Bracket, Guard	8-33
00590-51743-71	Wire, Multiconductor (Includes:)	8-33
00590-51744-71	Rail, Tilt	8-33
00590-51745-71	Tiller, Steering, Optional (6.37 in. Long)	3-19
00590-51746-71	Bracket, Positioner	8-33
00590-51747-71	Cylinder Assembly, Tilt	1-12
00590-51747-71	Cylinder Assembly, Tilt	6-45
00590-51748-71	Cylinder Assembly, Tilt	1-12
00590-51748-71	Cylinder Assembly, Tilt	6-45
00590-51749-71	Gear, Pinion, Helical	4-5
00590-51751-71	Bracket, Lift Motor	6-12
00590-51752-71	Anchor, Chain	3-5
00590-51753-71	Hose Assembly, Lift Suction	6-4
00590-51754-71	Hose Assembly, Lift Suction	6-4
00590-51755-71	Axle, Shaft	4-7
00590-51756-71	Hose, Suction	6-4
00590-51757-71	Spring, Torsion	1-19
00590-51757-71	Spring, Torsion	4-19
00590-51758-71	Cover Armrest	2-12
00590-51759-71	Cover, Top	2-12
00590-51760-71	Cover, Motor L.H	2-12
00590-51761-71	Cover, Motor R.H	2-12
00590-51762-71	Plate	2-24
00590-51763-71	Bumper	1-16
00590-51763-71	Bumper	2-24
00590-51764-71	Bracket, Tiller	3-3
00590-51765-71	Bracket	6-16
00590-51766-71	Cover, Steer, Lower	2-12
00590-51768-71	Cover, Steer Tiller	2-12

Part No.	Description	Page
00590-51769-71	Cover, Rapid Charge	2-12
00590-51770-71	Cover	8-37
00590-51770-71	Cover	8-48
00590-51771-71	Hose Assembly, (Manifold TC Port to Right Tilt Cyl. Cap End)	6-4
00590-51772-71	Hose Assembly, Side Shift, Left	6-6
00590-51773-71	Hose Assembly, Side Shift, Right	6-6
00590-51774-71	Hose Assembly, Auxiliary 1	6-6
00590-51775-71	Hose Assembly, Auxiliary 2	6-6
00590-51776-71	Hose Assembly	3-7
00590-51777-71	Hose Assembly, Auxiliary (SSR and SSL)	6-6
00590-51778-71	Hose Assembly (Steer Valve L Port to Steer Motor Left-Hand Port)	3-7
00590-51779-71	Hose Assembly (Steer Valve R Port to Steer Motor Right-Hand Port)	3-7
00590-51780-71	Hose Assembly, Lift (CYL-1)	6-6
00590-51782-71	Hose Assembly, (Left Tilt Ram End Cap to Right Tilt Ram End Cap)	6-4
00590-51783-71	Hose Assembly, (Lift Pump Press. Port to Manifold PI Port)	6-4
00590-51784-71	Hose Assembly (Steer Valve T Port to Manifold S-Ret Port)	3-7
00590-51786-71	Hose Assembly (Steer Valve T Port to Manifold S-Ret Port)	3-7
00590-51787-71	Hose Assembly (Steer Valve T Port to Manifold S-Ret Port)	3-7
00590-51788-71	Hose Assembly, Lift Pressure (P1)	6-4
00590-51789-71	Hose Assembly, Lift (CYL-1)	6-6
00590-51791-71	Hose Assembly (Steer Pump Press. Port to Steer Valve P Port)	3-7
00590-51792-71	Hose Assembly (Steer Pump Press. Port to Steer Valve P Port)	3-7
00590-51793-71	Hose Assembly (Steer Pump Press. Port to Steer Valve P Port)	3-7
00590-51795-71	Hose Assembly, (Manifold TR Port to Right Tilt Cyl. Rod End)	6-4
00590-51796-71	Hose Assembly, (Manifold TR Port to Right Tilt Cyl. Rod End)	6-4
00590-51797-71	Hose Assembly, (Lift Pump Press. Port to Manifold PI Port)	6-4
00590-51798-71	Plug	6-9
00590-51799-71	Plug	6-9
00590-51800-71	Plug	6-9
00590-51801-71	Cable Assembly (TML-W to TLA-W)	5-7
00590-51802-71	Cable Assembly (TML-V to TLA-V)	5-7
00590-51803-71	Cable Assembly (TML-U to TLA-U)	5-7
00590-51804-71	Cable Assembly (TMR-W to TRA-W)	5-7
00590-51805-71	Cable Assembly (TMR-V to TRA-V)	5-7
00590-51806-71	Cable Assembly (TMR-U to TRA-U)	5-7
00590-51807-71	Cable Assembly (LM-W to LA-W)	5-7
00590-51808-71	Cable Assembly (LM-V to LA-V)	5-7
00590-51809-71	Cable Assembly (LM-U to LA-U)	5-7
00590-51810-71	Cable Assembly (TP4 to AUX)	5-7
00590-51811-71	Cable Assy, Elec (AUX(+) to STR-2)	5-7
00590-51812-71	Cable Assembly (TLA-B+ to TPC-2)	5-7
00590-51813-71	Cable Assembly (TRA-B+ to TPC-2)	5-7
00590-51814-71	Cable Assembly (LA-B+ to LPC-2)	5-7
00590-51815-71	Kit, Seal	1-17
00590-51815-71	Kit, Seal	6-20
00590-51816-71	Bearing, Set (Includes:)	4-7
00590-51817-71	Bearing, Set (Includes:)	4-7
00590-51818-71	Terminal	5-23
00590-51819-71	Filter, Hydraulic, Element (W/O Shield)	1-17

MidWestTech | Toyota 8BNCU15, 8BNCU18, 8BNCU20 Forklift Parts Catalog | Publication... Order the manual at mid-west-tech.com >