REPAIR PARTS MANUAL

Snorkelift.

UNO-41D/41G

NOTES:

Always give the serial number and model number of your "Snorkelift" when ordering parts.

This information is found on the nameplate which is mounted at the Ground Controls Station.

Be sure to order all parts by their part number, and if possible specify routing of shipment.

All correspondence relative to this unit, such as field reports, discrepancy reports, requests for service information, etc., should be directed to:

Snorkel-Economy
A Figgie International Company
P O BOX 4065
ST JOSEPH MO 64504-0065

Attention Service Manager

Snorkel ECONOMY
A FIGGIE INTERNATIONAL COMPANY
ST. JOSEPH, MISSOURI


Publication no. RPM-002-UNO-41D/41G
September 1991

MidWestTech | Snorkel UNO-41D, UNO-41G Articulating Boom Lift Repair Parts Manual |... Order the manual at mid-west-tech.com >

BOTTOM BOOM INSTALLATION

ITEM	PART NO	DESCRIPTION	REQ
1.	C-015-0824	BOTTOM BOOM WELDMENT	1
2.	C-015-0822	BOTTOM FOLLOWER BAR WELDMENT	1
3.	D-015-1414	CYLINDER ASSEMBLY, BOTTOM BOOM LIFT	1
	B-015-1102	REPLACEMENT HYDRAULIC TUBE	
	A-601-0092	REPLACEMENT CARTRIDGE NEEDLE VALVE	
	A-601-0093	REPLACEMENT CARTRIDGE HOLDING VALVE	
4.	A-015-0182	PIN, LIFT CYLINDER ROD END	1
5.	A-015-0685	PIN, LIFT CYLINDER TO TURNTABLE	1
6.	A-015-0689	PIN, FOLLOWER BAR TO TURNTABLE	1
7.	A-015-0687	PIN, BOTTOM BOOM TO TURNTABLE	1
8.	A-007-0033	PIN LOCK	4
9.		WASHER 5/16 MEDIUM LOCK	8
10.	A-007-0473	CAPSCREW 5/16-18 DRILLED HD	8
11.		.040 DIA SS SAFETY LOCKWIRE	AR
12.	250-2032	BEARING, GARMAX #GM2024-32	4
13.	A-015-0123	BEARING SPACER	2
14.	250-0026	BEARING, GARMAX #GM2024-16	1
15.	250-0016	BEARING, GARMAX #GM2428-32	4
16.	A-015-0126	BEARING SPACER	2

MidWestTech | Snorkel UNO-41D, UNO-41G Articulating Boom Lift Repair Parts Manu... Order the manual at mid-west-tech.com >



Order the manual at mid-west-tech.com >
MidWestTech | Snorkel UNO-41D, UNO-41G Articulating Boom Lift Repair Parts Manual | Publication 01533020