REPAIR PARTS MANUAL

Snorkelift.

UNO-41E

NOTES:

Always give the serial number and model number of your "Snorkelift" when ordering parts.

This information is found on the nameplate which is mounted at the Ground Controls Station.

Be sure to order all parts by their part number, and if possible specify routing of shipment.

All correspondence relative to this unit, such as field reports, discrepancy reports, requests for service information, etc., should be directed to:

Snorkel-Economy
A Figgie International Company
P O BOX 4065
ST JOSEPH MO 64504-4065

Attention Service Manager

Snorkel ECONOMY
A FIGGIE INTERNATIONAL COMPANY
ST. JOSEPH, MISSOURI

Publication no. RPM-002-UNO-41E
May 1991

MidWestTech | Snorkel UNO-41E Articulating Boom Lift Repair Parts Manual | Publication... Order the manual at mid-west-tech.com >

REPAIR PARTS - SECTION 1
INDEX


Bottom Boom Installation . . . . . Page 1 - 5
Chassis/Turntable Mounting . . . . . Page 1 - 3
Drive Train Installation . . . . . Page 1 - 31
Extension Cylinder Assembly . . . . . Page 1 - 17
Gear Reduction Unit . . . . . Page 1 - 33
Hose Carrier Assembly . . . . . Page 1 - 19
Lower Floating Turret Installation . . . . . Page 1 - 7
Middle Boom Installation . . . . . Page 1 - 9
Placards Installation . . . . . Page 1 - 41
Platform Installation . . . . . Page 1 - 21
Platform Rotator Assembly . . . . . Page 1 - 23
Platform Rotator Gear Box . . . . . Page 1 - 25
Steer Yoke and Wheel Installation . . . . . Page 1 - 29
Steering Installation . . . . . Page 1 - 27
Swing Drive, Gear Products Manufacture . . . . . Page 1 - 37
Swing Drive, Hub City Manufacture . . . . . Page 1 - 39
Top Boom Assembly, Base Boom . . . . . Page 1 - 13
Top Boom Assembly, Tip Boom . . . . . Page 1 - 15
Turntable Cowling/Swing Drive Installation . . . . . Page 1 - 35
Upper Floating Turret Installation . . . . . Page 1 - 11

MidWestTech | Snorkel UNO-41E Articulating Boom Lift Repair Parts Manual | Publica... Order the manual at mid-west-tech.com >

CHASSIS/TURNTABLE MOUNTING

ITEM	PART NO	DESCRIPTION	REQ
1.	D-015-0762	CHASSIS	1
2.	D-015-0621	TURNTABLE	1
3.	C-015-0059	ROTATION BEARING GEAR	1
4.	A-556-0051	CAPSCREW 5/8-11 SELF LOCKING	38
5.		WASHER 5/8 FLAT ASTM-F436	38
6.	A-015-0466	CHASSIS COVER	2
7.		WASHER 5/16 MEDIUM FLAT	8
8.		WASHER 5/16 MEDIUM LOCK	8
9.		CAPSCREW 5/16-18 x 3/4 LG HEX HD GR 5	8

MidWestTech | Snorkel UNO-41E Articulating Boom Lift Repair Parts Manual | Publica... Order the manual at mid-west-tech.com >



Order the manual at mid-west-tech.com >