WSM

WORKSHOP MANUAL
DIESEL ENGINE

05 SERIES

Kubota

MidWestTech | Kubota 05 Series Diesel Engine Service Manual | Publication 01640

Order the manual at mid-west-tech.com >

MECHANISM

CONTENTS

- FEATURE M-1
- ENGINE BODY M-3
  - [1] CYLINDER BLOCK M-3
  - [2] CYLINDER HEAD M-3
  - [3] CRANKSHAFT M-5
  - [4] PISTON AND PISTON RINGS M-5
  - [5] CONNECTING ROD M-7
  - [6] ROCKER ARM M-7
  - [7] CAMSHAFT M-7
  - [8] FUEL CAMSHAFT M-9
  - [9] FLYWHEEL M-9
- LUBRICATING SYSTEM M-11
  - [1] GENERAL M-11
  - [2] OIL PUMP M-13
  - [3] RELIEF VALVE M-13
  - [4] OIL FILTER CARTRIDGE M-15
  - [5] OIL PRESSURE SWITCH M-15
- COOLING SYSTEM M-17
  - [1] GENERAL M-17
  - [2] WATER PUMP M-17
  - [3] THERMOSTAT M-19
  - [4] RADIATOR (not included in the basic engine) M-19
  - [5] RADIATOR CAP M-21
- INTAKE / EXHAUST SYSTEM M-23
  - [1] AIR CLEANER (not included in the basic engine) M-23
  - [2] MUFFLER (not included in the basic engine) M-23
- FUEL SYSTEM M-25
  - [1] GENERAL M-25
  - [2] INJECTION PUMP M-25
    - (1) Pump Element M-27
    - (2) Delivery Valve M-27
    - (3) Dumping Valve M-29
    - (4) Injection Control M-29
  - [3] INJECTION NOZZLE M-31
  - [4] FUEL FILTER (not included in the basic model) M-31
  - [5] GOVERNOR M-33
  - [6] AUTOMATIC ADVANCE TIMER (not included in the basic model) M-37
- ELECTRICAL SYSTEM M-41
  - [1] CHARGING SYSTEM M-41
    - (1) Alternator M-41
    - (2) IC Regulator M-41
- TURBO CHARGER SYSTEM M-43
    - (1) Mechanism M-45
    - (2) Turbine M-47
    - (3) Compressor M-47
    - (4) Bearing M-49
    - (5) Seals (Piston Rings) M-51

MidWestTech | Kubota 05 Series Diesel Engine Service Manual | Publication 01640 Order the manual at mid-west-tech.com >