M-3B Terratrac Forklift

Parts Catalog

1013

CASE CONSTRUCTION

Order the manual at mid-west-tech.com >

ALPHABETICAL INDEX

- A -

ACCELERATOR..... 63
ACCELERATOR LINKAGE..... 63
AIR CLEANER..... 71
AMMETER..... 67
AXLE SHAFT..... 17

- B -

BATTERY..... 65
BATTERY HOLD DOWN..... 65
BEARINGS - engine connecting rods. 27
BEARINGS - engine main..... 27
BUCKET INSTALLATION..... 111
BUSHING - camshaft..... 31
BUSHING - piston pin..... 27

- C -

CABLES - spark plug..... 43
CAMSHAFT - engine..... 31
CEMENT BUCKET..... 125
CARBURETOR - engine..... 37
CHOKE..... 65
CLUTCH..... 45
COIL - engine..... 43
CONNECTING RODS - engine..... 27
COUNTERWEIGHT..... 7
CRANKCASE - engine..... 21
CRANKCASE GUARD..... 101
CRANKSHAFT - engine..... 27
CYLINDER - bucket dump..... 111 & 131
CYLINDER - load clamp..... 127 & 135
CYLINDER - mast tilt..... 51 & 53
CYLINDER - terralogger lift.... 115 & 133

- D -

DASH PANNEL..... 67
DECALS..... 95
DISTRIBUTOR - engine..... 43
DOZER..... 123

- E -

ENGINE - camshaft & oil pump..... 31
ENGINE - carburetor..... 37
ENGINE - crankcase & head..... 21
ENGINE - crankshaft & pistons..... 27
ENGINE - electrical parts..... 43
ENGINE - fuel pump..... 35
ENGINE - kits..... 108
ENGINE - governor..... 39
ENGINE - oil filter..... 41
ENGINE - water pump..... 33
EXTENSIONS - mast..... 115

- F -

FENDER & TANK..... 65
FILTER - engine oil..... 41
FILTER - hydraulic oil..... 55
FINAL DRIVE..... 17
FLOOR PLATE..... 63
FLYWHEEL..... 29
FLYWHEEL HOUSING..... 25
FORKS - mast..... 107
FRAME - engine..... 7
FRONT END PLATE - engine..... 21
FUEL LINES..... 69
FUEL PUMP..... 35
FUEL STRAINER..... 69

- G -

GAUGE STICK & CAP - hyd. oil..... 65
GAUGE STICK - oil..... 21
GEAR COVER - engine..... 21
GENERATOR..... 43
GOVERNOR - engine..... 39
GREASE GUN..... 95 & 101
GUARD - crankcase..... 101
GUARD - overhead..... 51
GUARDS - rock..... 105

- H -

HEAD LIGHTS..... 87
HEAT INDICATOR..... 67
HOOD - engine..... 73
HOUR METER..... 99
HYD. SYSTEM - bucket..... 113
HYD. SYSTEM - load clamp..... 129
HYD. SYSTEM - standard tractor..... 55
HYD. SYSTEM - terralogger..... 117

- I -

IGNITION SWITCH..... 67

- K -

KITS - engine..... 108

- L -

LEVERS - brake..... 63
LEVERS - hydraulic..... 63
LIGHT SWITCH - head..... 67
LIGHT SWITCH - tail..... 67
LOAD CLAMP..... 127
LOADER INSTALLATION..... 111

Order the manual at mid-west-tech.com >

- M -

MANIFOLD - engine..... 23
MAST EXTENSIONS..... 119
MAST FORKS..... 107
MAST - part I..... 87
MAST - part II..... 89
MAST - part III..... 91
MAST - part IV..... 93
MOUNTING PLATE - mast..... 19
MUD PAN - track..... 75
MUFFLER..... 73

- O -

OIL FILTER - engine..... 41
OIL FILTER - hydraulic..... 55
OIL PRESSURE - gauge..... 67
OIL PUMP - engine..... 31
OVERHEAD GUARD..... 51

- P -

PEDAL - clutch..... 15
PINS - piston..... 27
PISTON - engine..... 27
PIVOT BAR..... 19
PIVOT BLOCK - track..... 75
PRESSURE SWITCH..... 99
PULL HOOK..... 83
PULLEY - fan..... 27
PUMP - engine oil..... 31
PUMP - fuel..... 35
PUMP - hydraulic..... 55 & 59
PUMP - water..... 33

- R -

RADIATOR..... 73
RADIATOR SHROUD..... 73
RAIN CAP..... 73
RECOIL SPRING..... 75
RECOIL SPRING HOUSING..... 75
RING GEAR - flywheel..... 29
RINGS - piston..... 29
ROCK GUARDS..... 105

- S -

SEAT..... 65
SEAT CUSHIONS..... 65
SIDE PLATE..... 19
SOLENOID SWITCH..... 43
SPACER TUBES - f/d..... 13
SPARK PLUG..... 43
SPROCKET - tractor drive..... 83
STARTER..... 43

-S- (CONT'D)

STARTER SWITCH..... 67
STEERING RODS..... 63
SUPPORT - engine..... 7

- T -

TAIL LIGHTS..... 73
TANK & FENDER - hyd. & fuel..... 65
TAPPETS - valve..... 31
TERRALOGGER..... 115
THERMOSTAT..... 43
TOOLS & EQUIPMENT..... 95
TORQUE CONVERTER..... 45
TORQUE TUBE..... 7
TRACK CHAIN..... 85
TRACK FRAME..... 75
TRACK FRONT IDLER..... 81
TRACK ROLLERS..... 77
TRACK SHOES..... 103
TRACK SUPPORT IDLERS..... 79
TRANSMISSION - part I..... 9
TRANSMISSION - part II..... 11


- V -

VALVE - engine..... 31
VALVE - hydraulic..... 55 & 61
VALVE COVER..... 67
VALVE COVER - engine..... 23
VALVE GUIDES - engine..... 31
VALVE SPRINGS - engine..... 31
VOLTAGE REGULATOR..... 43

- W -

WATER PUMP..... 33
WRENCHES..... 95
WIRING HARNESS..... 67

Order the manual at mid-west-tech.com >



Order the manual at mid-west-tech.com >