TEREX

TLB840PS - Tier 4 Interim

Backhoe Loader



Illustrated Parts Catalog
Ersatzteilkatalog
Catalogue pièces
Catálogo de repuestos

Serial No.:

Issue date: 20-June-2013

Language: en, de, fr, es

Revision No.: 0.10

Reference No.: 1121-0

WORKS FOR YOU.™

Order the manual at mid-west-tech.com >

Table of content - English

Chapter	Heading	Page
Chassis - Centremount 2 Wheel Steer - Short		18
Chassis - Centremount 2 Wheel Steer - Long		20
Chassis - Sideshift 2 Wheel Steer - Short		22
Stabilizer Cylinder		24
Chassis - Sideshift 2 Wheel Steer - Long		26
Stabilizer Cylinder		28
Chassis - 2ws - Ss Short - Tier 3 & 4		30
Chassis - 2ws - Ss Short - Tier 3 & 4		34
Chassis - 2ws - Ss Long - Tier 3 & 4		36
Chassis - 2ws - Ss Long - Tier 3 & 4		40
Chassis - 2ws - Cm Short - Tier 3 & 4		42
Chassis - 2ws - Cm Long - Tier 3 & 4		44
Bonnet - White		46
Bonnet - Yellow		50
Bonnet - White		54
Bonnet - Yellow		58
Wheels And Tyres - Mitas - 20f 30r - White		62
Wheels And Tyres - Mitas - 20f 30r - Yellow		64
Wheels And Tyres - Mitas - 18f 24r - White		66
Wheels And Tyres - Mitas - 18f 24r - Yellow		68
Wheels And Tyres - Mitas - 20f 26r - White		70
Wheels And Tyres - Mitas - 20f 26r - Yellow		72
Wheels And Tyres - Mitas - 18f 28r - White		74
Wheels And Tyres - Mitas - 18f 28r - Yellow		76
Wheels And Tyres - Firestone 18f - Mitas 30r - White		78
Wheels And Tyres - Firestone 18f - Mitas 30r - Yellow		80
Wheels And Tyres - Mitas - 18f 26r - White		82
Wheels And Tyres - Mitas - 18f 26r - Yellow		84
Front Axle - 2ws - 15:1		86
Front Axle - 15:1 - Axle Housing		88
Front Axle - 2ws - 15:1 - Swivel Housing And Steering Cylinder		90
Front Axle - 2ws - 15:1 - Bevel Gear Set		92
Front Axle - 2ws - 15:1 - Differential		94
Front Axle - 2ws - 15:1 - Double U-Joint		96
Front Axle - 2ws - 15:1 - Wheel Hub		98
Front Axle - 2ws - 15:1 - Final Reduction		100
Front Axle - 2ws - 16.5:1		102
Front Axle - 2ws - 16.5:1 - Axle Housing		104
Front Axle - 2ws - 16.5:1 - Swivel Housing And Steering Cylinder		106
Front Axle - 2ws - 16.5:1 - Bevel Gear Set		108
Front Axle - 2ws - 16.5:1 - Differential		110
Front Axle - 2ws - 16.5:1 - Double U-Joint		112
Front Axle - 2ws - 16.5:1 - Wheel Hub		114
Front Axle - 2ws - 16.5:1 - Final Reduction		116
Steering System - 2ws - Gear		118
Steering System - Hoses		120
Hardnose - White		122
Hardnose - Yellow		124
Engine - 90hp Turbo Aftercooled		126
Engine Parts - Tlb840		128
Engine Parts - Tlb840		130
Engine - Tlb840 - Gaskets & Oil Cooler		132
Engine - Tlb840 - Fuel Injection Pump		134
Engine - Tlb840 - Fuel Injector Complete		136
Engine - Tlb840 - Pre-Fuel Filter Assy		138
Engine - Tlb840 - Glow Plugs		140
Engine - Tlb840 - Pre-Fuel Filter Kit		142
Engine - 90 Hp - Tier 4i		144
Fuel System - Fuel Tank		148
Fuel System - Fuel Pipes		150
Fuel System - Fuel Tank - T4		152
Fuel System - Fuel Pipes - T4		154
Exhaust System From Serial Number H200 7 1093		158
Exhaust System T4i		160
Induction System - Air Cleaner		162
Induction System - Air Cleaner - Powercore T4		164
Radiator Assembly		166
Charge Air Tubes		168
Radiator Assembly		170
Charge Air Tubes		172
Cooling - Tier 4		174
Cooling System - Charge Air Tubes		176
Radiator Assembly		178
Charge Air Tubes		180
Radiator Assembly		182
Charge Air Tubes		184

MidWestTech | Terex TLB840PS Tier 4 Backhoe Loader Parts Manual | Publication 1121-0

Order the manual at mid-west-tech.com >

Table of content - English

Chapter	Heading	Page
Torque Converter		186
Driveline Bolting - Carraro		188
Driveline Bolting - Carraro		190
Transmission - Powershift Servo Synchro - Mech. Parking Brake		194
Transmission - Powershift Servo Synchro - Sahr Parking Brake		196
Transmission - Tlb1 - Mechanical Parking Brake - Tier 4		198
Transmission - Tlb1 - Shar Parking Brake - Tier 4		200
Transmission - Synchro - Mech. Parking Brake		202
Transmission - Sps - Shar Parking Brake - Tier 4		204
Consumable		206
Consumable		208
Not Serviced		210
Not Serviced		212
Not Serviced		214
Not Serviced		216
Not Serviced		218
Not Serviced		220
Not Serviced		222
Not Serviced		224
Not Serviced		226
Gearshift - Servo Power Synchro - 2ws - 4 Speed		228
Gearshift - Servo Power Synchro - 2ws - 3 Speed		230
Gearshift - Servo Powered Synchro - 2ws - 4 Speed - Tier 4		232
Gearshift - Servo Powered Synchro - 2ws - 3 Speed - Tier 4		234
Rear Axle - 2ws		236
Rear Axle - 2ws - Axle Housing		238
Rear Axle - 2ws - Bevel Gear Set		240
Rear Axle - 2ws - Differential		242
Rear Axle - 2ws - Differential Locking		244
Rear Axle - 2ws - Brakes		246
Rear Axle - 2ws - Wheel Hub & Final Reduction		248
Digger Valve - Without Digger - Servo		250
Digger Valve - Without Digger - Servo - Valve Assy, Inlet		254
Digger Valve - Without Digger - Servo - Valve Assy, Auxiliary		256
Digger Valve - Without Digger - Servo - Valve Assy, Slew		258
Digger Valve - Without Digger - Servo - Valve Assy, Boom		260
Digger Valve - Without Digger - Servo - Valve Assy, Dipper		262
Digger Valve - Without Digger - Servo - Valve Assy, Bucket		264
Digger Valve - Without Digger - Servo - Valve Assy, Stabilizer		266
Digger Valve - Without Digger - Servo - Valve Assy, Telescopic		268
Digger Valve - Without Digger - Servo - Valve Assy, Outlet		270
Digger Valve - Sideshift - Servo - Ext. Dipper - Without Qa		272
Digger Valve - Sideshift - Servo - Ext. Dipper - Valve Assy, Inlet		276
Digger Valve - Sideshift - Servo - Ext. Dipper - Valve Assy, Auxiliary		278
Digger Valve - Sideshift - Servo - Ext. Dipper - Valve Assy, Slew		280
Digger Valve - Sideshift - Servo - Ext. Dipper - Valve Assy, Boom		282
Digger Valve - Sideshift - Servo - Ext. Dipper - Valve Assy, Dipper		284
Digger Valve - Sideshift - Servo - Ext. Dipper - Valve Assy, Bucket		286
Digger Valve - Sideshift - Servo - Ext. Dipper - Valve Assy, Stabilizer		288
Digger Valve - Sideshift - Servo - Ext. Dipper - Valve Assy, Extending		290
Digger Valve - Sideshift - Servo - Ext. Dipper - Valve Assy, Outlet		292
Digger Valve - Sideshift - Servo - Ext. Dipper - With Qa		294
Digger Valve - Sideshift - Servo - Ext. Dipper - Valve Assy, Inlet		298
Digger Valve - Sideshift - Servo - Ext. Dipper - Valve Assy, Auxiliary		300
Digger Valve - Sideshift - Servo - Ext. Dipper - Valve Assy, Slew		302
Digger Valve - Sideshift - Servo - Ext. Dipper - Valve Assy, Boom		304
Digger Valve - Sideshift - Servo - Ext. Dipper - Valve Assy, Dipper		306
Digger Valve - Sideshift - Servo - Ext. Dipper - Valve Assy, Bucket		308
Digger Valve - Sideshift - Servo - Ext. Dipper - Valve Assy, Stabilizer		310
Digger Valve - Sideshift - Servo - Ext. Dipper - Valve Assy, Extending		312
Digger Valve - Sideshift - Servo - Ext. Dipper - Valve Assy, Outlet		314
Digger Valve - Centremount - Servo - Ext. Dipper - Without Qa		316
Digger Valve - Centremount - Servo - Ext. Dipper - Valve Assy, Inlet		320
Digger Valve - Centremount - Servo - Ext. Dipper - Valve Assy, Auxiliary		322
Digger Valve - Centremount - Servo - Ext. Dipper - Valve Assy, Slew		324
Digger Valve - Centremount - Servo - Ext. Dipper - Valve Assy, Boom		326
Digger Valve - Centremount - Servo - Ext. Dipper - Valve Assy, Dipper		328
Digger Valve - Centremount - Servo - Ext. Dipper - Valve Assy, Bucket		330
Digger Valve - Centremount - Servo - Ext. Dipper - Valve Assy, Stabilizer		332
Digger Valve - Centremount - Servo - Ext. Dipper - Valve Assy, Extending		334
Digger Valve - Centremount - Servo - Ext. Dipper - Valve Assy, Outlet		336
Digger Valve - Centremount - Servo - Ext. Dipper - With Qa		338
Digger Valve - Centremount - Servo - Ext. Dipper - Valve Assy, Inlet		342

MidWestTech | Terex TLB840PS Tier 4 Backhoe Loader Parts Manual | Publication 1121-0

Order the manual at mid-west-tech.com >

Table of content - English

Chapter	Heading	Page
Digger Valve - Centremount - Servo - Ext. Dipper - Valve Assy, Auxiliary		344
Digger Valve - Centremount - Servo - Ext. Dipper - Valve Assy, Slew		346
Digger Valve - Centremount - Servo - Ext. Dipper - Valve Assy, Boom		348
Digger Valve - Centremount - Servo - Ext. Dipper - Valve Assy, Dipper		350
Digger Valve - Centremount - Servo - Ext. Dipper - Valve Assy, Bucket		352
Digger Valve - Centremount - Servo - Ext. Dipper - Valve Assy, Stabilizer		354
Digger Valve - Centremount - Servo - Ext. Dipper - Valve Assy, Extending		356
Digger Valve - Centremount - Servo - Ext. Dipper - Valve Assy, Outlet		358
Torque Convertor Hydraulics - Powershift Servo Synchro		360
Main Hydraulics - 2ws - Hyd. Tank		362
Main Hydraulics - 2ws - Hyd. Pump & Filter		364
Throttle Controls		368
Throttle Controls - Tier 4		370
Service Brake - 2ws		372
Service Brake - Brake Pedal Assembly		374
Handbrake - Overcentre		376
Handbrake - Solenoid Operated		378
Cab And Mounts		380
Door Assemblies		382
Side Windows		384
Rear Window		388
Front Windows		390
Cab Structure		392
Roof Liner		394
Wipers		396
Electrics		398
Canopy And Mounts		400
Canopy Structure		402
Electrics		404
Canopy And Mounts		406
Front Windows		408
Canopy Structure		410
Electrics		412
Cab - Glazed Structure - Tier 4		414
Cab - Door Assemblies - Tier 4		416
Cab - Side Windows - Tier 4		418
Cab - Rear Windows - Tier 4		422
Cab - Front Windows - Tier 4		424
Cab - Structure - Tier 4		426
Cab - Roof Liner - Tier 4		428
Cab - Wipers - Tier 4		430
Cab - Electrics - Tier 4		432
Canopy And Mounts		434
Front Windows		436
Canopy - Structure		438
Canopy - Electrics		440
Cab Trim - Front Console		442
Cab Trim - Side Console - Right Hand		444
Cab Trim - Side Console - Left Hand		446
Cab Trim - Floor Plate Seals		448
Canopy Trim - Front Console		450
Canopy Trim - Side Console - Right Hand		452
Canopy Trim - Side Console - Left Hand		454
Cab Trim - T4 - Front Console		456
Cab Trim - T4 - Side Console - Right Hand		458
Cab Trim - T4 - Side Console - Left Hand		460
Cab Trim - T4 - Floor Plate Seals		462
Canopy Trim - Front Consonle - T4		464
Canopy Trim - Side Console - Right Hand - T4		466
Canopy Trim - Side Console - Left Hand - T4		468
Floormat - Cab - Servo Controls		470
Floormat - Canopy - Antislip		472
Heater - Cab - Without Air Con		474
Heater - Cab - Without Air Con - Air Ducts		478
Heater - Cab - With Air Con		480
Heater - Cab - With Air Con - Air Ducts		484
Heater - Cab - With Air Con - Compressor		486
Heater - Hvac Assy		490
Heater - Cab - With Air Con - Engine Bay Seals		494
Heater - Automatic Climate Control Assy		496
Heater - Air Ducts		500
Heater - Compressor		502
Heater - Canopy - None		506
Heater - Cab - Without Air Con - Tier 4		508
Heater - Cab - Without Air Con - Tier 4		512

MidWestTech | Terex TLB840PS Tier 4 Backhoe Loader Parts Manual | Publication 1121-0

Order the manual at mid-west-tech.com >

Hardnose - Yellow

Item Position Posición	Part number Teilenummer Numéro de pièces Número de la pieza	Anzahl Qty. Quant. El núm.	English	Deutsch	Français	Español	Remarks Bemerkungen Remarque Observación
1	T101571	1	Pressed Steel Grille Weld Assembly	Grill	Grille	Rejilla	
2	T117865	2	M8x40 Socket Button Screw	Schraube M8 X 40	Vis M8 X 40	Tornillo M8 X 40	
3	T103432	1	Edge Cap	Dichtring	Joint Etancheite	Reten	
4	T101534	1	Battery Cover	Deckel	Couvercle	Cubierta	
5	3009492X1	4	Bolt - Hex. M10 X 25	Schraube M10 X 25	Boulon M10 X 25	Tornillo	
6	390597X1	2	Washer, Large - M10	Scheible	Rondelle	Arandela	
7	T101693	1	Battery Clamp	Halteschelle	Collier	Abrazadera	
8	390734X1	2	Washer M10-21-2 Z	Unterlegscheibe	Rondelle - M10	Arandela	
9	6114915M1	1	Battery Tray	Mulde - Batterie	Plateau - Batterie	Bandeja - Bateria	
10	T111630	8	Hole Plug (Black)	Stopfen	Bouchon	Tapon	
11	1442739X1	2	Nut Nyloc M16	Flachmutter	Ecrou Blocage	Tuerca	
12	1441664X1	2	Washer M16-30-3 Z	Scheibe	Rondelle	Arandela	Eco 1880
13	MS35-250	2	M16 X 250 Bolt	Maschschraube - M16 X 250	Boulon - M16 X 250	Perno - M16 X 250	Eco 1880
14	339034X1	4	Nut, Hex. - M16, Coarse, Grade 8	Mutter Metrisch	Ecrou Métrique	Tuerca	
15	3019575X1	4	Washer M16 Hardened	Scheibe	Rondelle	Arandela	
16	6114503M1Y02	1	Hardnose Casting (Fermec Yellow)	Gussteil	Coulee	Fundicion	
17	1441500X1	2	Nut M6 Z5 Nyloc	Flachmutter M6	Ecrou	Tuerca De Retencion	
18	390971X1	4	Washer M6-12-1 Zwel	Scheibe - M6	Rondelle - M6	Arandela	
19	339804X1	2	Bolt, Hex, - M6 X 25	Maschschrb Metr - M6	Goupille	Tornillo	
20	T116884	1	Bracket - Bonnet Latch	Haltearm	Support Fixation	Soporte	
21	T112278	1	Bonnet Catch Lower Assembly	Falle	Loquet Porte	Fijador	
22	390972X1	2	Washer M8-17-1 Zwel	Scheibe - M8	Rondelle M8	Arandela	
23	339761X1	2	Bolt M8-25 Z5f	Bolzen M8 X 25	Goupille	Tornillo	
24	3516218M2	2	Screw S/Tapping	Schraube	Vis	Tornillo	
25	T102367	1	Bonnet Release Cable	Kabel	Cable	Cable	

MidWestTech | Terex TLB840PS Tier 4 Backhoe Loader Parts Manual | Publication 1121-0

Order the manual at mid-west-tech.com >

Loader Lever Assembly

Item Position Posición	Part number Teilenummer Numéro de pièces Número de la pieza	Anzahl Qty. Quant. El núm.	English	Deutsch	Français	Español	Remarks Bemerkungen Remarque Observación
1	T102629	1	Loader Lever Assy - Std	Hebel	Levier	Palanca	
2	T102646	1	Knob Top	Knob Top	Knob Top	Knob Top	
3	3522621M5	1	Base Control Knob	Griff	Poignée De Levier	Empuñ. Palanca	
4	3516886M1	2	Screw C/Sk 1/4 Lng	Schraube	Vis	Tornillo	
5	3019531X1	1	Pin - Roll	Spannhulse	Goupille Elastique	Pasador Elástico	
6	6109381M91	1	Cradle - Rexroth Valve W/Assy	Fahrschemel	Berceau	Soporte	
7	T102711	1	Gaiter - Std	Manschette	Manchette	Manguito	
8	394367X1	1	Nut, Hex. - Nyloc, M8	Flachmutter M8	Ecrou Blocage	Tuerca De Retencion	
9	6108769M1	1	Washer-M8 Nord-Lock	Federring M8	Rondelle De Blocage	Arandela De Freno	
10	339159X1	1	Bolt M8-65	Bolzen	Boulon	Tornillo	
11	6102844M1	2	Rodend-M12 Spherical	Kugelkopf, Plastik	Support De Fixation	Soporte De Fijación	
12	3009505X1	2	Hex. Bolt, M12 X 25 - Coarse	Bolzen M12 X 25	Boulon	Perno	
13	1664405M1	1	Tie Mm T50s	Kabelbinder	Attache Cable	Enlace De Cable	
14	6109802M91	1	Loader Control Column Assy	Haltevorrichtung	Ensemble De Support	Apoyadero, Conj.	
15	6106560M1	2	Bush	Buechse	Douille	Anillo	
16	6106561M3	2	Spacer-Loader Controls	Abstandstueck	Entretoise	Traviesa	
17	T102631	1	Lever W/Assy - Loader	Hebel	Levier	Palanca	
18	6106562M1	1	Plate-L/Cont. Tie Bar	Stab	Barre	Placa	
19	6108769M1	1	Washer-M8 Nord-Lock	Federring M8	Rondelle De Blocage	Arandela De Freno	
20	339291X1	1	Bolt M8-55 Z5s	Bolzen M8 X 55	Goupille	Tornillo	
21	3522507M3	4	Pin Parallel	Sicherungsstift	Goupille ÐArrêt	Pasador	
22	3516043M94	1	Switch And Harness - Ldr. Cont. Lever	Beschirrung	Interrupteur	Haz	
23	3522894M1	2	Boot Control Knob	Schutzkappe	Coffre	Fuelle	
24	3520328M3	2	Spring	Feder	Siege De Ressort	Muelle	
25	3521894M4	2	Button Ldr Cntls	Knopf	Bouton	Botón	

MidWestTech | Terex TLB840PS Tier 4 Backhoe Loader Parts Manual | Publication 1121-0
Order the manual at mid-west-tech.com >

Bucket Cylinder Hoses

Item Position Posición	Part number Teilenummer Numéro de pièces Número de la pieza	Anzahl Qty. Quant. El núm.	English	Deutsch	Français	Español	Remarks Bemerkungen Remarque Observación
1	6115157M91	1	Hose Assy - Boom/Dipper Bucket Re	Schlauch Kpl	Ensemble Durit	Con. De Manguera	
2	6115152M91	1	Hose Assy - Boom/Dipper Bucket He	Hose Assy - Boom/Dipper Bucket He	Hose Assy - Boom/Dipper Bucket He	Hose Assy - Boom/Dipper Bucket He	
3	356268X1	2	Union	Schraubanschluss	Union	Unión	
4	355574X1	2	Nut, Hex. - 7/8" Unf, Lock	Mutter 7/8" Unf	Ecrou 7/8" Unf	Tuerca	
5	6115158M91	1	Hose Assy - Dipper Bucket Re	Hose Assy - Dipper Bucket Re	Hose Assy - Dipper Bucket Re	Hose Assy - Dipper Bucket Re	
6	6115153M91	1	Hose Assy - Dipper Bucket He	Hose Assy - Dipper Bucket He	Hose Assy - Dipper Bucket He	Hose Assy - Dipper Bucket He	
7	3009493X1	4	Bolt M10-30 Z5c	Maschschraube M10	Boulon M10 X 30	Perno	
8	390734X1	4	Washer M10-21-2 Z	Unterlegscheibe	Rondelle - M10	Arandela	
9	T102353	1	Hose Bracket - W/Assy RH	Hose Bracket - W/Assy RH	Hose Bracket - W/Assy RH	Hose Bracket - W/Assy RH	
10	T102483	2	Hyd Hose Sleeve	Hulse Fuer Hydraulikschlauch Aus Stahl	Manchon	Mancha	
11	T102362	1	Hose Bracket W/Assembly	Halter Kpl	Ensemble Support	Cjt. Soporte	
12	3009493X1	2	Bolt M10-30 Z5c	Maschschraube M10	Boulon M10 X 30	Perno	
13	390734X1	2	Washer M10-21-2 Z	Unterlegscheibe	Rondelle - M10	Arandela	
14	724497M1	4	Tie 380mm T120r	Kabelbinder	Attache Câble	Enlace De Cable	
15	T102354	1	Hose Bracket - W/Assy LH	Hose Bracket - W/Assy LH	Hose Bracket - W/Assy LH	Hose Bracket - W/Assy LH	
16	3517731M1	2	Clamp-Hose	Schlauchschelle	Bride Pour Tutaux	Argolla De Fijación	
16	6114114M1	1	Hose Clamp (140-160mm Range)	Halteschelle (140-160mm)	Collier (140-160mm)	Abrazadera (140-160mm)	
17	6112656M1	2	Tube Saddle	Sattel	Selle	Silla	
17	T101034	1	Shock Mount	Halterung	Montant	Montante	
18	394367X1	4	Nut, Hex. - Nyloc, M8	Flachmutter M8	Ecrou Blocage	Tuerca De Retencion	
19	391039X1	4	Washer M8-24-2 Z	Scheibe M8	Rondelle M8	Arandela	
20	6115019M1	2	Hose Retainer	Haltering	Reteneur	Retenedor	
21	6115022M1	1	Hydraulic Clamp - Bottom	Halteschelle	Collier	Abrazadera	

MidWestTech | Terex TLB840PS Tier 4 Backhoe Loader Parts Manual | Publication 1121-0

Order the manual at mid-west-tech.com >